英文

iDO

Smart Watch

Operation Instructions

ID216



Thank you for choosing our product. Please read the instructions carefully before use.

Start to Use

1. Turn On

- Automatic turn-on after charging



Note: The Watch must be charged and activated before the first use. Please use the original power adapter to charge the watch.

- Turn on by pressing and holding DOWN button.



2. Download and Install VeryFitPro

You can directly scan the QR code to download VeryFitPro or search "VeryFitPro" in the APP store to download and install.

Note: Conditions required by hardware platform system are as below.

iOS 9.0 and above

Android 4.4 and above

Bluetooth 4.2

3. Please connect to mobile phone correctly.

✓ Correct operation: Pair the Watch via VeryFitPro APP on your phone.



✗ Wrong operation: Pair the Watch directly via Bluetooth in phone Settings.



4. Bind the Watch

Drop down on APP home to show binding request. Select product model, and tap "Confirm Binding" to complete binding.

日文

スマートスポーツウォッチ

取扱ガイド

ID216



本製品をお選びいただき、ありがとうございます。
ご使用の前に取扱ガイドをよく読んでおいてください

使用開始

1. 電源オン

- 充電すると電源が自動でオンになります。



注：初めてのご使用の際は充電によるウォッチのアクティブ化が必要です。原産の充電器を使って充電してください。

- 次の図のボタンを長押しして開けます。



2. VeryFitProをダウンロードしてインストールする

QRコードをスキャンしてVeryFitProをダウンロードまたはスマホのAPPストアによってVeryFitProをダウンロードしてインストールする。

注意：デバイスのハードウエアシステムが次のバージョンでなければならない

iOS 9.0及びそれ以上

Android 4.4及びそれ以上

ブルートゥース4.2対応

3. スマホと正しく接続してください

✓ スマホのVeryFitProアプリを使ってウォッチとペアリングする。



✗ 直接スマホのブルートゥースでウォッチとペアリングする。



4. ウォッチをバインディングする

Appホームページを引き下げバインディング請求が出てきます。製品型番を選択し「バインディングします」をタッチし、バインディング完了。

Operation Instructions



1. Key Instructions

UP button	Press	In screen locked state: Unlock screen
		Sibling interface: circularly flip
		Pop-up interface: confirm
		During stopwatch/timer working: pause/continue
		During sports paused: continue sport
	Press and hold	During sports: pause sports
		Other interfaces: quickly launch sports
DOWN button	Press	In screen locked state: Unlock screen
		During sports paused: stop sports
		Pop-up interface: Cancel/Close
		During stopwatch working: count
		During timer working: stop timekeeping and quit
		Other interfaces: return to previous interface/dial
	Press and hold	Turn on/Turn off

2. Operation on Screen

Screen	Tap	Select to enter the next interface/select current item.
	Tap and hold	Tap and hold in the main dial interface to enter dial switching interface.
	Slide left /right	Switch interfaces left and right.
	Slide up /down	Switch interfaces up and down.

3. Operation of Gestures



Raise to turn on backlight.



Hang to turn off backlight.

Note: ON/OFF of this function can be set up through mobile APP.

Introductions to Sports Functions

1. Activate Sports



Enter Sports list interface, slide up or down to select sports item, and tap icon to start sports.

2. Start Sports


3
Wear your watch tightly for more accurate heart rate detection

When Sports is activated, the Watch will show sports countdown. Sports starts after the countdown.

3. Operations during Sports



In screen locked state


Press and hold UP button to pause sports
Slide left/right to switch indicated sports data

In screen unlocked state

操作説明



1.ボタン操作

上ボタン	押す	画面を消した状態の下で：画面を点灯します
		同レベルメニュー：ページめくり
		ポップアップ：確認
		ストップウォッチ・カウント中：ストップ/続く
		運動ストップ中：運動を続ける
	長押し	運動中：ストップ
		その他画面：素早く運動開始
下ボタン	押す	画面を消した状態の下で：画面を点灯します
		運動ストップ中：運動を終了する
		ポップアップ：キャンセル/閉じる
		ストップウォッチ使用中：回数をカウント
		タイマー使用中：タイマーを閉じる
		その他画面：前のメニューに戻る/文字盤
	長押し	電源オン・オフ

2. スクリーン操作

スクリーン	クリック	次の画面に入る・当項目を選択する
	長押し	メイン文字盤画面を長押しして文字盤切替画面に入る
	左右スライド	画面を横で切り替える
	上下スライド	画面を上下で切り替える

3. ジェスチャーによる操作



腕を上げると、画面を点灯します



下げると、画面を消します

注：この機能はAPPによりオン・オフにすることができます。

運動機能についての紹介

1. 運動機能を開く



運動リストの画面を開き、スクリーンを上下スライドにより運動項目を選択し、アイコンをタッチして運動を開きます。

2. 運動を開始する



スポーツに入る時、腕時計がスポーツカウントダウンを示し、カウントダウンが終了した後、スポーツに入ります

3. 運動中の操作



画面を消した状態の下


上ボタンを長押しして運動をストップ
左右にスライドして運動データの表示を切り替える

画面を点灯している状態

4. Reminders during Sports

Heart rate reminder

During sports, the Watch will continuously detect current heart rate. If current heart rate exceeds the maximum heart rate, the Watch will remind to reduce sports intensity or stop sports through vibration and interface alarm.
Set your safe heart rate reminder through More>Heart rate zone>User defined Max. heart rate in the mobile APP.

5. Pause or Stop Sports

Pause sports:

In the unlocked state, press and hold UP button to pause sports. Tap Continue icon to resume sports.
In the paused state, slide up to view current sports data.



Stop sports

In the paused state, select STOP to stop sports.
After sports, the Watch will keep details of the sports. View in sports records.

Instructions to Other Functions

1. Health Data



Enter Health Data interface to view the accumulated steps, calories and distances when wearing the Watch that day.

2. Notifications

Turn on smart reminder

When it is in use, you need to turn on "Smart Reminder" on the APP end, select and turn on notification types to be reminded, and this function requires keeping the connection between the Watchand mobile phone.

View message

When receiving message, the Watch will vibrate to remind. If the message is not immediately viewed after being received, slide down to view the message.

Delete message

The Watch can save the most recent 12 notifications. Beyond the limit, the earliest notice will be automatically deleted once a new notice is received. When the notification content exceeds one screen, it will be displayed continuously on the second screen.

- On the message list view interface, slide left single message box to show Delete icon, and tap Delete icon to delete the message.

- Slide down to the top of message list, and tap Clear icon to clear all messages.


Clear all messages
Thomas 7:10AM
Tomorrow's visual design review meeting, remem-
Thomas 7:20AM
Tomorrow's visual design review meeting, remem-
nterest 15:30
material has
ed to the UI/UX
Thomas 7:20AM
Tomorrow's visual design review meeting, remem-
Pinterest 7:30AM
New UI material has been added to the UI/UX

3. Heart Rate

Measuring
Please stand still

The Watch supports heart rate detection. Slide to Heart Rate Detection interface, hold for two seconds, the Watch will automatically detect heart rate. Please stand still during the detection, so that the Watch can output more accurate heart rate data.

Note: To improve the accuracy of heart rate detection, please wear the Watch correctly and keep the wearing parts clean.

4. Weather

Weather function allows you keep track of the weather in your city. Because weather data is obtained through mobile phone network, it is required to maintain the connection between the Watch and the phone to timely update weather data.

5. More Functions

Stopwatch
It is available to record multiple times.
Timer
It is available to set count-down. Remind through vibration after count-down is over.
Alarm clock
Set alarm clocks in mobile APP.
When it is the set time, the Watch will remind through vibration. In case of no operation after 20s, the alarm clock will automatically stop. After 5 minutes, the alarm clock will remind again. Press UP/DOWN button to pause the alarm, and after 5 minutes the alarm clock will remind again.

Call reminder
Call Reminder can be set in mobile APP. When it is in use, turn on Call Reminder function in mobile APP, and keep the connection between the Watch and the phone. When there is an incoming call, the Watch will remind through vibration. Close the call pop-up by pressing UP/DOWN button.

---

4. 運動中の通知

心拍数通知

運動中にウォッチはこの状態での心拍数を検査し続けます。検出された心拍数が最大の心拍数を越えた場合は、ウォッチがバイブレーションや画面によって通知をします。このような時は運動の強度を下げるか運動を停止する必要があります。
スマホAPPの「さらに>心拍数区間>最大心拍数を設定」の中でお客様ご自分の安全心拍数通知を設定することができます。

5. 運動をストップ・終了する

運動をストップする：

ロック解除の状態では、上ボタンを長押しして運動をストップ、続ける場合は「続ける」ボタンを押してください。
ストップ状態では、上にスライドすると現在の運動データをチェックすることができます。



運動を終了する

ストップ状態で運動を終了すると選択すれば終了になります。運動を終了したらウォッチが今回の運動情報を保存してくれますので、ウォッチの運動記録からチェックできます。

その他の機能紹介

1. ヘルスデータ



ヘルスデータ画面に入るとその日ウォッチ着用している間の累計歩数や、カロリー、距離などをチェックすることができます。

2. メッセージ通知

スマート通知を開く
使用する際にAPPから「スマート通知」を開き、通知する必要のあるメッセージパターンを選択し開きます。この機能はスマホとウォッチが接続していなければ作動できません。
メッセージをチェック
本製品のウォッチにメッセージ着信があった時はバイブレーションで通知します。通知をもらってすぐにチェックすることができなかった場合は、文字盤画面を下へスライドすることでメッセージがチェックできます。
通知を消去
このウォッチには通知を12通まで保存できます。12通を超えた場合は新しい通知が着信するたびに最も古い通知を１通削除されます。通知内容が１つの画面に表示しきれない場合は、次の画面に表示します。

- 通知表示画面に、１つの通知表示を左へスライドすると「消去」が表示されます。タッチするとその通知が消されます。

- 通知表示画面のトップまで下へスライドすると「全て消去」が表示されます。タッチすると全ての通知が消されます。


全てのメッセージを消去します。
Thomas 7:10AM
Tomorrow's visual design review meeting, remem-
Thomas 7:20AM
Tomorrow's visual design review meeting, remem-
nterest 15:30
material has
ed to the UI/UX
Thomas 7:20AM
Tomorrow's visual design review meeting, remem-
Pinterest 7:30AM
New UI material has been added to the UI/UX

3. 心拍数

測定中です
動かないでください

このウォッチは心拍数モニタリングができます。スクリーンをスライドし心拍数検査画面が表示されると、２秒を待つと自動で心拍数モニタリングを開始します。より正確な心拍数データをとらえるために検査中にできるだけ動かないでいてください。

注：心拍数検出の正確性を確保するため、ウォッチを正しく着用し、着用する手首を清潔にしてください。

4. 天気

「天気」機能はお客様が所在の都市の天気状況を随時に知ることができる機能です。天気情報はスマホのネットワークを通して取得するため、新しい天気情報を常に入手するためにはスマホとウォッチの接続を常に保つ必要があります。

5. その他の機能

ストップウォッチ
複数のタイムを記録できます。
タイマー
カウントダウンを設定できます。カウント終了後にバイブレーションで通知します。
アラーム
スマホのAPPにて設定できます。
設定のアラームの時間になると、ウォッチはバイブレーションで通知します。20秒操作なしの場合は自動でストップし、5分後に再度通知します。上/下ボタンを押すとアラーム通知をストップすることができるが、5分後に再度通知します。

着信通知
スマホAPPで着信通知を設定できます。使用する際はAPPで「着信通知」機能をオンにし、スマホとウォッチが接続状態でいなければならなりません。スマホに着信があった時にウォッチがバイブレーションで通知します。上/下ボタンを押すと着信通知を閉じることができます。

6. Control Center

DND mode
Slide up once on dial interface, and enter control center interface. Tap DND icon ☾ to lighten the icon ☾. DND mode is on. Tap DND icon again to dim the icon. DND mode is off.

Brightness adjustment
Slide up once on dial interface, and enter control center interface. Bightness level is defaulted as Level 2 ☼. Tap the brightness icon to switch it to Level 3 ☼. Tap the icon again to switch it to Level 1 ☼. Tap the icon again to switch it to Level 2 ☼. Conduct repeatedly in order.

System settings
Slide up once on dial interface, and enter control enter interface,and tap System Setting icon ⚙ to enter system settings.

In system settings, you can enter:

- Dial settings: tap and enter this function to switch dials among different styles.
- Pressing and holing UP button settings: tap and enter this function to set sports style entered by pressing and holing UP button.
- Factory data reset settings: tap to enter factory data reset procedure.
- Firmware information: tap and enter to view firmware information and Bluetooth address.

Product Specifications

Product model	ID216	Screen model	1.3"TFT-LCD (round)
Battery capacity	260mAh	Working voltage	3.8V
Charging time	≤2 hours, 25℃ constant temperature	Battery duration	7 days (Battery life depends on how you use it.)
Waterproofing grade	5ATM	Bluetooth version	BLE4.2
Working temperature	10℃-45℃	Product weight	56.1g
Product frequency	2402-2480MHz	Max. transmission power consumption	0 dBm
Waterproofing: Use of the Watch at the time of hand washing, raining and swimming in shallow water is supported, but use under hot shower, diving, underwater diving, surfing etc. is unsupported.			

Care Instructions



Replace watch strap



Please use a soft brush or clean soft cloth to clean the Watch.

- Please stop using the Watch and disconnect all connections with other equipment before cleaning and maintenance.
- Please keep the Watch and its accessories dry. Do not dry them with external heating equipment such as microwave oven or hair dryer.
- Do not place the Watch and its accessories in an area where the temperature is too high or too low, which may cause malfunction, fire or explosion.
- Avoid strong shock or vibration to prevent damage to the Watch and its accessories or failure.
- Please do not disassemble or modify the Watch and its accessories without permission. In case of failure, please contact after-sales service.

⚠ FAQ

● Mobile phone cannot be connected to the Watch.
1. It is recommended to update VeryFitPro to the latest version.
2. It is recommended to quit all APPs, reactivate the phone Bluetooth and re-connect.
3. Confirm that system of the phone is Android 4.4 or iOS 9.0 and above.

● The Watch has no message or call reminders.
1. It is required to turn on smart reminder function and call reminder function in APP and synchronize to the Watch.
2. The Watch should be paired with mobile phone through Bluetooth.
3. It is required to keep Watch Bluetooth under normal connection.

●Bluetooth disconnects frequently.

1. Relatively long distance between the Watch and the phone may cause Bluetooth disconnection, and the effect of Bluetooth connection over 7 meters will be obviously weak.

2. Shielding between the Watch and the phone will affect the connection, and human body and metal jewelry will interfere Bluetooth connection signal.

3. Please confirm that Bluetooth function of the phone is normal.

●More detailed FAQs can be obtained through help and feedback in the APP.
Operating steps: VeryFitPro > 👤 > FAQ

Safety and Product Information Notes

⚠ Warning

Battery warning
Do not disassemble, bore or damage the battery. Do not disassemble the built-in batteries of non-replaceable battery devices. Do not use sharp objects to remove the battery.

Health Warning
If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitoring strap.

---

6. コントロールセンター

おやすみモード
文字盤画面を上へスライドし、コントロールセンターに入ります。「おやすみ」 ☾ のアイコンをタッチするとアイコンが点灯され、おや ☾ すみモードがオンになります。またタッチすると明かりが消え、おやすみモードオフになります。

明るさを調整する
文字盤画面を上へスライドし 、コントロールセンターインターフェイスに入り、明るさのディフォルトは2レベル明るさであり☼、明るさアイコンをクリックすると、明るさを3レベル明るさに切り替え☼、もう一度明るさアイコンをクリックすると、明るさが1レベル明るさに切り替え☼、再びクリックすると、2レベル明るさに切り替え☼、順次に循環します。

システム設定
文字盤画面を上へスライドし、コントロールセンターに入ります。「システム設定」 ⚙ をタッチして入ります。

「システム設定」においては次の項目を操作することができます。

- 文字盤設定：この機能を使って違う模様の文字盤を切り替えることができます。
- 上ボタン長押し設定：この機能を使って上ボタンを長押しによって選べる運動パターンが設定できます。

- リセット：タッチするとリセット開始します。

ファームウエア：タッチすると本製品のウォッチのファームウ
- エアやブルートゥース情報が確認できます。

製品仕様

型番	ID216	スクリーンパターン	1.3"TFT-LCD（円）
バッテリー容量	260mAh	作動電圧	3.8V
充電所要時間	≤2時間, 25℃ 恒温	バッテリ持続時間	7日間（持続時間は使用方法により異なります）
防水レベル	5ATM	ブルートゥースのバージョン	BLE4.2
作動温度	10℃-45℃	重さ	56.1g
周波数	2402-2480MHz	最大送信電力	0 dBm
防水：手洗いや雨濡れ、浅い水域での水泳などの際に使用することが可能ですが、お湯によるシャワーや潜水、ダイビング、サーフィンなどの時には使用しないでください。			

手入れ



バンドの交換



柔らかい歯ブラシやきれいな雑巾で整理してください

- 手入れの前にデバイスの使用を停止し、その他のデバイスとの接続を切らしてください。
- デバイスやその部品を常に乾燥のままにしてください。電子レンジやドライヤーなどの外部加熱設備による乾燥処理はおやめください。
- 温度の極めて高いまたは極めて低いエリアに本製品のデバイス及びその部品を放置しないでください。故障や火事、爆発など起こりかねないのでご注意ください。
- 本製品が強烈な衝撃や振動を受けることを避けてください。デバイスやその部品などが損害し故障になる場合がございますので、ご注意ください。
- デバイス及びその部品を勝手に取り外しまたは改装しないでください。故障の場合はアフターサービスへご連絡ください。

⚠ よくある質問

● スマホがウォッチと接続できません
1.VeryFitProの最新バージョンをダウンロードしてください。
2. 全てのアプリを閉じて、スマホブルートゥースを再度立ち上げてからまたお試しください。
3. スマホのシステムがAndroid 4.4またはiOS 9.0以上のバージョンであるか確認してください。

● ウォッチにはメッセージ・電話着信の通知がありません。
1. APPの中からスマート通知機能と電話着信通知機能を起動させてウォッチにシンクロさせなければなりません。

2. スマホはウォッチとブルートゥースによるペアリングをさせなければなりません。
3. ウォッチのブルートゥースが正常な接続状態でいなければなりません。

● ブルートゥースの接続はよく切れます。

1. スマホとウォッチとの距離は遠すぎるとブルートゥースが切れてしまうことがあります。7 メートルの距離を超えると接続が悪くなることがあります。
2. 人体や金属アクセサリーなどの遮断物がスマホとウォッチとの接続に干渉を与えることがあります。
3. スマホのブルートゥースが正常に動作できるか確認してください。

● その他の質問はAPPの「ヘルプ＆フィードバック」にてご確認ください。

操作手順：VeryFitPro > 👤 >よくある質問

安全性および製品情報のお知らせ

⚠ 警告

サイクリングについての警告
バッテリーを分解したり、穴を開けたり、損傷したりしないでください。また、交換不可のバッテリー装置の内部バッテリーを分解したり、鋭利なものでバッテリーを取り外したりしないでください。

健康に関する警告
心臓ペースメーカーまたはその他の埋め込み型電子機器を装着している場合は、心拍ベルトを着用する前に医師に相談してください。

The watch's optical heart rate sensor glows green and flashes. If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician if you can wear this product.

The device tracks your daily activities through sensors. These data are intended to tell you about your daily activities, such as steps, sleep, distance, heart rate and calories, but may not be completely accurate.

The device, accessories, heart rate sensors and other relevant data are designed for entertainment and fitness, not for medical purposes. They are not applicable to the diagnosis, monitoring, treatment or prevention of any diseases or symptoms. The heart rate data is for reference only. We are not responsible for any consequences caused by any data deviation.

Cycling Warning

If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitoring strap.

Notes:

Device data should be synchronized once every seven days to avoid data loss.

The device has no waterproof effect on seawater, acidic and alkaline solution, chemical reagent and other corrosive liquids. The damage or defect caused by misuse or improper use is beyond the warranty scope.

The device supports the use under cold shower or swimming excluding diving.

- In daily use, the device should be avoided from wearing too tight. Please keep the parts where the device touches the skin dry.
- During heart rate detection, please keep your arm stand still.

The device meets the EU ROHS criterion. Please refer to IEC 62321, EU ROHS Directive 2011/65/EU and revised directive.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could avoid the user's authority to operate the equipment.This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.

CAUTION
RISK OF EXPLOSION IF BATTERY IS REPLACED
BY AN INCORRECT TYPE
DISPOSE OF USED BATTERIES ACCORDING
TO THE INSTRUCTIONS

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.

ウォッチの光学心拍センサーは緑色に点灯して点滅する。癲癇または点滅する光源に敏感であれば、この製品を着用することができるか否かを医者に相談してください。

このデバイスは、センサーを介してあなたの毎日の活動を追跡します。これらのデーターは、歩数、睡眠、距離、心拍数とカロリデーターなど、毎日の活動について説明することを目的としているが、完全に正確というわけではありません。

このデバイス、付属品、心拍数センサーおよびその他の関連データーは、医療目的ではなく、娯楽目的やフィットネス目的のために設計されており、病気や病症の診断、監視、治療または予防に適用されません。心拍数データーは参考用であり、データーの偏差から生じる影響について、一切の責任を負うものではありません。

サイクリングに関する警告

常に良好な判断力を維持し、安全な方法でサイクリングしてください。お使いの自転車とハードウェアは正しく保守され、すべての部品が正しく取り付けられていることを確認してください。

注意事項

- データ紛失を防ぐため、デバイスのデータは七日間に一度シンクロするようにしてください。
- 本製品は海水や酸性・アルカリ性溶液、化学溶剤など浸蝕力のある液体に防水効能はありません。濫用あるいは不当な使用による損害や欠陥などは保証範囲ではありません。
- 冷水シャワーや水泳時に本製品のデバイスを使用可能ですが、潜水時のご使用は避けてください。
- 日常使用中にデバイスをきつくしないように適切に着用し、着用部位の清潔を維持するようにしてください。
- 心拍数検査中に腕はできるだけ動かないようにしてください

本製品は欧州連合ROHS標準に適応し、IEC 62321と欧州連合RoHS指令2011/65/EU及びその修正指令を参考したものであることを声明致します。

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could avoid the user's authority to operate the equipment.This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.

CAUTION
RISK OF EXPLOSION IF BATTERY IS REPLACED
BY AN INCORRECT TYPE
DISPOSE OF USED BATTERIES ACCORDING
TO THE INSTRUCTIONS

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.

Scan here to download
VeryFitPro

FC CE RoHS