cover

BYTECH
THE ART OF TECHNOLOGY

Bluetooth®

BY-AU-BE-233-AC

CHROME
OPEN EAR TWS EARBUDS

pages 1 & 2

1

Package Contents:

(2) True Wireless Earbuds 1.1in. x .7 in. x .99in.
(2.8cm x 1.79cm x 2.53cm)
(1) Charging Case 2.62 in. x 1.27in. x 1.96in.
(6.67cm x 3.24cm x 5cm)
(1) Type-C USB Charging Cable 11.8in.(30cm)
(1) Instruction Manual

Specifications:

- BT Version: 6.0
- Input Power: 5V⎓1A
- Driver Diameter: 10mm
- Frequency Response: 20 Hz-20 kHz
- Earbuds Capacity: 30mAh
- Power Bank Capacity: 200mAh
- Earbuds Charging Time: Up to 2 Hour
- Case Charging Time: Up to 2 Hours
- Charging Interface: Type C USB
- Talk/Music Time: Up to 4 Hours (dependent on volume level)
- Total Play Time: 16 Hours
- Standby Time: Up to 100 Hours
- Transmission Range: Up to 33 feet

Features:

- Open Ear TWS earbuds - enjoy listening to music while being open to the sounds of your environment
- Touch Control
- Charging case included
- Hands-free
- Battery power indicator digital display
- Supreme sound

***Up to 3 hours of earbud playtime, plus 12 hours from the charging case.**

pages 3 & 4

2 3

Operation Guide



Getting Started

Before using this device, fully charge it. Charging instructions can be found on page 5 & 6..

Open the charging case and take out the earbuds and place them in your ears. The earbuds will pair to each other automatically.

Pairing

1. Go to Bluetooth® Settings on your mobile device.
2. Turn Bluetooth® ON, on your device.
3. On your Bluetooth® device, select "**BY-BE-233**" from the list of available devices.

Using Siri or Google Assistant

On either earbud, Long Press the control surface for 3 seconds - AI assistant signals its activation.*

*The AI assistant on your device must have been previously set up prior to this operation.

4

Basic Functions

Right Earbud:

- Tap the control surface twice to play or pause the audio.
- Tap the control surface three times to skip to the next audio track.
- Single tap to raise the volume.

Left Earbud:

- Tap the control surface twice to play or pause the audio.
- Tap the control surface three times to skip to the previous audio track.
- Single tap to lower the volume.

Phone calls:

When there is an incoming call, the unit will pause the playback and ring to alert you of the call. Phone call functions work the same on either of the earbuds.*

To answer an incoming call, double tap the control surface of either earbud. To end a call, double tap the control surface. To reject an incoming call, Long press the control surface for 2 seconds.

*Volume controls may not work during phone calls with some smartphone models.

pages 5 & 6

5

Power ON/OFF

- Long press control surface of the left or right earbud for 3 seconds to turn ON the earbuds (the earbuds will automatically power ON when removed from the charge case).
- Long press control surface of the left or right earbud for 5 seconds to turn OFF the earbuds (earbuds will automatically power OFF when placed in the charge case).
- If for any reason you move out of the range of the device you are listening to while using this product, the earbuds will disconnect. When you are back in range you may need to perform the pairing procedure again as this depends on battery life. If the earbuds are powered on and are disconnected from a Bluetooth® device for more than 3 minutes they will power off.

Charging

1. Replace the earbuds in the case.
2. Connect the USB-C charging cable to the charging port on the back of the charge case.
3. Plug the cable into a standard USB 5V/1A or higher power output.
4. When the charge case is charging, the display shows the current charge, blinking. The display will show 100 and stop blinking when the case is fully charged.

6 7

5. If you want to charge the earbuds from the charge case internal battery, simply replace them in the case. They will begin charging from the built-in case battery. Earbuds will glow solid red to indicate charging. The lights will shut off after they are fully charged. When fully charged, promptly unplug the charge case from the power source.

Troubleshooting

Earbuds do not sync with each other:

1.Place the earbuds in the case, then take out the earbuds, ensuring both earbuds are turned on.

2.On each earbud, press and hold the control surface for 5 seconds. The earbud will turn off after the LED flashes red 3 times.

3.Replace the earbuds in the charging case.

4.Repeat the Getting Started process.

Earbuds do not pair to device:

1.Turn the Earbuds OFF by pressing the control surface on each earbud until the LED blinks red, and then turns off.

2.Replace the earbuds in the case. Turn you device's Bluetooth® OFF and than back ON. Then repeat the pairing process.

pages 7 & 8

Warnings

- Do not use this unit for anything other than its intended use.
- Do not puncture, throw, drop, bend, or modify this product.
- Do not throw this product into fire or water.
- Do not short-circuit the battery with any metal or metallic objects.
- Do not expose this product to corrosive liquids such as salt water.
- Do not operate the unit if it has been wet or moist to prevent against electric shock and/or injury to yourself and damage to the unit.
- Do not allow children to play with this product as it is not a toy, and may present a choking hazard.
- Avoid leaving your device in direct sunlight, such as on the dashboard, console, or seat of a vehicle.
- Do not leave your device, or use your device, in any area where the temperature is likely to drop below 32°F, or may exceed 140°F, such as inside a closed vehicle on a hot day.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Protect your hearing by always listening at a safe level. Prolonged use at elevated volumes may affect your hearing capacity and could result in hearing loss.
- Use the earbuds with this charging case only.
- To avoid damage to the charging case, please only use a USB 5V/1A or higher charger.
- In order to ensure the battery life, charge normally at least once a month.
- Keep this product away from high frequency transmitter equipment, this will affect the local signal reception, resulting in sound breakup and distortion or disconnection.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

* RF warning for Portable device:
This device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

8 9

USB Cable rating input/output 5V 1A 5W Max

⚠ **CAUTION: FOR YOUR SAFETY.** The charging cable included with this item is intended for use with this product only

12 MONTH WARRANTY
Please visit our website Bytechintl.com/warranty

Bluetooth® is a registered trademark of Bluetooth SIG, Inc.

Google, and the Google Assistant are registered trademarks of Google LLC registered in the U.S and other countries.
Siri® is a registered trademark of Apple Inc. registered in the U.S and other countries.

Bytech has no affiliation to Apple Inc., Google LLC or Bluetooth SIG, Inc.

*All Trademarks and copyrights are th property of the respective companies.
*Photos are for illustration purposes only.

BYTECH
Contact Info:
2585 West 13th Street.
Brooklyn, NY 11223
BYTECH intl.com

©2026 BYTECH NY INC.

MADE IN CHINA