BC

VIVITAR®

STEREO PAIRING

PLAY SEPARATELY OR TOGETHER

TWO-IN-ONE

TRUE WIRELESS BLUETOOTH® SPEAKER

User's Manual: SPK-2N1-FD

Important Safety Precautions

When using the Vivitar Two-In-One True Wireless Bluetooth® Speaker, basic safety precautions should always be followed, including:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR SPEAKER.
2. Do not allow children to play with your speaker without adult supervision. Keep out of reach from infants,
3. Do not use your speaker near water. Do not submerge your speaker.
4. Do not place the speaker on any wet surfaces.
5. Do not expose your speaker to excessive heat, flames, or fire.
6. Do not expose your speaker to temperatures above 104°F/ 40°C. Keep out of direct sunlight.
7. Always press all buttons or switches carefully. Do not manhandle your speaker.
8. Do not use in extremely dry environments as this can lead to static discharge during usage.
9. Do not attempt to repair this product yourself. Contact a qualified service center if your speaker is in need of service.
10. Do not drop, puncture, crush, or expose your speaker to excessive physical trauma.
11. Your speaker is not intended for commercial use.
12. Do not place near objects that generate a strong magnetic field.
13. Use a soft cloth to clean your speaker. Never use any harsh chemicals or detergents. Make sure your speaker is dry before charging.
14. Please recycle or dispose of your speaker properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your speaker for further information.

CAUTION

BATTERY WARNING:

-The device is equipped with an integrated lithium battery. The battery cannot be replaced. Do not attempt to remove the battery from the device.

-Do not dispose of in fire or expose to excessive heat.
-Do not crush, puncture, incinerate, or short circuit external contacts.
-Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacturer for further information.

Introduction

Thank you for purchasing the Two-In-One True Wireless Bluetooth® Speaker, item SPK-2N1-FD. You can use your speaker with most smartphones and Bluetooth devices to stream music wirelessly and enjoy hands-free calling. Separate your speakers to create a surround sound atmosphere. In order to get the best results, please read this manual first before using your speaker.

Package Contents

- Vivitar Two-In-One True Wireless Bluetooth® Speaker
- Detachable Carrying Sleeve
- USB Charging Cable
- User's Manual with Warranty Information

Specifications

Bluetooth Version: 5V
Bluetooth Range: Up to 33 feet. (10 meters)
Power Supply: DC 5V
Battery Type: Lithium Ion Battery
Charging Time: Approximately 4-5 Hours
Play Time: Approximately 8-10 Hours

*Applicable at 50% of maximum volume. Results will be lower when volume is higher.

A Quick Look


Power Button
Increase Volume/ Next Selection
Decrease Volume/ Previous Selection
Battery Light Indicator
Micro USB Port

Charging The Speaker



1. The USB charging cable has a Micro USB plug and a standard USB plug.



2. Insert the USB charging cable's Micro USB plug into the Micro USB port on your speaker.



3. Insert the USB charging cable's standard USB plug into the USB port of a computer or suitable USB charging adapter.



4. The Battery Indicator Light turns red while the speaker is charging. The light will turn off when charging is complete.

NOTES:

-- Charging can take approximately 5 hours to complete when the battery is fully drained.

-- Remove the charging cable once charging is complete.

-- Overcharging could reduce the life of the battery.

-- A charged battery will lose its capacity if it is not used on a regular basis.

Important: To avoid a complete discharge of the battery, charge your speaker at least once every six months.

Bluetooth Pairing



1. Press and hold the Power Button for 1-2 seconds to power the speaker ON.



2. The Battery Indicator Light will turn blue flashing rapidly to indicate the speaker is in pairing mode.



3. Go to the Bluetooth settings menu on your phone. Make sure that Bluetooth is turned on. Connect to the device listed as “TWS Speaker”.



4. The Battery Indicator Light will turn solid blue to indicate your speaker and phone are paired.

Pairing The Speakers



1. Press and hold the power button for 1-2 seconds on each speaker to power them ON.



2. Press the Decrease Volume/ Previous Selection button on one of your speakers. This will activate pairing mode.



3. The speakers will beep indicating they have successfully paired together.



4. Go to the Bluetooth settings menu on your phone. Make sure that Bluetooth is turned on. Connect to the device listed as “TWS Speaker”.

Using The Speakers



1. Press and hold the Power Button for 1-2 seconds to power your speaker ON/ OFF.



2. Press the Power Button to play and pause music.



3. Press the “+” to go to the next selection. Press and hold the button to increase volume.

Press the “-” to go to the previous selection. Press and hold the button to decrease volume.

FCC Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference. and (2) this device must accept any interference received. including Interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions. may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment end receiver.
-- Connect the equipment Into an outlet on a circuit different from that to which the receiver Is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

Vivitar One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty
Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:

Call 1-800-592-9541 or visit our website at www.vivitar.com.

To receive warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaired.

Vivitar One Year Warranty (continued)

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, OR SAKAR INT. BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

VIVITAR®

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Sakar International is under license. Other trademarks and trade names are those of their respective owners.”