Instruction Manual

# SOUND HUB

## Portable Wireless Speaker + Charge Station

atomi™

atomi™

**For questions or concerns, email us at info@atominy.com.**
**Manufactured and marketed by Atomi, Inc.**
**10 West 33rd St. Suite 520, New York, NY 10001.**
**Atomi™ is a trademark of Atomi, Inc.**
**Designed by Atomi in New York. Made in China.**

iPad, iPhone, iPad are trademarks of Apple Inc., registered in the U.S. and other countries. Android and Android Market are trademarks of Google Inc.

The Bluetooth® product name and logos are registered trademarks owned by Bluetooth SIG, and any use of such branding is has been fully licensed.

Proposition 65 warning: This product may contain chemicals known to the state of California to cause cancer and/or birth defects or other reproductive harm.

**Thank you for purchasing the Atomi Sound Hub.**

This speaker provides high-quality wireless sound for your smartphone, tablet or other Bluetooth® audio device.

It can also charge up to 4 USB devices simultaneously and 2 more devices with its secure grounded outlets.

This instruction sheet explains the basic functioning and care of the Sound Hub. Please read this carefully and keep it for future reference.

Caution:

This device complies with Part 15 of the FCC rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or change to this equipment. Such modifications or change could void the user's authority to operate the equipment. This radio transmitter (identify the device by certification number or model number if Category II) has been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.
To maintain compliance with FCC's RF exposure guidelines, this equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

Bluetooth™

This product is compatible with any Bluetooth wireless technology enabled device which supports any of the A2DP, AVRCP, Hands-Free or Headset Profiles.

RoHS 2002/95/EC

Complies with the European regulations for certain hazardous substances.

1 YEAR WARRANTY

One-year limited warranty from date of purchase against defects in materials and workmanship.

C ETL LISTED US
Intertek
5001673

## USING YOUR SOUND HUB

**1. POWER ON/OFF**
To turn your Sound Hub on, press and hold down the power button. You'll hear a brief musical melody, followed by the device's voice. (It will say, "Bluetooth is on.")

**TO POWER OFF:** Press and hold down the power button. You will again hear a quick melody, along with the phrase, "Sound Hub signing off."

**2. BLUETOOTH®**
Any Bluetooth® device can be paired with the Atomi Sound Hub.

**A.** Turn on your Bluetooth® device and activate it by turning on the Bluetooth® mode. You can find the Bluetooth® menu in the Options or Settings menus on your device.

**B.** Power on the Sound Hub. Once the unit is on, it will enter an auto-pairing mode and attempt to pair with a nearby Bluetooth® device.

**C.** Once turned on, the Atomi Sound Hub should appear on your device's Bluetooth® list. If a message such as "Not Paired" or "Not Connected" appears, select "Sound Hub" to connect.

**D.** Once pairing is successful, the blue LED light will illuminate on the Sound Hub. You will now hear the device say, "OK! Let's play your music."

You may now play music on the Sound Hub through your device. The next time the Sound Hub is powered on, it will automatically link with the last paired Bluetooth® device. To pair with a new device, follow steps A-D above. NOTE: A Bluetooth® device must be within 10M (33 ft.) of the Sound Hub to be paired with it.

**3. VOLUME**
To adjust the volume of the Sound Hub, use the volume controls directly from your Bluetooth® device. Or use the volume up and volume down (+ -) buttons directly on the unit itself. NOTE: when the speaker has reached its highest possible volume, you will hear a beep when pressing the "+" volume button.

**4. USB PORTS**
The Atomi Sound Hub features 2 2.1-amp ports for charging tablets and 2 1-amp ports for charging smartphones. To charge your device, attach your smartphone or tablet to the Atomi Sound Hub via a USB cable (not included).

**5. GROUNDED OUTLETS**
The Atomi Sound Hub also features 2 grounded outlets for powering laptops, printers, or other appliances. Plug the cord into one of the secure, grounded outlets for power.

**6. CHARGING AND BATTERY**
The Atomi Sound Hub arrives pre-charged and ready-to-use. When the speaker requires charging, the Play button will turn red. The Play button turns blue when the speaker is fully charged.

To recharge the speaker, simply connect the Hub to a power source and place the speaker in the Hub. Battery life is approximately 4 hours at moderate listening levels.

**TECHNICAL SPECIFICATIONS:**

| | |
|---|---|
| Weight: | 632g (including cable) |
| Battery Life: | Up to 4 hours |
| Bluetooth® Range: | Up to 10M |
| Driver: | 2.1 EDR |

**SAFETY INFORMATION**

**1.** Read these instructions carefully for best use.
**2.** DO NOT expose the Sound Hub to rain or moisture.
DO NOT use the Sound Hub near water.
**3.** DO NOT use the Sound Hub near open flames, such as candles, heat sources such as radiators and stoves, or any other heat-producing appliance.
**4.** Only clean the Sound Hub with a dry cloth.
**5.** Only use attachments/accessories as specified by the manufacturer.
**6.** If the Sound Hub is to go unused for an extended period of time (1 month or longer), fully charge the unit before storing and detach any cables or accessories.
**7.** Always make sure you can easily access the device's main power button.

**CAUTION**

To reduce the risk of electric shock, use indoors only. Do not plug into another relocatable power source. Use only in a dry location.

LISTEN.
CHARGE.
GO.