C81说明书：58x85MM 105G铜版纸单色折页印刷

Metallic Housing Wireless Car FM TRANSMITTER with PD24W & QC3.0

USER GUIDE



Model No . C81

Introduction

This device, Lets you stream music and calls directly from your Wireless device to your car FM stereo system. The built-in Wireless V5.1 provides you with an amazing hands free function, it also features dual USB Charging ports (Q.C 3.0 & PD24W) which will greatly save your mobile charging time.

Packing contents:

- Wireless device
- User Guide

Specifications:

- Wireless version: 5.1
- Wireless Protocol: AVRCP,HFP,A2DP
- LED display dimensions: 20*8mm
- FM frequency: 87.5-108.0MHZ
- Frequency stability: ±10ppm
- Product Input: 12-24V
- Charger output: PD24W +QC3.0 (total 42W)
- Wireless Distance: about 8 m
- Product Weight: 45.8g
- Product Dimensions: L36*W36*H 83mm
- Material: Aluminum Ring & ABS Shell

Features:

1.Wireless transmit phone call from mobile phone to car FM Stereo system via Wireless.
2.Switch to Hands-free mode automatically from music playing status when receiving call.
3. Bass boost for enhanced audio performance
4. Big metal rotatory knob for convenient operations
5. Detect and display the voltage of Car Battery when power on
6. Full 206 channels optional from 87.5-108MHz
7. Input: DC12-24V,Output: QC3.0 + PD 24W for Fast Charging
8. Siri & Google Voice Assistant activation
9. Delightful circle light
10. Up-to-date Wireless 5.1

Compatibility:
This device can be paired as a hands free kit with any compatible Wireless enabled devices.
Precautions:
Please read all safety instruction and warnings carefully before using this product. Improper use of this product may result in damage. To ensure it works well, please never use this in the following conditions :
1.Moist or underwater conditions.
2.Conditions near heater or high-temperature service.
3.Conditions with direct and strong sunshine,
4.Conditions with apt falling
5.Never dismantle the product without due permission, otherwise it may nullify the warranty clause.

Appearance:Please read the User Manual carefully before using. Hope this device make your driving more interesting and safer.

Appearance:



Tips:
1.Press and hold the 'CH' button for 2 seconds to turn off FM/display/Wireless function on the product, only keep charging. Press and hold the 'CH' button for 2 seconds again to turn on.
2.While Wireless music is playing, double press the phone button then turn the knob clockwise or anticlockwise to skip to the next song or go back to the previous song.

Get Started

Installing the Product:

- Plug the auxiliary power plug into an auxiliary power outlet.
- The LED display shows the voltage of the battery of the car first for seconds and then shows "bt" to indicate Wireless pairing mode is successful.

Wireless Pairing

Pair with Wireless:

- When LED display shows "bt"and the device will enter into Wireless pairing mode.
- Enable Wireless on the device you want to pair.
- Search and select "C81" from the list, then connect.
- If asked enter the pairing code '0000' or '1234'.

FM Tuning

Connect to FM Radio

- Tune your car radio to an unused FM frequency.
- Press 'CH' button to enter frequency tuning mode.
- Tune the rotatory knob on this device to match the same frequency.

Music & Call

Playing and Controlling the Music

- Play music directly from the mobile device that is connected to the product via Wireless.
- Press the Phone button to play or pause music.
- While Wireless music is playing, double press the phone button then turn the knob clockwise or anticlockwise to skip to the next song or go back to the previous song.

- Tune the rotatory knob clockwise or anticlockwise to increase or decrease volume.
- Press the "b" button enter BASS Booster mode, press again to return.

Tip: If you receive a call while playing music, the product automatically switches to the phone call.

Making Phone Calls

- Please press to answer the incoming call. Press and hold to reject the call.
- Please press to hang off a call.
- During a call, press and hold to switch a private conversation.
- When making a call, you can only dial the phone number by your mobile phone, but once the call connected, you can use the hands-free function to enjoy it.

Activating Voice Assistant

- When in Wireless mode Press and hold the phone button to activate voice assistant on your mobile phone (Siri or Google Assistant ect...)

Charging & Power

Charging Mobile Devices

- When charging, connect your USB device with a USB cable (not included) to one of the two USB charging ports (USB & PD)
- Voltage outputs: PD 24W & QC3.0 18W

Switch Off / On

- Press and hold the 'CH' button for 2 seconds to turn off FM/display/Wireless function on the product, only keep charging.
- Press and hold the 'CH' button for 2 seconds again to turn on.

END

Federal Communications Commission (FCC) Statement. This device complies with part 15 of the FCC Rules. Operation is subject to the following twoconditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received,

including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide Reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one ormore of the following measures:

•Reorient or relocate the receiving antenna.

•Increase the separation between the equipment and receiver.

•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

•Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by **SAGE HUMAN ELECTRONICS INTERNATIONAL CO., LTD.** may void the FCC authorization to operate this device.Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF exposure statement:

The transmitter must not be colocated or operated in conjunction with any other antenna or transmitter. This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a Minimum distance of 5mm between the radiator and any part of your body.