正面

BLUETOOTH V5.3
头戴式主动智能降噪耳机

功能按键说明



iOS

全新智能头戴式系列

兼容iOS系统Android智能手机平板等蓝牙功能的电子产品

轻松配对

① 将耳机从包装盒里拿出来佩戴好

② 长按电源键 "●" 2秒，听到出厂中文提示音，耳机成功

③ 打开手机蓝牙功能，在配对页面上，搜索设备，KF-King Pro，点击并完成配对

④ 再次配对连接成功后，耳机每次开机会自动连接上一部有连接记录的手机，无需重复配对

注：如有必要，请关闭耳机后重复上述步骤重新连接

耳机开&关

开机：【长按】电源键 "●" 2秒，出现中文提示音
关机：【长按】电源键 "●" 3秒，出现中文提示音

降噪模式

【长按】："ANC"键切换
循环切换："透明模式"降噪模式"环境音模式"

接听&操作

增加音量：【短按】"+"键，音量调整一个音阶，最大音量时"滴"
降低音量：【短按】"-"键，音量调整一个音阶，最小音量时"滴"
上一曲：【长按2秒】"+"键
下一曲：【长按2秒】"-"键
接 听：【单击】电源键 "●"
挂 断：【单击】电源键 "●"
拒绝来电铃声：【三击】电源键 "●"

回切模式

开启音响模式：【三击】"ANC"键，听到提示音回切动态入耳检测式
关闭音响模式：【三击】"ANC"键，听到提示音回切动态出耳检测式

语言切换

操作单电：【双击】电源键 "●"
控制电话：【长按】2秒电源键 "●"
接听电话：【双击】电源键 "●"

重置方式

关机状态下长按电源键 "●" 5秒，强行进入配对状态，出现语音提示到出现配对状态，指示灯闪烁蓝色两次

切换中英文语音提示

开启英文模式：【四击】"ANC"键，听到三下提示音则进入英文模式
关闭英文模式：【四击】"ANC"键，听到一下提示音则退出英文模式
•出厂默认中文，请完成已在开机后重复本流程切换不限有效

LED指示灯状态

开机状态：指示灯闪烁交替LED5-LED6
关机状态：指示灯灭
连接正常：灯常亮LED
充电状态：电源指示灯红灯常亮
满电状态：电源指示灯红灯常亮
低电状态：低电时语音提示一次
未电状态：未电时，语音提示关机关机，如果关机不发扬语音提示，提示语"请离开，请离开，LED指示灯闪烁10秒第一次。

查看剩余电量

开机后：【单击】"ANC"键，听到提示音报动态进入语音模式
100%-75%：语打报"满"
74%-50%：语打报"良好"
49%-25%：语打报"正常"
<24%：语打报"低"
注：出现红灯时表示处于充电状态

外置麦克风接口

插入时，自动切换外置麦克风，通话声音更大更清晰。
•若无风线时只有蓝牙模式下支持

音频线接口

3.5mm音频线，插入Aux-in线（音频线），蓝牙功能自动关闭，切换到Aux-in模式。

使用ANC主动降噪功能小提示

耳机ANC主动降噪开启后主要消除掉低的频率，对于高频率的环境噪音（如车行驶的声音，机器运转的声音，风声等等），对于人声（高频区间）方面的噪音不明显。

产品充电注意事项

1. 请在使用type-C充电线连接**type-C**接口充电或进行产品进行充电
2. 请没有对应充电器或的手机充电器，四可使用耳机自带充电，5V= 2A或 5V= 4.5A 等常规手机充电头产品进行充电。
3. 请在第三方手机充电头出现 **≥24W(5V5A=2A 三倍 10W)**，超过此功率容易烧耳机。
4. 不要使用有水、油类、USB接线、USB充电宝、快充充电宝对产品进行有线充电，因输出功率和高压不稳定，很容易出现产品无法充电，且产品有起烧安全（低能量除外）。就是说有不稳定增强元。



为什么耳机不能开机或要关机？

1. 请保耳机有电的情况下，长按电源键开机。
2. 请检查耳机是否有机械损坏情况，进水，跌落等。若无以上打为，可联系客服帮助您进行售后流程并处理。

为什么按键功能不灵敏？

1. 产品上有电镀键，无线键，音量键，灯为物理按键，常工确按下并回弹时，产生产生响应，若您功能不灵敏，请以重新进一遍操作即可。
2. 回弹到机盖没有机械回弹时，进水，跌落等，若无以上打为，可联系客服帮助您进行售后流程并处理。

如何使用连接PC或其他带有蓝牙连接设备？

1. 在耳机充满了一次3.5mm的AUX音频线，跌落等，无法，并且使用AUX音频线插入连接耳机与PC电脑，笔记本，或者其他设备，可将耳机作为有线耳机使用。
2. PC电脑或者笔记本等设备有蓝牙功能情况下，也可以使用蓝牙方式连接耳机。

产品规格

产品名称：头戴式主动智能降噪耳机

蓝牙连接距：
输 入 电 压：DC 5V
充 电 接 口：Type-C
充 电 时 间：约2小时
蓝 牙 版 本：5.3
输 入 电 流：500mA
电 池 容 量：1000mAh
支 持 协 议：HSP/HFP/A2DP/AVRCP

包装明细：头戴式蓝牙耳机主体、Aux-in音频线、Type-C充电线、指导说明书、精美包装盒

【特心解放时尚产品，深度用户口碑推荐，KF-King Pro 也不想被大家所埋没】

使用头戴耳机时请留意以下信号等注意事项：

① 日常耳机与手机之间，蓝牙两者距离不要超过10-20米，以及其中间不要有太多干扰物品阻碍物（比如四周，墙壁等间距不要太密集，会影响蓝牙信号）

② 日常使用过程中，若有偶尔断连问题属于正常现象，毕竟蓝牙属于非线缆传输，会受**Wifi**信号一样，偶尔的不稳定属于正常现象，可能此时信号传输受到了部分干扰，请稍等片刻或者换一个位置即可解决。

③ 关于头戴耳机的佩戴，是否佩戴合适也间接配方法有很大的关系，请先将耳机按照使用说明说明以佩戴正确的方式，否则会为您带来产品不合适，耳机容易耳机的佩戴角度和松耳朵现象。

④ 头戴耳机质量保证期是一年，出现任何质量问题请与正规卖家，若您想要更换或维修耳机请，请记得查看保修卡上所填写以及佩戴角度调整是否正确。

⑤ 请不要将**Type-C**接口插入**Type-C**以外的设备。

⑥ 请勿在潮湿，高温，易腐蚀物的环境使用设备，否则可能会导致产品起火，电子元件受损等情况出现本产品，而进行为损坏产品售后无效。

⑦ 请勿将设备置于儿童可及的地方。

⑧ 请勿将设备置于温度超过40℃以下的环境下以上的环境中。

⑨ 请勿在雷雨，大雾或动物的睡眠等情况设备运行。

⑩ 请勿在雷雨天气下使用设备，雷雨时请将耳机设备工作不正常，并增加输电的风险。

⑪ 请勿用油及其他挥发性化学溶液擦拭本产品表面，否则可将酒精日常清洁保养产品。

⑫ 请勿将设备随意拆卸本产品。

3. 若产品高起过1个月不用，请打开充满电后，再妥善放置存放，即间建议每一个月都打开充满电，可延大有效延长产品的使用寿命。
若由产品无的电池自动自然的导致性的导致的自然，过度放电导致生产品的损坏，无法修理使用，非不属于质保范围。

4. 请勿将设备置于儿童可及的地方，请勿将设备置于儿童可及的地方。
5. 若非长期使用请关闭耳机，接触心脏等耳机或其他对手机等对电子设备的干扰，若长时间未或或不使用请取出，若非耳机或对功能有关对应的产品，若未长期未出现，请重新开机手机，若证开耳机再充电，请重开机至开机。

警告

1. 请以任何理由拆除或修改或替换耳机，否则可能会导致产品起火，电子元件受损等情况出现本产品，而进行为损坏产品售后无效。
2. 如果有出现紧急行使后，
3. 请勿将设备置于温度超过40℃以下的环境下以上的环境中。
4. 请设在雷雨天气下使用设备，雷雨时请将耳机设备工作不正常，并增加输电的风险。
5. 请勿用油及其他挥发性化学溶液擦拭本产品表面，否则可将酒精日常清洁保养产品。
6. 请勿将设备随意拆卸本产品。

背面

BLUETOOTH HEADPHONE

Please read this manual carefully before you operating
You set and retain it for future reference

Welcome

Official package including
Headphone*1
Charging cable*1
AUX audio cable*1
External microphone*1
User manual*1

iOS

Before use

Important Safety Instructions

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Only use attachments/accessories specified by the manufacturer.
8. Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in anyway, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

WARNINGS/CAUTIONS

- Do NOT use the headphones at a high volume for any extended period.
- To avoid hearing damage, use your headphones at a comfortable, moderate volume level.
- Turn the volume down on your device before placing the headphones on your ears, then turn the volume up gradually until you reach a comfortable listening level.
- Do NOT use your headphones while driving for phone calls or any other purpose.
- Do NOT use the headphones with noise canceling on at any time the inability to hear surrounding sounds may present a danger to yourself or others, e.g., while riding a bicycle or walking in or near traffic, a construction site or railroad, etc., and follow applicable laws regarding headphone use.
- Remove the headphones, or use the headphones with noise canceling off and adjust your volume, to ensure you can hear surrounding sounds, including alarms and warning signals.
- Be aware of how sounds that you rely on as reminders or warnings may vary in character when using the headphones.
- Do NOT use the headphones if they emit any loud unusual noise, if this happens, turn the headphones off and contact KF customer service.
- Remove headphones immediately if you experience a warning sensation or loss of audio.
- Do NOT use mobile phone adapters to connect headphones to airplane seat jacks, as this could result in injury or property damage due to overheating.
- Do NOT use the headphones as aviation communication headsets.

Contains small parts which may be a choking hazard, Not suitable for children under age 3.
This product contains magnetic material, Consult your physician on whether this might affect your implantable medical device.
- To reduce the risk of fire or electrical shock, do NOT expose this product to rain, liquids or moisture.
- Do NOT expose this product to dripping or splashing, and do not place objects filled with liquids, such as vases, on or near the product.
- Do NOT make unauthorized alterations to this product.
- Use this product only with an agency/approved power supply that meets local regulatory requirements (e.g., UL, CSA, VDE, CCC).
- If the battery leaks, do not allow the liquid to come in contact with the skin or eyes, if contact is made, seek medical advice.
- Do not expose products containing batteries to excessive heat (e.g. from storage in direct sunlight, fire or the like).
- Do NOT wear the headphones while charging.
- The headphones do not play audio while charging

Getting experience
For maximum ease with this product, please contact our customer service at the website where you purchased the product, leave a message or email us, we will answer as soon as possible.

Company: Shenzhen Oumu Technology Co., Ltd.
Address: Room 315~318, Building D, Nanxi Industry International, Nancheng District, Dongguan City, Guangdong Province, China
Website: http://kf-wuyin
Email：support@163.com

Overview

Specifications

Model: Bluetooth version: V5.3
Power input: DC 5V Input parameters: 500mA
Noise reduction depth: ≥ 38dB
Charging interface: TYPE-C CJ188
Battery capacity: 1000mAh
Charging time: about 2 hours
Supporting agreement: HSP/HFP/A2DP/AVRCP

How to charge

For the first time use, please fully charge the product.
Charging: The power indicator light is solid red
Full power: The red light of the power indicator is off
Charging time: 2 hours
Low battery alarm: Voice prompt once when the battery is low.



Warnings

When charging the headset,to avoid damage to the battery, it is recommended to use a 5V/2A charging head to charge. The power of the charging head should not exceed 24W. Avoid using car chargerfast charging power bank or charging head with unknown power for charging, there may be situations where charging cannot be performed or the power consumption is too fast and the signal is poor.

Instruction



Headphone Status

LED indicator

Turn on: Signal light flashing white and green
Turn off: The signal light is white for 3 seconds
Connection succeeded:light is not on
Incoming call status: Green light is on every 10 seconds
(When a call comes in, it will prompt the ringtone of the mobile phone synchronously, if the mobile phone does not support synchronization ringtone, prompt tone "Didididid")

How to Check the Battery Status of Headphones

After power on, click the ANC button, the power indicator will light up for 2 seconds:
Green and red flashes 4 times slowly: 75%~ 100%
Green light flashes 3 times slowly：50%~ 74%
Green light flashes 2 times slowly：25%~ 49%
Green light flashes 1 times slowly：<24%
Please charge the headset in time when the red light appears

Turn on and Turn off

Turn on: Long press the power button 2 seconds and hear the prompt "ka2" that it is turned on;
Turn off: Long press the power button 3 seconds and hear the prompt "guang" that it is turned off;

How to connect

1、Long press the power button 2S and hear the English prompt "Power on" that it is turned on;

2、Open the Bluetooth interface of the mobile phone, search for "KF-King Pro", click to connect;

3、After the first pairing and connection is successful, the headset will automatically connect to the last mobile phone with a connection record every time it is turned on, and there is no need to repeat pairing.

Call with headset

Double-click the power button	Answer
4 Press the power button	Hand up
Long press the power button 2S	Incoming telegram: Reject

Listen to music with headset

Click the power button	Play/Pause
Click the + button	Volume up
Click the - button	Volume down
Long press the + button 2S	Next song
Long press the - button 2S	Previous song
Triple tap the power button	Wake up voice assistant

Three modes switch

(Long press) "ANC" button for 2 seconds
Cycle through "Music Mode/ANC Mode/Ambient Sound Mode"
Note: After plugging in an external microphone, ANC mode cannot be turned on

Turn on /Turn off game mode

3.click the "ANC" button, and you will successfully enter the game mode when you hear the prompt sound ;
3.click the "ANC" button, and you will successfully exit the game mode when you hear the prompt sound;

Wired connection

Use the audio cable to connect a non-wireless device or if the headphone battery is depleted,
1, Insert the cable into the 3.5 mm jack on the right earcup.
2, Insert the other end of the cable into the 3.5 mm jack on your device.
*Bluetooth cannot be turned on under wired connection

External microphone

Insert the configured microphone into the microphone jack.Calls/voices are clearer.
There may be third- party software incompatibility problems during the use of the external Microphone, resulting in the inability to receive audio, and the actual experience may be slightly different.

TIPS

1. Make sure the headset and the connected device are within a valid connection range and there are not too many obstacles that interfere with the signal;
2. It is normal for the headset to be disconnected occasionally.Just like WiFi, occasionally the connection is unstable,It may be due to interference in signal transmission.,Please wait a moment or change the location to resolve;
3. When the headset cannot be connected to the device, please check whether the headset has power or is connected to other devices;
4. Please fully charge the Headphone once a month.If the Headphone isnot used for a long time, the battery of the Headphones may be damaged;
5. The sound insulation and sound leakage of headphones are related to the way of wearing the headphones and the volume of the headphones.
You can adjust the wearing angle and degree of ear wrapping of the headphones in time according to the actual comfort of use, Please close the earhead foam part of the headphone as much as possible.
6. Please use a standard- compliant charging head to charge the headset.
7. Do not wear the product for bathing, or use it in the rain, and do not soak the product in water, After each normal use, it is recommended to dry the sweat or stains on the headphone with a dry cloth, paper towel, etc., and then store it.

Limited warranty

Warranty period: 1 year from the date of product receipt

During the warranty period of the product, due to the quality of the product itself, please contact us with the warranty card and shopping records to receive a return authorization / free maintenance and shipping instructions.

Fault Table

1.	Bluetooth headset cannot hear sound.
2.	The other side cannot hear the voice during the call.
3.	Unable to charge Bluetooth headset

The following conditions will not provide free repair

1,Unauthorized maintenance, misuse, collision, neglect, abuse, accident, alteration, or damage or alteration of the appearance of the product,
2,The product exceeds the warranty period specified by the company;
3,Damage caused by self- disassembly;
4,Failures caused by accidents such as water ingress or falling, squeezing, etc;
5,Normal wear and dirt caused by use, such as scratches, damage caused by contact with chemical reagents, contact with sharp objects, etc;
6,Outer packaging and accessories, gifts, services other than the products promised by the sales staff, and additional configurations and gifts;
7, Improper storage: If the product is exposed to abnormal humidity and temperature for a long time, the performance is damaged;
8,Failure or damage caused by force majeure;

This device complies with part 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including (2) interference that may cause undesired operation.
NOTE: The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.