70mm

100mm

USER MANUAL

HB206-2

Thank you for choosing our Membrane keyboard. Please read the user manual carefully before using this product.

Package contents:

Membrane Keyboard ------------------------------------x1
User manual ---x1
USB-C Cable ---x1

System requirement:

Compatible with Windows7,Windows8,Windows10,Mac,Android,IOS

Product parameter

Connection:Wireless	Operating Distance:8m
Keystroke Life:3 million strokes	Operating Temperature:-10℃ - +55℃
The Number of Keys:100 keys	Working Voltage:3.0-4.2V
Lithium Battery:280mAh	Working Current:≤4mA
BT Version: BT 5.1	Sleep Current:<50uA

The Keyboard Function



1.

Icon	IOS Function	Windows Function	Icon	IOS Function	Windows Function
Fn+ ESC	FN switch	FN switch	F1	Mute	Mute
F2	Volume-	Volume-	F3	Volume+	Volume+
F4	Previous Track	Previous Track	F5	Play/Pause	Play/Pause
F6	Next Track	Next Track	F7	Lightness-	Lightness-
F8	Lightness+	Lightness+	F9	Select all	Select all
F10	Copy	Copy	F11	Paste	Paste
F12	Cut	Cut			

Instruction

1.Code Matching Mode:

- Turn on the power switch on the keyboard.
- Press a BT key for 3 seconds. The BT indicator will flash in white light.
- Turn on the BT of your device and search.(BT name:Bluetooth 5.1 KB2) , click the BT name, and then your device will connect to the Keyboard.
- When the connection is done, the indicator light keep on.

2.Device Switch:
After the keyboard is connected with your device, you can simply click the relevant BT icon key to select the connected device, and the relevant indicator light will stay on. If you don't need to connect the keyboard with three devices, you can also connect the keyboard with one or two devices.

3.The keyboard will go in to sleep mode without any action in a period of time. But it can be woken up by pressing any key.

2.

4.Troubleshooting

- Make sure the keyboard is on (slide switch in "ON" position).
- Make sure the keyboard is in operating distance (within 10 meters).
- Ensure the battery storage has power.
- Make sure the BT in tablet I PC / smartphone is on.
- Ensure wireless keyboard have already matched with BT.
  If you cannot find "Bluetooth 5.1 KB2" in the"add new devices", it might be because the "Bluetooth 5.1 KB2" is in the "BT interface and other devices" list, you can delete it and add it again.

保 修 服 务 卡

感谢您对多彩产品的信任与支持，我们将竭诚为您提供满意的服务，请准确清晰的填写相关条目，以确保您的合法权益。

多 彩 产 品 保 修 卡	
产 品 型 号	维 修 记 录
制 造 编 号	
购 买 日 期	
用 户 电 话	
销售商电话	

备注：请清楚填写各条目，勿擅自涂改，并妥善保管好本保修服务卡，以维护您的合法权益。如果保修服务中有任何疑问，请咨询本地经销商或与我们联系，请拨打免费电话:4006990600

产品售后服务指南

购买多彩产品，在质保期内产品出现质量问题用户可以选择：
①前往多彩的服务中心进行维修。维修流程为：在我们工作人员的指导下填写用户信息注册单，等待我们的工程师为您检测及维修或更换产品。
②如果本地或者附近没有多彩的产品服务中心；您可以凭借购买记录，联系购买的渠道（平台）进行维修或者更换处理，相对应所产生的邮费，可与购买平台协商后再行承担。
③对于已经停产了在质保期内的产品，多彩将按照国家规定提供免费维修的服务保障。

保修期的确认

多彩保证您的多彩硬件产品自购买之日一年内不会出现材料和性能方面的缺陷。并提供为期一年(从购买之日起)的保修服务。保修期自最终用户购买之日起算起,以最终用户的购机发票(注明型号、主机序列号(S/N)，并由代理商盖章)或发票复印件及有效保修卡为凭证。若用户无法提供以上证明，则按照用户购买本公司产品的出厂日期计算保修日期，出厂日期根据主机序列号(S/N)判断。保修标签被人为破坏，本公司不给予免费保修，如需维修需收取相应的材料费用。

1、所有配件必须为本公司产品标准配件并在保修期内。
2、以下情况不予保修：
①人为地自行拆卸、修理、安装;
②使用非本公司部件;
③使用了未经公司认可的扩展部件或外围设备导致本公司标准部件损坏或产生故障;
④不慎使异物进入设备、运输、移动、碰撞等造成的布局损坏及故障;
⑤不可抗力:所有地震、火灾等自然灾害或意外事故(被盗.丢失)等不可抗力引起的设备不能正常工作。

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

感谢您选择我们的薄膜键盘，使用前请仔细阅读使用说明书。

包装清单

薄膜键盘 --- x1
用户手册 --- x1
USB-C 电缆 -- x1

系统兼容

Windows7/Windows8/Windows10/Mac/iOS/Android

性能参数

连接方式:无线蓝牙5.1	有效距离:8m
按键寿命:300万次	操作温度:-10℃-+55℃
按键数量:100	工作电压:3.0-4.2V
睡眠电流:<50uA	工作电流:≤4mA
锂电池容量:280mAh	

产品图示



3.

使用需知

1.连接方式

无线蓝牙连接，支持蓝牙5.1版本，拨动电源开关至ON位置，设备开机。

2.对码方式：

- 打开键盘的电源开关，指示灯常亮3秒后熄灭。
- 长按一个蓝牙配对键3秒，蓝牙指示灯将会呈白色闪烁。
- 打开平板电脑的蓝牙并搜索，平板电脑自行或手动搜索找到键盘名称（蓝牙名称：Bluetooth 5.1 KB2），点击蓝牙名称自动连接成功。
- 将会显示已成功连接，键盘蓝牙指示灯会常亮。

3.如何在第一、第二、第三设备之间进行切换：

键盘与设备配对完成后，可以简单地点击相关蓝牙图标键来选择相关连接的设备。如果你不需要将键盘与3个设备配对，你也可以将键盘与1或2个设备配对。

4.设备有效使用距离大于8M。

5.节能休眠模式

当键盘一段时间无任何指令时会自动进入休眠模式，需要使用时，只需要按任意键并等待≤4秒左右，键盘将会被唤醒，键盘可以进行正常工作。

6.注意：如果你的设备在"添加新设备"界面中找不到"Bluetooth 5.1 KB2"，可能是因为"Bluetooth 5.1 KB2"在"蓝牙和其他设备"列表中，你可以找到并删除它，然后重新添加一次。

4.

按键功能

按键	IOS 系统功能	Windows 系统功能	按键	IOS 系统功能	Windows 系统功能
Fn+ ESC	FN切换	FN切换	F1	静音	静音
F2	音量减小	音量减小	F3	音量增大	音量增大
F4	上一曲	上一曲	F5	播放/暂停	播放/暂停
F6	下一曲	下一曲	F7	亮度减小	亮度减小
F8	亮度增加	亮度增加	F9	全选	全选
F10	复制	复制	F11	粘贴	粘贴
F12	剪切	剪切			

合格证
深圳市多彩实业有限公司
质检员:
QC01 PASS

5.

产品中有害物质的名称和含量

根据中国《电子电气产品有害物质限制使用标识要求》

有害物质 Hazardous Substances

部件名称 Parts Name	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)	邻苯二甲酸二丁酯 (DBP)	邻苯二甲酸丁基苄酯 (BBP)	邻苯二甲酸二(2-乙基）己酯 (DEHP)	邻苯二甲酸二异丁酯 (DIBP)
电缆线/电源 Cable/Adaptor	X	O	O	O	O	O	O	O	O	O
电路板组件 PWAs	X	O	O	O	O	O	O	O	O	O
塑料/其他部件 Plastic/Others parts	O	O	O	O	O	O	O	O	O	O
玻璃部件 Glass parts	X	O	O	O	O	O	O	O	O	O
金属部件 Metal parts	X	O	O	O	O	O	O	O	O	O
电池 Battery	X	O	O	O	O	O	O	O	O	O

本表格依据SJ/T 11364的规定编制。
O=表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求下。
X=表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。
表中标有"X"的所有部件均符合欧盟RoHS Recast 法规 -2011/65/EU指令。

此表显示"多彩科技有限公司"的电子电气产品部件中何处存在这些有害物质。请注意，并非内装产品都包含上述所有部件。
注：环保使用期限的参考标准，取决于产品正常工作的温度和湿度等条件。

此为A级产品，在生活环境中，产品可能会造成无线电干扰。在这种情况下，可能需要用户对干扰采取切实可行的措施。

温馨提示

如果您收到的产品底部脚垫有轻微磨损，请不要担心，这是我们为了保证送到您手中的产品没有任何问题而进行测试所致，请您放心使用，再次感谢您的购买！

深圳市多彩实业有限公司
地 址:深圳市龙华区观乐路5号多彩科创园
服务热线:400 699 0600
www.deluxworld.com

说明书或驱动请登录以下网址：https://www.deluxworld.com/service.html 或扫描上方二维码登录官网进入-服务支持-下载专区进行下载

设计说明：
1、尺寸：70x135mm(公差+/-1mm)
2、材质：70g书写纸
3、颜色：单色印刷
4、装订方式：风琴折页

DELUX 多彩	深圳市多彩实业有限公司 SHENZHEN DELUX INDUSTRY CO., LTD.		
	名 称	K2212V标准双语说明书	
	料 号	R3.4.K221206001B	

分 发	☐研发部 ☑产品部 ☑资材部 ☑品保部 ☑生产部 ☑工程部 ☐海外营销部 ☑国内营销部 ☑文控中心	批 准		审 核		设 计	郑小纯/2022.05.18