AUSDOM®

User Manual

KAM200

Wireless Keyboard and Mouse Combo

Thank you for purchasing AUSDOM Wireless Keyboard and Mouse Combo

AUSDOM®
Enjoy Smart Life

For more information, please visit our official website
www.ausdom.com

Your valuable comments and suggestions on improving AUSDOM products are welcome!

support@ausdom.com sales@ausdom.com
www.ausdom.com

1. Product Overview



2. Packing list

1* Wireless Keyboard
1* Wireless Mouse
1* USB Receiver (Keyboard and mouse use the same USB Receiver)
1* USB to Type-C charging cable
1* User manual

3. Connections

Wireless Keyboard



Turn on the keyboard power switch

Plug the USB Receiver into your computer device to use

Wireless Mouse



Turn on the mouse power switch

Plug the USB Receiver into your computer device to use

4. Function key description

Key	System Function	Key	System Function
F1	Mute	F7	Decrease volume
F2	Increase volume	F8	Previous track
F3	Play /Pause	F9	Next track
F4	Decrease brightness	F10	Increase brightness
F5	Calculator	F11	Search
F6	Setting	F12	Turn on Dvoka
	Windows Switch		Open Browser
	Display Desktop		Lock Screen
Fn +	Fn lock,pages or close the F1-F12 the fn/Esc		

5. Indicator

	Indicator	Status	Meaning
Keyboard	Power indicator Charging Indicator	Red light goes off after being on for 3s	Powered on
		Red light flashes	Low battery ,please charge the battery as possible
		Red light is on always	In charging
		Green light is on always	Battery is fully charged
	CapsLock Indicator	White light is on always	CapsLock on
	NumLock Indicator	White light is on always	NumLock
Mouse	Power Indicator Charging Indicator	Red light goes off after being on for 3s	Powered on
		Red light flashes	Low battery ,please charge the battery as possible
		Red light is on always	In charging
		Green light is on always	Battery is fully charged
	DPI Indicator	Light off after red light flashes twice	Adjust DPI to our gear
		Light off after red light flashes twice	Adjust DPI to second gear
		Light off after red light flashes three times	Adjust DPI to third gear

6. Charging

When the power of the keyboard and mouse is too low, the power Indicator light will flash red. Please charge in time to ensure normal use.
Note: When the power level is low, the transmission of the keyboard and mouse will be delayed, stuck and unstable.

7. Specifications

Keyboard	Connections	2.4G wireless Technology(USB Receiver)
	Wireless Range	>8m
	Battery Capacity	380mAh
	Continuously working time	>180 hours
	Standby Time	>120 days
	Charging Time	>1.5 hours
	Keys Life	3 Million times
Mouse	Connections	2.4G wireless Technology(USB Receiver)
	Wireless Range	>8m
	Battery Capacity	300mAh
	Continuously working time	>30 hours
	Standby Time	1 year
	Charging Time	>1.5 hours
	DPI	800-1200-1600

Note: Features and technical specifications are subject to change without notice, we apologize for any inconvenience.

8. Warranty

The Wireless Keyboard and Mouse Combo is covered by a 1-year manufacturer warranty. For more information, visit **www. ausdom. com**

CAUTION
RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

RECYCLING
This product bears the selective sorting symbol for Waste electrical and electronic equipment.(WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.
User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.

⎓ DC voltage

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.-Consult the dealer or an experienced radio/TV technician for help.
This device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

1. 产品概述

2. 包装清单

1*无线键盘
1*无线鼠标
1*USB接收器（键盘和鼠标共用一个接收器）
1*USB-C充电线
1*用户说明书

3. 连接方式

无线键盘



打开键盘的电源开关

将USB接收器插入电脑设备即可使用

无线鼠标

打开鼠标的电源开关

将USB接收器插入电脑设备即可使用

4. 按键交互功能

按键图标	系统功能	按键图标	系统功能
F1	静音	F7	音量减
F2	音量加	F8	上一曲
F3	暂停/播放	F9	下一曲
F4	亮度减	F10	亮度加
F5	计算器	F11	搜索
F6	设置	F12	打开浏览器
	窗口切换		打开浏览器
	显示桌面		锁屏
Fn +	打开键盘关闭 F1-F12的fn功能		

5. 指示灯

	指示灯	灯光状态	意义
键盘	电源/充电指示灯	红灯长亮3秒熄灭	开机成功
		红灯闪烁	电量不足，请尽快充电
		红灯长亮	充电中
		绿灯常亮	电量充满
	大写锁定指示灯	白灯长亮	大写锁定
	NumLock锁定灯	白灯长亮	NumLock锁定
鼠标	电源/充电指示灯	红灯长亮3秒熄灭	开机成功
		红灯闪烁	电量不足，请尽快充电
		红灯长亮	充电中
		绿灯常亮	电量充满
	DPI指示灯	红灯闪烁一下熄灭	DPI调节至一档
		红灯闪烁两下熄灭	DPI调节至二档
		红灯闪烁三下熄灭	DPI调节至三档

6. 充电

当键盘或者鼠标处于低电量时，电源指示灯会一直闪烁红灯，请及时充电哦。请及时充电以确保有足够电量保证您的工作顺畅。
提示：当电量过低时，键盘和鼠标的传输可能会出现延迟、卡顿、连接不稳定的情况。

7. 参数

键盘	连接方式	无线2.4G连接
	无线距离	>8M
	电池容量	380毫安时
	可持续使用时长	>180小时
	待机时长	>120天
	充电时长	>1.5小时
	按键寿命	>300万次
	连接方式	无线2.4G连接
鼠标	无线距离	>8M
	电池容量	300毫安时
	可持续使用时长	>30小时
	待机时长	1年
	充电时长	>1.5小时
	DPI	800-1200-1600

提醒：功能和技术规格如有更改，恕不另行通知，对于由此给您带来的任何不便，我们深表歉意。

8. 保修

无线键盘鼠标享有1年的质量保修。更多的信息，请登录
www.ausdom.com

9. 安全须知

⚠ 警告：不遵循以下安全说明可致命导致起火，触电，损坏键盘设备
危险(高度危险要警惕)★警告(中度危险要警惕) ⚠ 注意(轻微危险要关注)

★ 1.请勿拆卸
2.远离高温指数或辐射源
★ 3.禁止重物挤压
★ 4.禁止冲击，弯曲键盘
⚠ 5.远离油类，酸类，碱类，化学腐蚀其他有机溶液

产品中有害物质的名称及含量

产品中有害物质的名称及含量						
	有害物质					
部件名称	铅（Pb）	汞（Hg）	镉（Cd）	六价铬（Cr6+）	多溶解度（PBB）	多溶二苯醚（PBDE）
电路板组件	×	○	○	○	○	○
塑壳部件	○	○	○	○	○	○
金属部件	×	○	○	○	○	○
电缆	×	○	○	○	○	○
其它配件	×	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。
○：表示该有害物质在该部件所有均质材料中的含量均在SJ/T 11363规定的限量要求以下。
×：表示该有害物质至少在该部件的某一均质材料中的含量高于SJ/T 11363规定的限量要求。
注：本产品所标识的环保使用期限，是指在该产品遵循产品安全及使用指导说明的条件下，期间内不泄漏有毒有害物质的期限。

合格证 certification
生产日期 Production date
SP-BA1806

品牌商:深圳市刚哲普由科技有限公司
地址:深圳市宝安区宝石工业园内第三工业区B栋

保修卡

保修期
产品自售出之日起7日内，发生质量问题，消费者可以选择退货，换货或维修，产品自售出之日起15日内，发生质量问题，消费者可选择换货或售修理。本产品自出商保证期限为以产品购买日起12个月有效。

免费服务：
在产品保修期内，凡属产品本身质量引起的故障，请用户凭此保修卡向我方以旨经销商/授权维修点，以享受免费保修。

以下情况恕不免费维修：
1.正保修卡或损坏产品标签。
2.由于质量造成的损坏。
3.因进水或跌落而造成的故障及人为机械损坏。
4.因不可抗力造成的故障或损坏。

客户姓名：	
联系地址：	
联系电话：	
产品名称：	
产品型号：	
购买日期：	
销 售 商：	
S / N 号：	
维修记录：	

WARRANTY CARD

ATTENTIONS:
- Please read the return procedures and warranty policy carefully on www.ausdom.com
before sending items back to point-of-purchase.
- Please fill the card and send it to your reseller together with the product if your product's warranty is valid.

S.N:	
Date of Purchase:	
Product Model:	
RMA Number:	
Return Reason:	
Customer Name:	
TEL:	
E-mail:	
Address:	

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.