Mobile screen manual

140mm

210mm

User Manual

Fileye

FIT-32

Customer Service

service@fileye.net

Customer Service

Dear customer:
If you are have any issues while using the product, please feel free to contact us before you return the product to us, we will provide solutions for the following:
Defective or damaged item?
Wrong or missing parts?
Missing parts or accessories?
Instructions are unclear or not adequate?
Wrong item was sent?

CONTACT US HERE
OUR EMAIL ADDRESS: service@fileye.net
You can email us directly.
Typically we will reply to you in 24 hours on business days!

Warning

Preface

Please read the Fileye smart screen Before starting the device. Please read the product features and notes in the user manual carefully.

Warning ⚠

- You can't use other power adapter to power this device.
- Do not block or cover the ventilation hole at the back of the device.
- Place the display store this machine in dusty, humid and high temperature environment.
- Do not use this machine in humid place, please do not disassemble and repair it by yourself. Please contact the original factory if the product is found to be faulty.
- To prevent electric shock, do not step on the power cord or power adapter. do not continue to use damaged power cord, if the power cord is found to be damaged, cut off the power at the time, please unplug the power cord.
- Do not place the display in high or low temperature or use, do not squeeze the display screen hard, and do not place the display screen in the environment with sharp objects, so as to avoid damage to the display screen.
- To avoid damage to the display screen, do not use sharp objects to touch the screen, or use pressure.
- Please clean the machine with a dry soft cloth or a soft cloth soaked in water. Do not use any other liquids, such as solvent, such as alcohol or gasoline, or it may damage the surface of the machine.
- Children must be made aware of the dangers of climbing this product, which can cause serious life injury if it is dropped or tipped.
- Do not place the product in an unstable or inclined position.
- To avoid tripping, be sure to arrange the cables connected to the equipment in time.

Packing List

After opening the package, please confirm the contents of the package below.

Installation Instructions for Fileye Mobile Smart Screen

Please keep the package 1-2 weeks in case of return or exchange.

1.Please check the appearance of the product, whether there are scratches, cracks, or other damaged parts on the product. If there are any damaged parts, please return the product.

2.If you need to return or exchange the product, please contact the seller in time. Please keep the product complete (with inside and outside, and the product and accessories are not damaged).



Notice:

- If you do not use this product for a long time, please remove the power cord on the back of the display.
- If the product crashes, unplug the power cord on the back of the monitor and plug it back in.

Using Remote Control

The descriptions in this manual are based on the buttons on the remote control. Please read this manual carefully and use the remote control in the manner described in this manual. The remote control must be pointed in the direction of the display's remote sensor.

To install batteries, open the battery cover, replace batteries with two AAA batteries, ensure that the battery is installed in the compartment, and close the battery cover. To remove the batteries, perform the installation actions in reverse.

Product Icon



Air Mouse has 3 levels of cursor speed.

From slow to fast:
Press and hold "OK" and "Volume+" buttons.
The speed adjusts one level when LED light on.
From fast to slow:
Press and hold "OK" and "Volume-" buttons.
The speed adjusts one level when LED light on.

Function Keys :

- **Home**: Press and hold 3 seconds Go back to the home;
- **Return**: Go back to previous screen;
- **OK**:Confirm action or insert cursor;
- **Cursor Locking**: Press to lock the air mouse, press again to unlock.
- **Play / Pause**: Multimedia play/pause.

Voice switch:

Press and hold "Volume Switch" to turn on voice channel. Release the key to turn off voice channel.

Low battery reminder:

The red light flashes slowly when the AAA battery power is low. The red light flashes quickly means that the battery need to be replaced at this time.

Sensor Calibration:

Automatic calibration:

The changes of voltage and temperature may make the cursor drifts. In this case, put the mouse flat on the desk and keep it still.
You can complete calibration by pressing any key to wake it up when it is in hibernation mode.

How to Use

For initial use, plug a USB receiver into the USB port of the device and wait for 20-60 seconds to install driver of USB receiver. Turn on the device, the receiver and can move on the screen means that pairing is successful.
If it is unsuccessful, press and hold "OK" and "Home" buttons, the LED light is flash. Pairing is successful when LED light stop flashing.

Product specifications

Transmission method: 2.4GHZ wireless
Sensors: 6 axis Gyroscope
Number of keys: 17
Range: ≥10m
Battery type: 2 AAA*2
Material: ABS Plastic and silicone
Size: 147*47*26MM
Weight: 50g

(Some buttons and services may not be provided depending upon models or regions.)

Notice:

- You can be button, press and hold for more than 1 second.
- The screen can be used without the remote control by touching the screen.

Internal Battery

This circular base contains a built-in rechargeable battery. When the device is not plugged in, it automatically switches to other power sources, when the power is adequate, the charger can connect to charge the battery. It will display 100% when the battery is full, and it will display 0% when it is empty. When using 3%, the "1%" on the display will keep flashing.

⚠Note:

The battery recharge from 0% to 100% for about 8 hours when the device is turned off.
The battery life of the equipment is about 7-8 hours after being fully charged.
The using time of the product increases, and the battery life and battery life decrease proportionally.
When the battery is low, the device is not in a recommended to charge the battery after using it for a period of time. After the battery is fully charged, it can be used.
Do not keep the battery fully charged all the time, and the battery cannot be charged in the extreme environment.

In the standard service time in the manual is based on the standard operation of the equipment, the actual time will vary according to the different conditions of use.

Note: Users are strictly prohibited from replacing or disassembling the battery by themselves, and the expansion of the whole machine due to improper installation or the use of the battery, the user should be responsible for it, please contact our customer service to deal with the relevant problems.

Description of Interfaces and Buttons

HDMI IN: Used to connect external HD video input.
TYPE-C: multi-functional interface, Can connect U disk, mouse, keyboard, computer, computer adapter, read the contents of the machine.
USB: Can use USB storage device, for mouse and keyboard connection.
Headphone jack: 3.5mm headphone output stereo sound for connecting external power amplifier devices or headphones.
POWER: Press once the power button for standby, and hold down 3s to shut down or restart the machine.

Product Specification

Hardware Specification	Model	FIT-32
	Operating system	Android 12(S)
	Processor	RK3566
	Memory	2G+16G
	Screen Type	32 inch panel
	Resolution (Effective pixel)	1920*1080
	Aspect Ratio	16:9
	Wi-Fi	2.4G/5G
	Bluetooth Output	Support audio output
	Power Consumption	12V/3A
	Power	Support all voltage input
	Type	Full-functional port for charging function
	HDMI IN	Video Compatibility
	Audio	Power
	Loudspeaker	Support 3D Stereo
	Speaker	8Ω 5W*2
	Input Voltage	12V/3A
	Built-in battery capacity	7h-8h(1000mAh)
	Storage Temperature	0°~ +40°
	Working Temperature	0°~ +40°

Product Specification

Hardware Specification	Camera	Support camera function
	Microphone	Support voice input function
	Sensor	Support G-sensor function
	Physical Dimension	147mm*47mm*26mm
	Net Weight	50g
	Gross Weight	200g
Product Appearance	Material	Plastic and silicone
	Color	Black
Product Function	Function	Support Wireless Screen Mirroring, Support Wireless Screen Casting, Support Wireless Screen Sharing, Support Wireless Screen Control, Support Wireless Screen Recording, Support Wireless Screen Capture, Support Wireless Screen Annotation, Support Wireless Screen Broadcast, Support Wireless Screen Interaction, Support Wireless Screen Collaboration

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.