280x210mm

L.L.Bean CUBE OUTDOOR SPEAKER LANTERN

BUTTON FUNCTIONS:

BUTTON "A"

-Press Two Seconds to Turn Speaker On or Off. After Turning On, Bluetooth Indicator Light Will Flash, then Stop Flashing When Connection Is Activated. Mood Light will Flash Slowly When Music is Playing.
-Press Again to Synchronize Mood Light to Music.
-Press Again to Turn Off Color Changing Mode.

BUTTON "B"

-Press to Play. Press Again to Pause Music.

BUTTON "C"

-Press and Hold to Decrease Volume.
-Gently Touch to Go To Previous Song.

BUTTON "D"

-Press and Hold to Increase Volume.
-Gently Touch to Go To Next Song.

BUTTON "E"

-Press to Turn LED Light On.
-Press Again to Adjust Light Intensity.
-Hold Button 1.5 Seconds to Turn Off at any Mode.

SPECIFICATIONS:

Material: ABS Plastic/Silicone
Speaker Power: 3W-5W
Battery Capacity: 1800 mAh
LED: 1W (3 Pcs SMD LED)
Brightness: 100 Lumens
Input: 5V1A
Bluetooth Receiving Distance: 32.8ft/10M
AUX Input Port: 3.5MM
Battery Charge Time: 4 Hours
Speaker Run Time: 10 Hours
LED Run Time: 6 Hours
Speaker/LED Together Run Time: 3.5 Hours
Waterproof Level: IPX4

BATTERY POWER INDICATOR:

Remaining Battery Power will be Displayed Showing One to Four Lights, Depending on Remaining Battery Power.

REMARKS:

Light and Speaker Controlled Independently or Together.
USB Charging Cable Included.

Made in China

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Modifications to this product will void the user's authority to operate this equipment.