IC2171



InkCase IVY
Quick Start Guide



❶ Mode / Power Button
❷ Up Button
❸ Down Button
❹ Magnetic Charging Port

■ Charging your InkCase IVY



Battery Full
Battery Empty
Battery Charging

■ Switching on your InkCase IVY



Press and hold the Power Button for 2 seconds, to switch on the InkCase IVY.

Note the Device ID at the bottom left corner of the startup screen during boot up. You will need this Device ID during the InkCase setup.

■ Switching off your InkCase IVY

To switch off the InkCase IVY, press and hold the Power Button for 2 sec.

The last viewed image will remain on the display after the InkCase IVY is switched off.

■ Standby Mode

InkCase IVY will enter standby mode automatically after inactive for 5 seconds. Click any button to exit from standby mode

■ Restarting the InkCase IVY

Press and hold the Power Button for 15 secs to reset an unresponsive InkCase IVY.

■ Navigating the InkCase IVY

Click on the Up or Down Buttons on the InkCase to navigate to the next or previous display.



Clock & Date Mode



To Do List Mode

Click on the Mode Button to switch between functions: Clock & Date, To do list and, Wallpaper

■ Specifications

- 2.13 inch E Ink single bit display
- Resolution: 250 x 122 pixels
- Color mode: 1 bit black & white
- Rechargeable Lithium polymer battery
- Standby time up to 60 days
- InkCase App required
- Bluetooth 4.0 BLE
- Weight: 50g approx
- 9H hardness cover lens
- Shock and drop proof design

FCC Statement
1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could
void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help