封面

Quick Start up Manual

Tronsbel

- Plug in the Micro USB pin into the charging port on the side of the speaker and the other end of the cable into any standard USB port (Dock or computer USB charger)
- The red LED indicator light will be turned on when it is charging.
- After the speaker being fully charged,the red LED light will be turned off automatically.
- If the speaker is out of battery,the speaker will "beep" twice every 2 minutes to remind for a recharge.

The product will take ►hours to be fully charged,You can use your when it is charging.

IMPORTANT NOTE

After being fully charged, the MagicBox has a play time up to 18 hours depending on volume, The play time varies for a number of reasons including the volume (for Maximum volume, it could be played around 3 hours), device, connection, and music type.

4.How to pair your Bluetooth device with the

- Make sure the product is fully charged.
- Make sure that the and Aux cable are plugged out when you are trying the Bluetooth function. If the or Aux cable is plugged in, the Bluetooth function will be disabled.
- Turn on the product, a blue LED light will be turned on and you can also hear a "Pair mode" message. And the blue LED will start flashing.

- Turn on the Bluetooth function of your smart device/PC.
- Search available Bluetooth devices on your smart device/PC. When the "Product name " appears on the list, please select it and your device will pair, connecting with the Product. Very few devices will request a password, if your device does, please enter"0000" (four zeros).
- When the speaker being paired successfully, you will hear a "brief message tone" again. The blue LED will stop flashing.

IMPORTANT NOTE

The Product ,could only pair with 1 device at once. When you turn on the Product, the Product will be automatically connected with the last paired Bluetooth device if that Bluetooth device is available and within range. If the product successfully paired with the last device, it will prevent any other Bluetooth device from pairing to it. The best way is to disconnect the first device from the product before trying to pair to another device.
To disconnect a device from the product, please press and hold ► for 5 seconds until the Blue light flashing. The Blue light flashing indicates the device is disconnected.

5.Connecting to new Bluetooth (AuxIN) devices

For devices that do not have Bluetooth or support for Bluetooth audio, you can connect and play music and audio by connecting your device to the AUX IN jack on the the product with the included 3.5mm audio cable.

- Turn on the product by sliding on the ON/OFF switch to the on position.
- Plug one end of the 3.5 mm audio cable into the AUX IN jack on the right side of the product and plug the other end into the headphone jack on your device. You can then play your music and audio on the product.

IMPORTANT NOTE

When in AUX IN mode the forward/backward and volume +/- ►► controlled from the device only. The ◄◄ and ►► will not be functional on the product

7.Troubleshooting.

Problem	Solution
Product will not turnon	• Ensure that the product has sufficient electricity. • Ensure that the switch button is in the "ON" position.
Cannot pair the product with my Bluetooth device	• Please make sure that the TF card and audio cable are plugged out when you are trying the Bluetooth function. • The product can only be paired and connected with one other device. (No speaker could only pair with 1 device at once) • The product will be automatically connected with the last paired Bluetooth device. The best way is to disconnect the Bluetooth of your other device or first and try begain.

Product appears on my device but will not connect	• Please make sure the speaker is not connected with any other devices. • Disconnect the other device from Bluetooth. • Turnthe product on and off. • Remove the product from the pairing list on the device and then repair.
Confirmed that Bluetooth driver for my Laptop	• For some older generations laptop/desktop, the Bluetooth driver on the laptop/desktop may not support A2DP. • We are suggesting you to buy an external Bluetooth USB adapter for your computer to support Bluetooth range.
Could not pair with my product	• Please unpair your product in the menu DEVICE SETPAIRED. • When you see RE connection between your product and the Bluetooth speaker, make sure that the Mic is on the Speaker or audio device.
Bluetooth range is short	• For smartphone/pad,the straight line Bluetooth range varies from 15-30ft depending on the Bluetooth version of the device and the environment. • For laptop/desktop, the Bluetooth range will drop significantly depending on the Bluetooth driver on the computer. • Walls, other electronic devices, obstacles, distancebetween speaker and the paired device will degrade the Bluetoothrange significantly.

1

TSE Magnetbox

● 3.5mm audio cable(*1) ● Micro USB cable(*1)

2

1.The Power Switch and Connectors.

Power on/off

Press and hold the power button for 3 seconds to turn on the speaker.The blue LED indicator will light up.
Press and hold the power button for 5 seconds to power off.

3

2.Control Buttons of the

Control music play with the in Bluetooth mode



Answering Calls

You can use them a portable speakerphone for incoming calls when connected wirelessly via Bluetooth.

- To answer a call, press the ► button.
- To end the call, press the ► button again.
- To refuse a call, press and hold the ► button for 2 seconds
- To end a call, press and hold the ► button for 2 seconds
- Control the volume during the phone call.

4

IMPORTANT NOTE

The Microphone is assembled on the back of the speaker. For better phone call quality, please face to the back of the speaker when you are calling.

3.How to charge the speaker

Before using your new wireless portable speaker, please charge it via the mini USB charging cable included in the package.Charging through a computer USB port is Preferred.If you need to use an AC/DC adapter/charger to charge the speaker,please use 5V, 1A USB wall charger.

MAKE SOUNDS MORE VIVID

封底

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

[1]This device may not cause harmful interference, and

[2]This device must accept any interference received, including interference that may cause undesired operation.