How to use your

RECHARGEABLE REMOTE CONTROL EGG

Before first use, charge the egg and remote by plugging the USB cable into a USB charging port for 120 minutes.

Press and hold the button on the egg until a light flickers. Press and hold the button on the controller until a steady light comes on. Push the controller button again to start the vibrations. The light on the egg will go off once a connection has been made with the controller. The light on the controller will stay on and mimic each vibration setting during play.



Press the controller button to cycle through 2 speeds and 5 patterns. Press and hold it to turn it off.

Apply a generous amount of water-based lubricant to the egg before insertion.

Clean after use with a specialist toy cleaner.

Warning: To avoid injury or aggravation of pre-existing conditions, do not use on swollen or inflamed areas or skin lacerations. No medical claims are warranted or implied by use of this product.

Conseils d'utilisation

ŒUF RECHARGEABLE TÉLÉCOMMANDÉ FR

Avant la première utilisation, veuillez charger l'œuf et la télécommande en branchant le câble USB dans un port USB pendant 120 minutes.

Appuyez et maintenez le bouton sur l'œuf jusqu'à ce qu'une diode clignote. Appuyez et maintenez le bouton sur la télécommande jusqu'à ce qu'une diode s'allume.

Appuyez à nouveau sur le bouton de la télécommande pour lancer les vibrations. La diode sur l'œuf s'éteindra une fois la connexion établie avec la télécommande. La diode sur la télécommande reste allumée et suit chaque motif de vibration lors de l'utilisation.

Appuyez sur la télécommande pour explorer les 2 vitesses et 5 motifs de vibration. Appuyez et maintenez pour l'éteindre.

Veuillez utiliser une quantité généreuse de lubrifiant à base d'eau sur l'œuf avant de l'insérer.

À nettoyer après utilisation avec un nettoyant spécial sex toy.

Attention: Pour éviter toute blessure ou risque d'aggraver des infections préexistantes, n'utilisez pas ce produit sur des régions gonflées et enflammées ou sur des lacérations cutanées. Aucune revendication d'ordre médical n'est posée ou impliquée.

Verwendung Ihres

WIEDERAUFLADBARES VIBRO-EI MIT FERNBEDIENUNG DE

Laden Sie das Vibro-Ei vor dem ersten Gebrauch auf, indem Sie das USB-Kabel für 120 Minuten in einen USB-Anschluss stecken.

Halten Sie die Taste auf dem Ei so lange gedrückt, bis die Leuchte flackert. Halten Sie die Taste auf der Fernbedienung so lange gedrückt, bis ein Dauerlicht erscheint.

Drücken Sie die Taste auf der Fernbedienung erneut, um die Vibrationen einzuschalten. Sobald eine Verbindung mit der Fernbedienung hergestellt ist, wird die Leuchte auf dem Vibro-Ei erlöschen. Die Leuchte auf der Fernbedienung leuchtet weiterhin und simuliert jedes Vibrationsmuster während des Gebrauchs.

Drücken Sie die Taste auf der Fernbedienung, um zwischen den 2 Geschwindigkeiten und 5 Vibrationsmustern hin- und herzuschalten. Halten Sie diese gedrückt, um das Vibro-Ei auszuschalten.

Verwenden Sie eine großzügige Menge Gleitmittel auf Wasserbasis, um das Vibro-Ei optimal nutzen zu können.

Reinigen Sie es nach Gebrauch mit einem Spezialreiniger für Sexspielzeuge.

Vorsicht: Um Verletzungen bzw. die Verschlimmerung von bereits bestehenden Problemen zu vermeiden, benutzen Sie dieses Produkt nicht auf geschwollenen bzw. entzündeten Stellen oder Wunden. Es wird kein medizinischer Nutzen der Verwendung dieses Produkts angenommen oder behauptet.

Consejos de utilización

HUEVO RECARGABLE CON MANDO A DISTANCIA ES

Antes del primer uso, cargue el huevo y el mando a distancia enchufando la cable USB a un puerto de carga USB durante 120 minutos.

Mantenga presionado el botón en el huevo hasta que parpadee una luz. Mantenga presionado el botón en el controlador hasta que una luz permanezca iluminada.

Presione el botón en el controlador de nuevo para iniciar las vibraciones. La luz en el huevo se apagará una vez que se haya conectado con el controlador. La luz en el controlador se mantendrá iluminada e imitará cada patrón durante el uso.

Presione el botón en el controlador para desplazarse por las 2 velocidades y 5 patrones. Mantenga presionado el botón para apagarlo.

Aplique una cantidad generosa de lubricante de base acuosa al huevo antes de la inserción.

Limpie después de cada uso con un limpiador de juguetes especializado.

Atención: Para evitar causar una herida o para no agravar infecciones preexistentes, es importante no utilizar este producto sobre zonas hinchadas o inflamadas o sobre laceraciones cutáneas. No puede realizarse ninguna declaración médica.

"My body is building, building to an explosion – with the relentless vibrations."

Fifty Shades of Grey®

THE OFFICIAL PLEASURE COLLECTION

Approved by E L James

FC CE RoHS

® & © Fifty Shades Ltd 2014.

Manufactured in China for Lovehoney Group Ltd, BA1 3EN, UK.
©Lovehoney Group Ltd 2014.
Lovehoney® is a registered trademark of Lovehoney Group Ltd.

Relentless Vibrations

RECHARGEABLE
REMOTE CONTROL EGG

Your Fifty Shades of Grey Relentless Vibrations Love Egg is a versatile and orgasmic toy that's ideal for both solo play and couples play.

Switch on the egg and remote control to establish a connection and kick-start the exciting vibrations.

Apply a generous amount of water-based lubricant to the egg and slip its smooth curves inside your vagina. Its ergonomic, silicone form is designed to fit your contours perfectly and carry the powerful vibrations straight to your sensitive nerve endings, including your G-spot.

The remote control operates the 2 speeds and 5 patterns of vibration from a distance of up to 10 metres, giving you and your lover plenty of exciting play options.

Alternatively, take charge of the remote control and embark on your very own pleasure adventure.

Virtually silent and completely waterproof, it's perfect for discreet play at home, out and about or underwater for extra thrills as well – the possibilities are endless.

Charge the egg and controller separately for 120 minutes with the USB charger cable for 100 minutes of play.

Fifty Shades of Grey®

Relentless Vibrations

RECHARGEABLE
REMOTE CONTROL EGG

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user’s authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.