BLE voice & Infrared remote conrtol manual

IR Mode
IR protocol: TC9012
Customer code: 0E0E



There are two modes of remote control: infrared + Bluetooth, remote control and TV is not paired or paired but not connected, in infrared mode, the key issued infrared code, press the button after the indicator light is red. After matching and connecting with the TV, press the button to send Bluetooth code -LRB-except power button) : continue to press the voice button to start recording, release the voice button to end recording, press the button after the light is green. Matching green “LEFT + HOME” or “BACK + Home” hold for at least three seconds and enter matching mode. The red light will flash from green to green, and the green light will turn off after two seconds, if the match is not successful within 1 minute, the matching mode will automatically exit and the light will be turned off. When the remote is not paired, press the voice button to enter the pairing mode. If the remote control previously had matching information, but did not connect with the TV, at this time press the voice button, the remote control will initiate 3s after sending infrared code back, such as back connection failure, the remote control automatically into matching mode. If the pairing is successful, the remote control clears the previously reserved pairing information and saves the pairing information; if the pairing fails, the previously reserved pairing information is retained. Without any operation for 10 seconds, the remote control goes to sleep. Press any key to wake up the remote control.

BLE voice & Infrared remote control manual

The remote control has two modes: infrared and Bluetooth.

In the infrared working mode, the key sends the infrared code.The indicator light is red after pressing the key.

In Bluetooth mode (after successful pairing with the TV), press the key to issue the Bluetooth code (except the power key).The indicator light is green after pressing the key.
Continue pressing the voice key, start the voice input.Release the voice key and end the voice input.

The pairing keys are HOME and LEFT keys. Press for more than 3 seconds to enter the pairing mode.
The red light changes from always on to green flashing.

After the pairing is successful, the green light is always on and goes out after 2 seconds.
If the pairing is unsuccessful within 1 minute, automatically exit the pairing mode and the green light goes out.

No operation was performed within 10 seconds and the remote control went to sleep.
Press any key to wake up the remote control.

If the remote control has paired before, press LEFT + HOME for 3 seconds to clear the pairing information.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

FCC Statement :
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
This device may not cause interference.
This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.
L'exploitation est autorisée aux deux conditions suivantes:
1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

IC Radiation Exposure Statement: This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. The equipment can be used in portable exposure condition without restriction.
Cet équipement est conforme aux limites d' exposition au rayonnement d' ISD établies pour un environnement non contrôlé. L' équipement peut être utilisé en état d' exposition portable sans restriction.