CYLO™ CANNONBALL

REGISTER
Register at **gocylo.com** you will be entered to win one of our monthly prizes!

IN THIS PACKAGE
- CYLO Cannonball Bluetooth Speaker
- Micro USB Charging Cable
- USB Outlet Adapter

BUTTONS

1. Power on/off. Hands free calling.
2. Play/Pause Music.
3. Press to increase volume. Hold to skip to next song.
4. Press to decrease volume. Hold to skip to previous song.

CYLO™ CANNONBALL

CONNECTION

1. Auxiliary Input
2. USB Charging Port



CHARGING DEVICE

To charge speaker, follow steps below:

1. Silicone dome casing, port cover, and input panel must be completely dry before charging.
2. Insert USB end of micro cable, included, into computer USB port or adapter.
3. Connect micro end of cable into the USB charge port.
4. Red indicator light is on when battery is charging.
5. LED indicator light is off when battery is fully charged.
6. Battery is fully charged in approximately 3 hours.

3 ways to recharge: Wall outlet, car, computer.

CYLO™ CANNONBALL

OPERATION

A. Power On/Off

Function	Operation
Power on	Hold the ⏻ power button for 2 seconds
Power off	Hold the ⏻ power button for 3 seconds

B. Pairing Earbud with Bluetooth Enabled Device

1. To enter pairing mode, turn on Cannonball Speaker.
2. On your device's Bluetooth menu, find and select "CANNONBALL". Your speaker and device are now paired (you may be required to enter a password "0000").
3. To unpair Cannonball Speaker, hold ⏯ button for two seconds.

C. Playing Music

Function	Operation
⏯	Press to Play/Pause
+	Press to increase volume. Hold to skip to next song
−	Press to decrease volume. Hold to skip to previous song

When volume is adjusted to it's maximum setting an indicator tone will sound.

D. Hands-Free Calling

Use the CYLO Cannonball as a portable speakerphone when connected wirelessly via Bluetooth®. To answer/end a call, press the Power On/Off button.

E. Stabilization

1. Press stabilization cap on bottom of Cannonball to stand speaker in place.
2. Depress stabilization cap to release.

CYLO™ CANNONBALL

HANDS-FREE CALLING

Your phone will forward calling alerts to the Cannonball

Your phone calls will ring through the Cannonball. Press the Power On/Off button to answer.

The Cannonball's built-in microphone will allow you to speak to the caller.

STABILIZATION

CYLO™ CANNONBALL

WATERPROOF

- The CYLO Cannonball has been rated IPX7 which allows it to be submerged underwater up to 1 meter. The speaker can stay underwater for 30 minutes maximum.
- The CYLO Cannonball will float above water and is fully splashproof.
- For best sound performance, the CYLO Cannonball must remain above the water.
- Make sure USB/Aux input flap is completely sealed before wetting the speaker.
- Do NOT charge speaker while speaker is wet.
- Do NOT plug auxiliary cable into speaker when speaker is wet.
- After use in water, it is recommended to place the CYLO Cannonball on an absorbent surface until it is fully dry.

Input flap must be completely sealed before submerging
(As shown above)

CYLO™ CANNONBALL

LED BEHAVIOR

Function	Action
Power ON	Rapid blinking BLUE indicator (until paired)
Pair Successful	Slow BLUE blinking indicator
Low Battery	Blinking RED indicator
Charging	Solid RED indicator
Fully Charged	LED off

SPECIFICATIONS

- Bluetooth: V 3.0+ EDR
- Support: A2DP V1.3, AVRCP V1.6, HFP V1.7
- Transducer: 1 x 50mm
- Rated Power: 1 x 3W
- Frequency Response: 75Hz-20kHz
- Signal-to-noise Ratio: >80dB
- Power Supply: 5VDC, 1A USB
- Battery Type: Lithium-ion polymer (3.7V, 1200mAh)
- Battery Charge Time: 3hrs
- Music Playing Time: Up to 8 hours (varies by volume level and audio content)
- Bluetooth Transmitter Power: 0-4dB
- Bluetooth Transmitter Frequency Range: 2.402-2.480GHz
- Dimensions: ø 110mm
- Weight: 453g

BACK COVER

CYLO™ CANNONBALL

IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Install this apparatus in accordance with the manufacturer's instructions.
6. Do not install this apparatus near any heat sources such as radiators, heat registers, stoves or other heat producing appliances.
7. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles and the point where they exit from the apparatus.
8. Use only attachments/accessories specified by the manufacturer.
9. Unplug this apparatus during lightning storms and when unused for long periods of time.
10. The main plug of the power-supply cord shall remain readily operable.
11. THIS PRODUCT IS PRIMARILY INTENDED FOR LISTENING TO MUSIC. THIS PRODUCT IS NOT A TOY.

CYLO™ CANNONBALL

CAUTION

RISK OF ELECTRIC SHOCK. DO NOT OPEN.

THE LIGHTNING FLASH WITH AN ARROWHEAD SYMBOL, WITHIN AN EQUILATERAL TRIANGLE, IS INTENDED TO ALERT THE USER TO THE PRESENCE OF UNINSULATED "DANGEROUS VOLTAGE" WITHIN THE PRODUCT'S ENCLOSURE THAT MAY BE OF SUFFICIENT MAGNITUDE TO CONSTITUTE A RISK OF ELECTRIC SHOCK TO PERSONS.

THE EXCLAMATION POINT WITHIN AN EQUILATERAL TRIANGLE IS INTENDED TO ALERT THE USER TO THE PRESENCE OF IMPORTANT OPERATING AND MAINTENANCE (SERVICING) INSTRUCTIONS IN THE LITERATURE ACCOMPANYING THE PRODUCT.

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE.

CAUTION FCC FOR USERS (USA ONLY)

This device compiles with Part 15 of the FCC Rules. Operation is subject to the following two conditions. (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CYLO™ CANNONBALL

FEDERAL COMMUNICATION COMMISSION INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by CYLO could void the user's authority to operate the equipment.

CYLO™ CANNONBALL

FOR PRODUCTS THAT TRANSMIT RF ENERGY:

This device compiles with Part 15 of the FCC Rules. Operation is subject to the following two conditions. (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RADIATION EXPOSURE STATEMENT

This equipment complies with the FCC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance 20cm between the radiator and your body.

WEEE NOTICE

The Directive on Waste Electrical and Electronic Equipment (WEEE), which entered into force as European law on February 13, 2003, resulted in a major change in the treatment of electrical equipment at end-of-life.
The purpose of this Directive is, as a first priority, the prevention of WEEE, and in addition, to promote the reuse, recycling and other forms of recovery of such wastes so as to reduce the disposal equipment consits of the crossed-out wheel bin, as shown:

CYLO™ CANNONBALL

This product must not be disposed of or dumped with your other household waste. You are liable to dispose of all your electronic or electrical waste equipment by relocating over to the specified collection point for recycling of such hazardous waste equipment by relocating over to the specified collection point for recycling of such hazardous waste. Isolated collection and proper recovery of your electronic and electrical waste equipment at the time of disposal will allow us to help conserving natural resources. Moreover, proper recycling of the electronic and electrical waste equipment will ensure safety of human health and environment. For more information about electronic and electrical waste equipment disposal, recovery, and collection points, please contact your local-city center, household waste disposal service, shop from where you purchased the equipment, or manufacturer of the equipment.

RoHS COMPLIANCE

This product is in compliance with Directive 2011/65/EU of the European Parliament and of the council of 8 June 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment.

CYLO™ CANNONBALL

LIMITATIONS OF WARRANTY

This Warranty only applies to products purchased for use, not for resale. This Warranty is invalid if the factory-applied serial number, date code label, and/or product label has been altered or removed from the product.

This Warranty only applies to defective factory material and factory workmanship and does not cover defects or damages caused by or attributable to: a) improper storage or faulty installation and operation; misuse or abuse; accident or neglect; b) internal damage caused by any liquid; c) subjecting the product or accessories to improper or abnormal usage or conditions, or d) other acts which are not the fault of CYLO/SPSA.

This Warranty does not apply to products which have not been charged for six (6) months. If the battery in a product has not been charged for a period of six (6) months, the product might not function or require its full potential and longevity performance. CYLO/SPSA does not offer any warranty for such performance.

It is the enduser's responsibility to operate and care for the product in accordance with the instructions and specifications supplied with the product. Repairs resulting from failure to do so are not covered by the Warranty.

REPAIRS, REPLACEMENTS OR REFUNDING AS PROVIDED UNDER THIS WARRANTY ARE THE EXCLUSIVE REMEDIES OF THE ENDUSER. CYLO/SPSA SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT, INCLUDING BUT NOT LIMITED TO LOST PROFITS, LOST SAVINGS, DAMAGE TO PROPERTY, LOSS OF TIME, OR INCONVENIENCE. EXCEPT TO THE EXTENT PROHIBITED BY LAW, THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESS AND IMPLIED WARRANTIES WHATSOEVER, INCLUDING BUT NOT LIMITED TO THE WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PRACTICAL PURPOSE.

NOTE:
The Warranty gives the enduser specific legal rights. The enduser may also have other rights which vary from state to state or country to country. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or implied warranties, so the above exclusions may not apply. The Warranty does not affect statutory legal rights under applicable national or local laws.

This Limited Warranty applies to U.S. residents only. All other countries are subject to review on a case by case basis.

CANNONBALL™
QUICK START GUIDE
AND ACCESSORIES

FRONT COVER

2016-04-05

FCC RF Exposure Information and Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.