DiDa pro　尺寸：110*80mm/128铜版纸/16P骑马钉/正反/彩色印刷　货前打样确认！

User's Guide



Portable **WiFi & Bluetooth** Speaker

NQFEB

User's Guide　EN

1. Introduction

Thank you for purchasing the NQFEB - WiFi speaker, the entirely new concept. It is totally different with Bluetooth speaker and traditional speaker: One or more pieces speaker can be connected with your smart device via router to play same music or different music at the same time.

Specification

NQFEB

Output Power:	15W
Frequency range:	80Hz-20KHz
Power supply:	Lithium battery or USB cable
Function Spec:	WiFi, Bluetooth, Line-in
Supported Device:	iPhone, iPad, iPod touch, Android Smartphone and Tablet, Window PC etc.
Support Mode:	Network Connection, Direct Connection, Bluetooth Connection, Cable connection

Rechargeable battery with charging option from USB cable

Operating Range:

Bluetooth Mode: operating range up to 33 ft

2. Function Profile





3. GETTING STARTED

Download the MUZO app in the App Store or Google Play store, then install the app on your device.

Available on the App Store

GET IT ON Google play

CONNECTING TO WIFI

1. Ensure your device is connected to a wireless network,then open the MUZO app.On the home screen, press"Wi-Fi Setup Wizard" button.You will be prompted to choose your network. Choose"YOUR WIRELESS_2.4G".-from the network list.
Please note:only 2.4GHz networks are supported.

2.Power on your NQFEB speaker by pressing and holding the power Button for 3 seconds.The mode indicator Will flash white when ready to pair to your network。

3. Long Press the W/M button about 2S into network connection。

4. Then check your APP, find this page on your APP. Then "Add your device". When goes into next page, choose "Add other MUZO compatible speakers"



5. Then goes into below page, click "BUSH"; then goes into SETUP page, to click "Settings" to set your WIFI. It will jump to your WIFI setting, then you just choose the "NQFEB_" to connect the speaker WIFI.





6. Then open you APP, you will find below page, choose your own WIFI and connect. Then Click "Continue", then connected.

7.To add more speakers, press+ on the top right and repeat steps 2-6.



8.Add your local music service provider to enjoy more music. Click the "Add More Services" button.



9.Increase the source service providers, need to open the source service providers behind the button.



LOGGING INTO YOUR AMAZON ACCOUNT

Once connected to your network, press the Login button to log in to your Amazon account, or skip this step. Note:You cannot utilize Alexa Voice Service if you are not logged in to an Amazon account.



Sign in to your Amazon account. If you do not already have an Amazon account, choose "Create a new Amazon account." It may take a few seconds for your account to load.Once logged in, the app will confirm your login successful. Note:You will be prompted to agree to Amazon's terms when logging in.



NQFEB Setting WiFi Password





① After connected with wifi, getting into the wifi connected page of MUZO App.

② Then click the "setting" button, select "speaker info" to get in the next page.

③ Select the "personal hotspot", then click the" Wi-Fi password", and you can set your own NQFEB Wi-Fi password.

Note: The NQFEB Wi-Fi password only can be set or changed under the opening of the "personal hotspot".

To activate Alexa, tap the microphone button on the top of your speaker or say "alexa" to awake speaker. You will hear a short tone. Next, ask Alexa a question, such as, " what is the weather today in New York?" Or you can tell Alexa to do something like, "Alexa, add milk to my Shopping list".

Note: After Network Connection, the password of speaker is always the password of the last router you connect, which will be used when Direct Connection.
If you forget the password of speaker, just use the router you have to Network Connection, then password will be this router's.

Resetting your DiDa speaker

To reset the NQFEB, insert a toothpick, straightened paper or insulation object clip into the AUX IN jack untill all touch button lights flash. You are successful complete resetting after all light off.



4. Mode Switch

When turn on speaker, it will be WiFi Mode automatically
Long time press "W/M" turn to Bluetooth mode
Long time press "W/M" again, it will turn back to WiFi mode

5. Bluetooth Connection

Long Press mode switch key"W/M"to change the mode from WiFi to Bluetooth . Then will see blue light"W/M" flash . The speaker is in Bluetooth mode and waiting for connection.
Navigate the Bluetooth function of your device (Select "Set Up" Bluetooth or turn "ON" Bluetooth)
Select "Search" or "Discover" devices
Select Bluetooth "**NQFEB**"
After completing the steps above, your device will remind you "connected". In case of unsuccessful pairing, turn off the speaker and restart it.

Direct Connection

(This is used when there is no network, such as outdoor activity)
1. Turn on the speaker. The mode indicator will flash white .
2. Enter WLAN setting of your device and turn on WLAN
3. Search the WiFi name of speaker "NQFEB_", connect.
4. Enter APP, play music or add more speakers
Remarks: The first speaker you connected just like the router, if you turn off the speaker, other speakers will be disconnected. If you turn off other speakers, the rest ones remain work.

The possible reasons of failure of adding devices:

1.The most possible reason is that your smartphone connect with the WiFi router which is 5G, then device can't receive the request of connection sent from smartphone.
2.If you have a dualband router (5G + 2.4G), please set the 2.4G password same as the 5G, then maybe connectable, maybe not, depends on the routers.
3.If the router set Enterprise WPA will fail to connect, as we don't support Enterprise WPA.
4.Below setting on router will also result in failing to add device:
a)If the IP address is assigned statically
b)If there is MAC address limitation, only specific MAC address could connect
c)The router is hidden.
5.Some routers has maximum connection, when exceed the maximum, will fail to add device.
6.Network is too bad, may be successful after trying many times.

6.Cable connection（Line-in)

Use provided audio cable as below to connect with speaker:



The 3.5mm audio cable of NQFEB can be effective under the boot state,and which will have hint tone.This 3.5mm audio cable does not work under the off state.

7. Charging and LED Indicator Light

Built-in lithium battery can be charged by Micro USB cable, see below picture:



8. Product Care

Your device is designed to be durable, but as an electronic device, it must be treated carefully. Putting unnecessary pressure on it or striking the device against other objects may cause damage:
1.Do not drop, crush, bend or apply excessive force to the device.
2.Do not expose your device to moisture, extreme or prolonged heat, cold, humidity, or other adverse conditions. Avoid storing it in damp, humid or wet places. It is not waterproof.
3.Clean the unit with a soft cloth or damp chamois leather. Never use solvents.
4.The unit can only be opened by qualified person.
5.This device contains magnets. Keep magnetic field sensitive products such as credit cards and video screen away from this device to avoid damage or malfunction.

9.LED Instructions

Button/LED	Color	Action	Significance
Status-LED	Red	Flashes	Battery is charging
Status-LED	White	Flashes	WLAN-Connection direct Wi-Fi connection
		Shines	Connected with router
	Blue	Flashes	Searches Bluetooth-device
		Shines	Connected With Bluetooth Device
Mic button	Red	Shines	Alexa feature is off
Voice control button	Blue	Shines	recording
		Flashes	Processing
		Slow Flashes	Replying

10. Things to try

Listen to music
"Alexa, turn it up!" Ask Alexa...
"Stop the music" "Pause"
"Next song" "Repeat this song"
Reminders
"Alexa, set a reminder"
Alexa can remind you about things
Ask Alexa...
"Remind me on Saturday to take out the recycling" "What are my reminders this weekend?"
Order from Amazon
Use your voice to stop 。
"Order light bulbs"
"Reorder toothpaste" "Add a drone to my cart"
Weather
"Alexa, how's the weather?"
Ask Alexa...。
"Will it rain tomorrow?"
"What's the weather in Honolulu?" "Is it sunny in Philadelphia?"
Learn and Be Curios
Ask Alexa all kinds of questions.
"Alexa, why is the sky blue?"
"When's Thanksgiving?"
"How many euros in a dollar?" "What's the capital of Costa Rica?" "How many people live in Wyoming?"

Federal Communications Commission notice
This device complies with Part 15 of the FCC Rules. Operation of this product is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance with the FCC Rules could void the user's authority to operate this equipment.

Specific Absorption Rate (SAR) information
The SAR limit of USA (FCC) is 4 W/kg averaged over 10 gram of tissue. This model (FCC ID: 2ANXWNQFEB) has also been tested against this SAR limited. The highest Reported SAR for extremity(hand) exposure condition is 0.16W/kg.

Distributed by
Bluestem Brands Inc.,
7075 Flying Cloud Drive, Eden Prairie, MN 55344
Tel: 1-800-208-2500
(Monday-Friday 8:00am-8:00pm Central time)