尺寸：90*84mm

包装清单



参数

型号：K042
耳机电池容量：40mAh*2
主动降噪：35dB
充电盒电池容量：400mAh
蓝牙版本：5.1
耳机充电时间：1-2H
阻抗：32Ω
频率范围：20HZ~20,000Hz
播放音乐时间（ANC关闭）：5H
充电口：Type-C
播放音乐时间（ANC ON）：4H
充电仓充电电压: DC5V

开始使用

配对与连接
1.开机后左右耳机进入TWS配对模式，自动配对
2.指示将闪烁到蓝灯（以配对模式）绿灯亮1秒，配对成功.
3.从蓝牙设备中的“设备”列表中选择[K042]。
4.超过蓝牙范围蓝牙断开，如果60分钟内回到蓝牙范围内自动回连，如果超过60分钟后自动关机(绿灯3秒一闪)

恢复出厂设置

如果以下步骤发生任何异常连接问题，请考虑将耳机重置为出厂设置：
1.清除设备上的配对记录。
2.从充电仓中拿起耳塞，耳塞都会闪烁绿灯。
3.长按左耳和右耳的触摸点击4次（请在按下之前注意不要悬外触摸），耳塞指示灯红灯闪三次，完全重置。
4.两已恢复为出厂设置的耳塞返回充电盒，关闭充电盒盖，然后再次拿出来。
建议第一个配对操作来使用
5.如果指示灯红点击4次后，红灯没有闪三次；请将耳塞放回充电盒中，再次重复步骤2-3



控制

佩戴

1. 识别左耳和右耳。
2. 旋转耳机并找到最舒适的位置。

开机与关机

开机：
1. 打开充电盒盖，耳机会自动开机。

关机：
1. **当耳机放入充电仓内，并合上电池仓上盖。**
2. **耳机在断开连接超过 6 分钟后会自动关闭。**

充电

耳机充电：
1. 耳机放入充电仓内合上电池仓盖关机自动开始充电，红色灯长亮。

电池仓充电：

开盖时循环亮呼吸变色，颜色变化 浅蓝，红色，浅黄，浅绿，深蓝，浅蓝,粉色，红，循环提示，一分钟灭灯。
2)**当耳机不在充电仓时仓盖显示，同开盖时一样。**
3)**当耳机在充电仓时合盖显示，检测耳机电量亮当前电量呼吸灯，呼吸灯循环显示，一分钟灭灯。**
4)**充电仓在充电状态:充电时亮显当前电量呼吸灯，电量在25%之间亮红色呼吸灯，电量在50%之间亮深蓝呼吸灯，电量在75%之间亮浅绿呼吸灯。电量在100%之间亮粉红色呼吸灯。电量充满后关掉全部充电呼吸灯。**
5)**充电仓电量低于25%以下，每隔一分钟亮10秒红色呼吸灯提示。**
6)**长时间不使用时，请至少每 3 个月为耳机和充电仓充电一次。 否则可能会损坏电池而无法使用。**



* 耳机低电报警：
电仓电指示低于3.5V±0.1V；自动关机电压为3.2V±0.1V;红灯指示灯（一分钟提示一次）亮1秒

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.
These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Package Content

Specications

Model: K042
Earphone Battery Capacity: 40mAh*2
ANC Noise Reduction: 35dB
Charging Box Battery Capacity: 400mAh
Bluetooth Version: 5.1
Charging Time of Earphone: 1-2H
Impedance: 32Ω
Frequency Range: 20HZ~ 20,000Hz
Play Music Time (ANC OFF): 5H
Charging Port: Type-C
Play Music Time (ANC ON): 4H
Charging voltage :DC5V

Getting Started

Pairing and connecting
1. The earbuds automatically pair to each other after open the charging case.
2. One of the indicators will flash to blue light. The other one lights up green for 1 second and then goes out(In pairing mode).
3. Selecting the [K042] from the device list in your Bluetooth list.

Factory Reset

Please consider resetting your earbuds to factory setting if any abnormal connectivity issues occur by below steps:
1. Clear the pairing record on your devices.
2. Pick up both earbuds from the charging case and Both earbuds will flash a green light.
3. press the touch button of the left ear and right ear 4 times respectively(Please be careful not to accidentally touch before pressing), the earbud indicator light goes out, reset completely.
4. Put the earbuds that have been restored to factory settings back to the charging case, close the charging case cover, and pick it out again. Follow the first pairing operation to use
5. If the indicator light does not go out after pressing 4 times, please put the earbuds back into the charging case and repeat steps 2-3 again



Controls

Wearing the Earphones

1. Identify the left and right earbuds;
2. Rotate the earbuds,and adjust tond the best angle.

Turning on & Turning off

Turn on:
1. Open the cover of the charging box, the earbuds will power on automatically.

Turn off:
1. When the headset is placed in the charging compartment, and close the battery compartment cover
2. The earbuds will turn off automatically after it is disconnected for more than 6 minutes.

Charge

KINGSTAR ANC earbuds are provided with a charging case for easy carrying and charging. It can recharge both earbuds around 4 times.
Charge the earbudsThe earbuds have been partially charged at the factory, please make sure they are fully charged before using for the first time.
1. Place back the earbuds correct charging slots and make sure the contactors connect.
2.Charging starts with lighting indicators staying on, (25%--red light. 50%--blue light. 75% --green light. 95%--pink light.)When the battery is fully charged all lights are turned off
Charge the case
The charging indicators will turn red when the battery of the case is low, please charge the case then.
1.Use a Type-C adapter to charge the case (current not over 1A, Please use a 5V charger).
2. Please charge the earbuds and case at least once per 3 months when not in use for a long time. Otherwise, the battery may be damaged and cannot be used.



Truly Wireless Active Noise Cancellation Technology

With the technology of Earbuds, you can select compatible communication devices without using cables. Earbuds do not require keeping the phone facing earphones directly, but the maximum distance between them should not exceed 10 meters (about 30 feet).

Using active noise cancellation technology, the microphones collect the noise, then the acoustic engineer calculates and designs a series of software and hardware algorithms, the circuit generates a reverse sound wave that is opposite to the noise and emits it through the horn. Finally, the noise and the reverse sound wave cancel each other.

Warranty and Support

We warrant this device 6-24 MONTHS from the date of the original purchase for the manufacturer.
email:vpservice@sina.com
FB:Vpservice10
After-sales URL：https://www.kingstarstore.com/

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.
These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

パッケージ内容



製品仕様

製品型番：K042
イヤホン本体バッテリー容量：40mAh*2
ANCノイズキャンセリング：35dB軽減
充電ケースバッテリー容量：400mAh
Bluetoothバージョン：5.1
充電時間：約2時間
インピーダンス：32Ω
周波数帯域：20Hz-20000Hz
再生時間：5時間（ANCオン）/4時間（ANCオフ）
充電電圧：DC5V

ペアリング

①充電ケースから左右両方のイヤホンを取り出し電源をONにします。
②接続する機器のBluetooth機能をオンにします。
③指示ライトが青色に点滅すると、緑色ライトが一秒間点灯したら、ペアリングが成功しました。
④接続する機器のBluetoothデバイス画面に本機「K042」が表示されたら選択します。
⑤接続範囲に超えたら自動的に接続を切断します。指示ライトはこの時青い色に点滅します。6分以内接続範囲に戻ると再接続します。6分過ぎて接続しないなら自動的に電源オフします。

リセット

ペアリングが出来ない場合や、本マニュアルに記載していない点滅や音声が流れた場合には、以下の操作でリセットをお試しください。
【リセット操作手順】
①接続した機器のBluetoothの設定を削除します。
②充電ケースからイヤホンを取り外します。
③左右いずれかのイヤホンのコントロールボタンを短く4回押してから（その前に誤って触れないように注意ください。）、指示ライトは赤色に3回点滅したら、リセットが成功しました。
④リセット成功したイヤホンを充電ケースに戻し、もう一度と取り出すと、最初のペアリング操作をもう一度やり直してください。
⑤4回押すと指示ライトは赤色に3回点滅しないなら、イヤホンを充電ケースに戻し、②と③をもう一度やり直してください。



操作方法

装着方法

①充電ケースに書いているとRから
左耳と右耳を分けます。
②快適な装着角度を調整します。

電源オン/電源オフ

●電源オン：
充電ケースのカバーを開けると、イヤホンは自動的に電源オンにします。
●電源オフ：
①イヤホンを充電ケースに戻し、充電ケースのカバーを閉じるとイヤホンは自動的に電源オフにします。
②イヤホン本体は6分以上に接続が切れると自動的に電源オフにします。

充電

①充電ケースのUSBポートに付属の充電用ケーブルのUSBコネクタを接続し、USB(A)コネクタをUSB充電アダプタなどに接続した後、ケースに本機を装着してケースを閉じると充電が始まります。
②充電ケースの指示ライトは充電する時、充電ケースバッテリー残量を表示できます。（25%-赤色のライト。50%-青色のライト。75%-緑色のライト。95%-ピンクのライト。）フル充電にすると、指示ライトは消えます。バッテリー残量は25%以下の時赤色のライトが点滅します。その時すぐに充電してください。
注意：
①本イヤホンは出荷する時一部に充電されていますが、初めて使用する前に、バッテリーを守るために、フル充電にしてください。
25V/1Aのアダプターで充電してください。
③長時間使用しないとき，バッテリーを守るために3ヶ月に一回充電してください。
④イヤホンのバッテリー残量低下する時にイヤホン指示ライトが1秒赤に点灯します（1分に一回）。バッテリー残量が低下すると自動的に電源オフします。



無料保証規定

本製品は、初期不良や通常のお取扱いにより発生した自然故障に対し、当社が無償交換を行わせていただきます。購入品あるいは以下のメールアドレスにお問い合わせください。保障期間はご購入日より24ヶ月で日本国内のみ適用いたします。
メールアドレス：qianlima1232021@163.com

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.
These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.