Table of Contents

1.Foreword.....2
2.Getting to know your touch phone 5
3.Starting up the device.....6
4.Introduce the basic phone function 8
5.Technical Specifications 14
6.SAR..... 15

Foreword

Safety

In order to ensure the phone is used safely and correctly, please read the precautions below carefully before use.

1. General precaution

·Your phone is only suitable for the battery and charger approved by our company or else it may cause the battery to leak, overheat, explode or even catch fire.
·Do not knock, vibrate or throw the phone heavily to avoid malfunction, fire, overheating, explosion or fire.
·If there are abnormal phenomena, like temperature rising, color change or distortion during the usage, charging or storage of the battery, please stop using it and replace it with a new battery.
·It may burn the skin if liquid in the battery leaks onto skin or clothes. If this happens please flush with plenty of clean water immediately and go to a hospital at once.
·Please keep the battery away from fire to avoid fire and explosion if the battery leaks or emits a strange smell.
·Do not place expose the battery to moisture or it may cause overheating, fumes and corrosion.
·Do not use or place the battery under direct sunlight, or in hot places, it may cause leakage and overheating, thus reducing performance and shortening the lifespan.
·Do not charge the battery for over 24 hours continuously.
·Use careful with the earphone maybe possible excessive sound pressure from earphones and headphones can cause hearing loss.

2.Precaution for the use of charger

·Do not cause short circuit to the charger, or it may cause electric shock, fumes and damage to the charger.
·Do not use the charger if the power wire is broken, or it may cause fire and electric shock.
·Please remove accumulated dust on the power plug.
·Do not put water containers next to the power supply to avoid overheating, fire, electric shock and malfunction in case they come into contact.
·Do not disassemble or tamper with the charger or it may cause personal injury, electric shock, fire and the damage of the

charger.
·Do not use the charger in places of high humidity, like bathrooms, or it may cause electric shock, fire and damage of charger.
·Do not touch the charger, power cord or power plug with wet hands or it can cause electric shock.
·Do not put heavy objects on the power cord or change the power cord or it may cause electric shock and fire.
·Please unplug the power socket before cleaning and maintenance.
·Please hold the charger to unplug the socket as pulling the power cord may damage the power wire and cause electric shock and fire.

3.Cleaning and maintenance

·As the phone, battery and charger are not waterproof, do not use them in places of high humidity and avoid them being wet by rain.
·Please clean the battery and charger with a soft dry cloth.
·Never use alcohol, thinner or solutions, like benzene, to wipe the phone.
·Dirty sockets can cause poor contact and power down, and even make recharging unavailable. So, please clean them periodically.

4.Common Precaution

Mobile Phone:
·Please use the phone in an environment with temperature between -20℃- 45℃and humidity of <75%.
·Please use the phone far away from regular telephones, TV sets, radio sets and office automation equipment, to avoid affecting the normal use of these equipment and mobile phone.
Battery:
·Store the battery in cool and ventilated place without direct sunlight.
·The battery has a limited lifespan. The usage of battery will be shortened progressively due to frequent charging. Once the battery is out of use, it means that its lifespan has ended, and you will need to replace it with an approved new battery.
·Do not dispose of old batteries as household waste. Give them to specified disposal places and follow any stipulated instructions for disposal.
CAUTION:RISK OF EXPLOSION IF BATTERY IS REPLACED

BY AN INCORRECT TYPE.DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCYIONS.

Charger:

·Do not charge under following conditions:

-- places with direct sunlight

-- places with ambient temperature less than 0℃ or over 40℃, wet or dusty places with strong vibrations (it may cause malfunction)

-- places near electrical appliances (it may affect the image and sound) like TV set, radio, etc

-- Adapter shall be installed near the equipment and shall be easily accessible. The plug considered as disconnect device of adapter.

Getting to know your touch phone

Starting up the device

To remove the back cover

·Make sure your device is turned off.

·Firmly hold the device with the front panel facing down.

·Slide your finger into the groove at the bottom of the phone and gently pull open the back cover.

To install the SIM card

·Remove the battery if it is installed.

·Locate the SIM card slot, and then insert the SIM card with its gold contacts facing down and its cut-off corner facing out of the card slot as shown in the diagram.

·Slide the SIM card completely into the slot.

To install a memory card

To have additional storage for your images, videos, music and files, you can purchase a memory card and install it in your device.

Locate the memory card slot on the upper part of the exposed left panel.

Insert the memory card into the slot with its gold contacts facing down until it clicks into place.

To install the battery

1. Align the battery's exposed copper contacts with the battery connectors at the bottom part of the battery compartment.

2. Insert the contacts side of the battery first and then gently push the battery into place. Replace the back cover.

Charging the Battery

New batteries are shipped partially charged. Before you start using your device, it is recommended that you install and charge the battery. Some batteries perform best after several full charge/discharge cycles.

Note: Only the AC adapter and USB sync cable provided with your device must be used to charge the device.

Connect the USB connector of the AC adapter to the sync connector on your device, and then plug in the AC adapter to an electrical outlet to start charging the battery.

As the battery is being charged while the device is on, a charging icon appears in the title bar of the Home screen. After the battery has been fully charged, a full battery icon appears in the title bar of the Home screen.

Warning:

• Do not remove the battery from the device while you are charging it using the AC or car adapter.

• As a safety precaution, the battery stops charging before it overheat

Power on/off

To power off your phone, press & hold POWER. On release, the Phone options menu opens. Select ‘Power off’ and confirm.

To power on again, press & hold power

Introduce the basic phone function

1.Switch MainMenu style

(1) In default Home screen, slide your fingertip left and right along the screen to reveal the more home screen.



(2) On Home screen, slide your fingertip up to enter the main menu screen, slide your fingertip up and down along the screen to reveal the more applications.





2. Home screen

(1) Read your notifications

When you see a notification in the status bar, touch the bar and slide your finger down the screen to open the list of notifications displayed in the sliding window.

Ongoing notifications report activities such as call forwarding ON, current call status,.

Notifications report the arrival of new messages, calendar events, and alarms. You can clear notifications list by selecting the icon of ‘Clear’ at the bottom of the notifications window.

To open the message, reminder or other notification, you can touch the items. To close the notifications window, slide your finger up the screen.

(2) Create Home screen shortcuts and widgets:

From the Home screen, long touch the TP and and then click the WIDGETS. Touch&hold to pick up a widget to select a shortcut to some of your saved information (such as a play list), a widget (a clock) for your Home screen.





(3) Move objects on the Home screen

• To move an icon or other item on the Home screen, you must first touch & hold it to enter move mode. The object will magnify when it's ready to be moved.

• Without lifting your finger (or you'll drop out of move mode), drag the object to the new position. To move the item to the part of the home screen that is not in the view, move it to the top of the screen and stay there for a while.The screen view will shift; position the object and release.

3. Camera

All the pictures you can capture or view on your phone are stored on a memory card, which must be installed in your phone. Before you can use the Camera or view pictures in Photos, make sure you have a card installed.

4. GPRS/WLAN network

Your device’s networking capabilities allow you to access the Internet or your corporate network through WLAN, GPRS.
You can also add and set up a VPN or proxy connection.
To use WLAN on your device, you need access to a wireless access point
Note: The availability and range of your device’s WLAN signal depends on the number, infrastructure, and other objects through which the signal passes.
To open the Browser you need to be connected to a network.





5. U-disk storage

This phone supports movable storage, i.e., the U-disk function. When the phone is switched on, you see the icon in the status bar on the top of the screen when it's connected to a PC by a data line. Touch the bar and slide your finger down the screen to open the list of notifications displayed in the sliding window. Select [Android system] and touch [Transfer files] , you can use the phone as a U-disk.





6. Bluetooth

The phone supports Bluetooth(BT) functions, you can establish a wireless connection between the phone with other compatible devices, and data transmission, you can establish a wireless connection between devices in the phone with a distance of up to 10 meters. Bluetooth connection may be interference by obstacles, such as walls or other electronic device.

1. Enter the setting menu, Touch the Bluetooth to open the function, idle screen will display BT icon in the status bar.
2. Open the BT discoverable, and other devices can search the phone.
3. Before using the phone as a Bluetooth device, you need to pair the phone with the target device as follows:

-Sure your phone has Bluetooth-enabled.

-Touch "Scan for devices." Bluetooth devices within the range of the phone will start scanning.

-Touch the device you want to pair, to confirm password to complete the pairing

You can use Bluetooth to share the pictures, videos or music files with family and friends

Technical Specifications

Technical Specifications

Weight: 134.5g(with battery)
Dimensions: 146.7*72*10.15mm
For the network:
GSM850MHz/GSM900MHz/DCS1800MHz/PCS1900MHz
WCDMA850MHz/1900MHz
Battery Type: Li-ion Battery
Battery Voltage：5V
Battery Capacity:2150mAh
standby time:2G About 375hrs
3G About 270hrs
Battery Manufacturer: Guizhou Hangtian
Battery model：H5315
Electric core mode：365680AR2150-2150mA
Battery Time (No prior or separate notice is required for capacity changes)

Note: Actual operating conditions depend on the local network environment, SIM, and user behavior.
Warning: Any consequence caused by misuse, abuse, or not following any and all of the above-written suggestions and instructions shall not hold the producer in any way responsible to any degree.
Announcement: The manufacturer reserves the right to change or upgrade specifications or software versions without prior or separate notice. Trade marks mentioned or used in this material belong to their respective owners.

SAR

FCC ID:2AO6ZK534

This wireless phone meets the government's requirements for radio wave exposure. The guide is based on standards developed by independent scientific organizations through regular and thorough evaluation of scientific research. The standard includes a substantial margin of safety designed to ensure the safety of all, regardless of age or health.
FCC RF exposure information and statements The United States (FCC) SAR limit is 1 gram of tissue average 1.6 W / kg. The device type K534 has also been tested for this SAR limit. The highest SAR value reported according to this standard during product certification for the ear is 0.77W / kg and is 1.16W / kg when properly worn on the body.

FCC Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information-

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. Before a new model phone is a available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, tests for each phone are performed in positions and locations as required by the FCC.

For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 1cm from the body. Non-compliance with the above restrictions may result in violation of RF exposure guidelines