TECKER X1 User Manual

Model : TECKER X1
FCC ID:2AOHZ000X1

Wireless Headset

Free Your Hands Free Your Life

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

1. Headset Overview



2. How To Use

2.1 How to Charge

A battery charge is necessary before the first time of use. Red light on means charging, while blue light on means fully charged (which takes about 2 hours).

2.2 How to Pair

(1) Long press the headset's MFB for 3 seconds until the LED blinks blue 3 times rapidly and then quickly blinks RED & BLUE (which means it is in pairing mode).
(2) Open your cellphone's Bluetooth, then search "Tecker X1" and connect. The LED blinks blue twice every few seconds once connected.

2.3 How to Pair Two Devices

(1) Pair with a cellphone first, then turn off both TECKER X1 and Bluetooth of the first cellphone.
(2) Turn on the headset again to pairing mode, and pair with another mobile phone.
(3) Turn on the Bluetooth of the first cellphone, the headset will connect the first one automatically. If not, you can manually connect it. (Then two devices are connected)

3. Functions

CALL & AUDIO	
Power On/Off	Press and hold the MFB for 3 secs
Play/Pause Audio	Tap the MFB when listening to music
Answer/End Call	Tap the MFB when a call is coming / when on a call
Reject A Call	Press and hold the MFB for 2 secs when a call is coming
Re-dialing	Double tap the MFB
Adjust Volume	Tap the "+"or "-" button
Previous/Next Song	Press and hold the "+"or "-" button for 2 secs
Activate Siri	Press and hold the MFB for 2 secs

Notes:

1. For better audio listening, it is advised to start a new headphone with some soft light music first under relatively low volume. It may takes days and even longer before the headset's speaker is fully "warm up" and perform the best.

2. For better and stable wireless range, please kindly make sure there are no obstacles (walls, etc.) between TECKER X1 and your Bluetooth device.

3. If you fail to connect, please pay attention to the below:
(1) Please turn off other Bluetooth devices that may connect TECKER X1.
(2) Pairing distance is advised to be within 3 feet (1 meter).
(3) Restart TECKER X1 and your device, then reopen their Bluetooth again for a second try.

4. Any Problems?

If you have any problems in actual use, please feel free to email us on Amazon, we will reply within 24 hours for your issue. It is appreciated that you can write us a review if you like our product, as your feedback can make a difference for us to improve our future product and service. Thank you very much!