105g双铜,彩色正反印刷,风琴折,
折后尺寸:65x65mm

正

MIUONO

True Wireless Stereo Earbuds with Charging Case

English

T1

User Manual

Bluetooth 5.1

POWER ON AND PAIRING

1. Before Using

Please charge your T1 before use. Simply take the earbuds out of the charging case and insert them into your ears. The earbuds will automatically power on and become ready to pair to your device.

The MIUONO T1 earbuds are rated IPX4 Waterproof ensures your bluetooth earbuds meet your active lifestyle needs.

3. Power On and Pairing

T1 earbuds will automatically turn on whenever removed from the charging case.

A. "*Power on*" prompt will be heard through the earbud within the first few seconds of wearing.

B. "*pairing*" prompt will be heard through the earbud if the previously paired device is not found.

LISTENING TO MUSIC

1. Once paired, open a music app on your device to Play/Pause music, adjust Next song/Previous song.

2. You can Play/Pause your music by simply press the button of either earbud once.

HANDS-FREE CALLING

1. Please followthe instructions below to answer/reject calls.

1. Answer Call

2. Reject Call

CHARGING

1. To charge your earbuds

Place both earbuds into the charging case whenever not using; Make sure to keep the lid closed.

2. To charge your case

With the provided Type-C Cable, plug the Type-C port into the charging port located onthe backside of the charging case. Then plug the USB side of the Type-C Cable into a standard USB Charger or port.

BATTERY LIFE

The T1 earbuds will provide a playtime of 20 hours. Get up to 7 hours on a single charge and an additional 13 hours from the included charging case. For a quick charge, place both earbuds back into the charging case for 20 minutes and get 2 hours of listening time.

	Earbud	Charging Case
Listening Time	7 hrs**	14 hrs
Charging Time	1.5 hrs	1.5 hrs
Talk Time	5 hrs	10 hrs
charged for 20 minutes	2 hrs	

** Listening time measured on a single charge at an 70% volume level

2. Power Off the Earbuds

To power off the earbuds, place both earbuds into the charging case and close the lid.

Please hold the press area of either earbuds for 5 seconds to power off the earbuds without the charging case; a "*Power off*" prompt will be heard. Please make sure that all music/audio is paused before powering off.

3. Auto Power Off

To conserve battery, the earbuds will automatically power off when it's out of range from your device for more than 5 minutes.

FAQ (FREQUENTLY ASKED QUESTIONS)

1.*How can I power on/off the T1?*
The earbuds will automatically power on when removed from the charging case and power off when placed back into the charging case. Whenever the charging case isn't near the earbuds, hold the press area of both earbuds for 2s to Power on and hold the press area of either earbud for 5s to Power off.

2.*How can I play/pause music ?*
Simply press the button area of either earbud to Play/Pause music.

3.*How can I receive/reject calls ?*
Press once the button either earbud to receive phone calls.Press hold for 2s to reject calls.

4.*What will affect the total playtime?*
Playtime will vary by the volume level, type of audio and connection status.

反

WHAT'S INCLUDED



2. Wear Earbuds

Both earbuds are marked with a L or R to indicate the appropriate ear side; earbuds are differently angled to fit either the left or the right ear. The proper fit will ensure the best sound quality. Insert the earbud into your ear and rotate slightly clockwise (as shown in image below); adjust for comfort.



C. Turn on Bluetooth on your device

a. Go to Settings > Bluetooth.

iOS

Android

b. Turn on Bluetooth.

c. Scan for and select "**MIUONO T1**".

d. Wait for successful pairing

3. You can skip tracks by double pressing the button of the earbuds. The Right earbud will skip to the next track and the Left earbud will skip to the previous track.

SIRI & GOOGLE ASSISTANT VOICE CONTROL

2. To activate Siri with the T1, triple press the button area of either the Right or Left earbud.

Note: Availability of Google Assistant voice control features will vary by different Android Phone models.
Button area is located directly on the center of the earbud.

3. Checking the Battery Level

A. Earbuds

- Earbud LEDs will indicate charge status while being charged in the case
- When fully charged, earbud LEDs will be turned off

B. Charging case

- LED will indicate the Battery level of the case whenever connected to a charger
- All LEDs will be lit when charging is complete
- LED will display the battery level of the case for 4 seconds when the earbuds are placed back in the case

POWER ON/OFF

1. Power On the Earbuds

The earbuds will automatically power on and connect to the previously paired device whenever taken out of the charging case.



To power on the earbuds without the charging case, hold the Press area of both earbuds for 2 seconds until a "*Power on*" prompt is heard.

TROUBLESHOOTING

Place both earbuds into the charging case and leave the lid closed; take earbuds out of charging case after 15 seconds.
This simple trick will resolve most problems which include but isn't limited to L/R channel disconnection or pairing/connectivity issues with devices.



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

TROUBLE SHOOTING: When the battery is completely drained while not in use for a long period of time, try charging it a few times as it will resume its normal charging process. Restart the charging process if the charging indicator does not respond or is turned off after a few minutes.

FCC ID: 2AXZ6-T1MIUMI

ONE YEAR LIMITED WARRANTY

RoHS
Printed in China