122 210*145MM

OPERATION INSTRUCTION

FUNCTIONAL DESCRIPTION

FM BAND RECEIVER

FM:88-108MHz



1.TELESCOPIC ANTENNA
2.MODE/LED LIGHT BUTTON
3.PLAY/PUASE/BT CALL BUTTON
4.PREV BUTTON
5.NEXT BUTTON
6.BATTERY COMPARTMENT
7.FAN
8.FAN BUTTON
（L/M/H THREE-LEVEL GEAR ADJUSTMENT）
9.POWER/LED LIGHT SWITCH
10.DC 5V IN JACK
11.AUX IN JACK
12.CHARGE INDICATOR LIGHT
13.POWER INDICATOR LIGHT
14.TF CARD SLOT
15.USB SLOT
16.HANDEL
17.STRAP
18.SPEAKER
19.SOLAR PANEL
20.LED FLASHLIGHT

	CAUTION	
The Lightning flash and arrowhead within the triangle is a warning sign alerting you of "dangerous voltage" inside the product.	RISK OF ELECTRIC SHOCK DO NOT OPEN CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK) NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.	The exclamation point within the triangle is a warning sign alerting you of important instructions accompanying the product.

1. Do not install this equipment in a confined or building-in space such as a book case or similar unit, and remain a well ventilation conditions at open site. The ventilation should not be impeded by covering the ventilation openings with items such as newspaper, table-cloths, curtains etc.
2. WARNING：To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such as vases, shall not be placed on apparatus.
3. WARNING: The battery (battery or batteries or battery pack) shall not be exposed to excessive heat such as sunshine, fire or the like.
4. WARNING: The mains plug is used as disconnect device, the disconnect device shall remain readily operable
5. No naked flame sources, such as lighted candles, should be placed on the apparatus.
6. Attention should be drawn to environmental aspects of battery disposal.

CURRENT 2600mA POWER 6W

THE OPERATING MANUAL

1.Put 18650 battery into battery compartment(6) paying careful attention to the polarity.
2.When listen to the programmes from FM,Please pull out the antenna and change the length to make the listening clear.When you don't want to listen to the radio, please turn it off and disconnect the USB power cord or take out the batteries. When you don't want to use the radio for a long time, please take out the batteries from the unite.

Function instruction

1.Push the power switch to start up, and the default is bluetooth. After hearing the bluetooth prompt, open the bluetooth function of the mobile phone for pairing and connection with the bluetooth number "FP-BT";
2. Open the mobile phone player to play music directly after the connection is successful. To select a song, press the " − " or" + "button to select the song, and press the " ►II "button to pause the play.
3. When dialing and answering the phone, the speaker of the host machine has a prompt sound of "beep". Press the language key once to make a phone call, and then you can make a call with the other party. At the end of the call, press the answer button again to hang up.
4, MP3 use note: there will U disk MP3 song or TF card in the machine, machine will automatically play music, if you want to choose MP3 or bluetooth or FM "MODE" button can be changed, want to choose songs, gently press the " + " or " − " button to select the curve up and down, if long press for 3 seconds the two buttons can quickly backward or forward, gently press" ►II "button to suspend play.
5. Radio instruction: press the MODE button gently to turn to the FM state, then pull out the antenna and place it in a good position. Press the " ►II " button for a long time for 3 seconds, and the radio will be automatically searched and stored in a good position. After the automatic search is completed, click " − "or " + " button to select the radio station.
6. Volume control: If you press " − " button for a long time, the volume will gradually decrease. If you press" + " button for a long time, the volume will gradually increase. When the volume is up to the maximum, the machine will make a "beep beep" sound.
7. Push the power switch to shut down. If there is no equipment operation with in 5 minutes of standby, it will automatically shut down.
8.While in the state of listening FM,MP3 and bluetooth play,long press "MODE"to turn the flashlight on/off.

NOTE:

1.This model includes built in rechargeable battery.
2.In order to prolong battery life and product normal use, charging time please keep 6-8 hours.

Notes for using rechargeable batteries:

After disassembling and installing rechargeable batteries, please plug in the power supply or charger to activate the battery, then turn on the power of the unit to work normally.

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However. there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.