# SP2

## Amazon Voice Control Music Speaker

# instruction manual

# SP2 APP SETUP:




1. Download APP from Play store ( Android ) or App store ( Apple )




2. Press " Add device " to setup.




3. Go to setting mode and select iHaper_XXXX device name.

Android Apple




4. Select iHaper_XXXX and press back key on android phone or press " < iHaper " on iPhone.




5. Select your home Wi-Fi network.




6. iHaper player is connecting to home Wi-Fi.




7. Connected Sucessful! Then, sign in with Amazon.




8. Logging into Amazon account.




9. Finally, select a language. And all setting is finished.

One device Three device




10. User can check your connected device on devic list.

# SP2 HOW TO PLAY:

## 1




Mobile phone

Wireless Speaker

1. Plug a power cord behind a wireless speaker. Then, connect a network and access to Amazon account. ( Please refer a previous page )

## 2 ALEXA MODE




Near field

Far field

2. For near field: Press “ 🎙” button on wireless speaker. And talk to Alexa.
   For far field: Say “ Alexa!” and ask a question to wireless speaker.

## BLUETOOTH MODE



Wireless Speaker

Mobile phone

1. Press BT button to select bluetooth mode. ( Blue light indicator will flash )
2. Turn on mobile phone bluetooth setting mode.
3. Search bluetooth device.
4. Select “ iHaper-SP2” and connect.
5. After connected, user can play music on wireless speaker through mobile phone.

## AUX MODE




Wireless Speaker

1. Press AUX button to select AUX mode. ( Yellow light indicator will show )
2. Connect an audio cable with 3.5mm stereo plug from an auxiliary audio device to the AUX-IN jack behind a wireless speaker.
3. Turn on the external auxiliary audio device and play music.

# FUNCTION LIST:












| | | |
|---|---|---|
| 1 | Sleep button | Sleep function |
| 2 | Mic button | Press to talk with Alexa |
| 3 | Mic mute button | Press to mute Alexa |
| 4 | Mute button | Press to mute music |
| 5 | Volume button | Adjust volume level |
| 6 | BT button | Connect to bluetooth device |
| 7 | Alexa button | Connect to Alexa |
| 8 | AUX button | Connect to AUX |
| 9 | Light indicator | Light indicator |
| 10 | WPS button | Connect to Wi-Fi network |
| 11 | DC-in jack | DC connect |
| 12 | AUX-in jack | Auxiliary audio signal input |
| 13 | Play/Pause button | BT music play/pause function |
| 14 | FF/FR button | Skip BT tracks backward/forward |

# LIGHT INDICATOR

MIC mute ( Red )

IDLE standby ( White )

Listening
(Blue->yellow->white->purple)

Thinking
(Flash Blue->yellow->white->purple)

Talking ( flash purple )

Exception
( 100% Yellow )

Notification
( Flash white + purple )




Other function mode

# FEATURE LIST

Alexa Speaker LinkPlay Module

Far field 2 mic System

Hi-Res Standard sample rate 96K for AUX

Wi-Fi Audio Streaming Via the APP

Bluetooth function support A2Dp and AVRCP

Aux input by 3.5mm Jack ( Aux Cable not include )

Touch key function with backlight

Stereo Speaker System

Speaker Size 1 inch Tre, 2 inch Full Range

8W + 8W power output

Card Type remote Control

Power input by AC/DC Adaptor

# FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.