尺寸：100x85mm

产品说明书

—Product description—




YYK-Q71

夹耳式蓝牙耳机

产品规格

蓝牙版本：V5.3
通话时间：约6小时
音乐播放：约6小时
待机时间：80小时
通信距离：>10m
耳机充电时间：约1小时
耳机电池容量：30MAH
充电仓电池容量：300MAH
频率特性：2.40ghz-2.48-ghz
支持协议：A2DP1.3/HFP1.6 HSP1.2/AVRCP1.6/D11.3

多功能键



暂停/播放：短按一下MFB键
上一曲：播歌状态下按两下L耳MFB键
下一曲：播歌状态下按两下R耳MFB键
音量加：长按右耳MFB键
音量减：长按左耳MFB键
接听电话：来电时单击MFB键
挂断电话：通话时单击MFB键
来电拒接：来电时双击MFB键
取消通话：拨号时单击MFB键
呼叫Siri：不播放状态按3下左或右MFB键
取消Siri：不播放状态按1下左或右MFB键

开机关机

1.初次将每侧的开盖反下，当耳机从充电仓里取出
耳机将会自动开机。
放回充电仓耳机前会开始充电并自动关机。

2.当耳机不使用时，放回充电仓自动关机。

如何重置

耳机在配对状态下，4秒MFB键，将耳机放入
充电仓，耳机盒自动关机并开始充电，取出耳机后，耳机
会自动开机，重置就完成。

如何配对

1.从充电仓拿出开机
2.耳机自动配对
3.打开手机/平板的设置—蓝牙—打开蓝牙—搜索—
YYK-Q71—配对/连接—播放音乐。

电脑/手提电脑配对的方法

打开电脑设置-设备-蓝牙和其他设备-开启蓝牙-添加蓝牙
或其他设备-检索蓝牙设备YYK-Q71点开后连接播放音乐。
注意：如果电脑没有蓝牙，请插入蓝牙适配器，下载蓝牙驱动
后再正常使用。

如何给耳机充电

1.把耳机放入充电仓内，耳机就会自动关机然后开始充电，
充电仓显示灯亮起，说明充电仓正在给耳机充电。
2.耳机充电时红灯常亮，充满红灯常亮充电仓灭灯。

给充电仓充电

请使用手机适配器给充电仓充电，可以使用电脑Type-c接
或者其他Type-c接口的充电器进行充电。

安全预防

产品包装内有

1.蓝牙耳机*2
2.充电盒*1
3.Type-C数据线*1条
4.说明书*1张

User Manual

—Product description—




YYK-Q71

Clip on Wireless headset

Product specifications

Wireless Version: V5.3
Talk time: about 6 hours
Music playing: about 6 hours
Standby time: 80 hours
Communication distance:>10m
Charging time of headset: about 1 hour
Headset battery capacity: 30MAH
Battery capacity of charging chamber: 300MAH
Frequency characteristic: 2.40ghz-2.48-ghz
Support agreement:A2DP1.3/HFP1.6 HSP1.2/AVRCP1.6/D11.3

multiple use key



Pause/play:Briefly press the MFB key
Last song: Press the L ear MFB key twice when playing the song
Next song: Press the R ear MFB key twice when playing the song
Sound plus: Press and hold the right ear MFB key
Sound reduction: Press and hold the MFB key on the left ear
Answer the call: Click MFB key when calling
Hang up the phone: Click MFB key during call
Call rejection: Double-click MFB key when calling
Cancel call: Click MFB key when dialing
Call Siri: Press the left or right MFB key 3 times in the state of not playing songs
Cancel SiriPress the left or right MFB key once when the MFB key is not playing songs

Power on/off

1. When the headset is taken out of the charging chamber for the first time,The headset will turn on automatically.
Put the headset back in the charging chamber and it will start charging and automatically shut down.
2. When the headset is not in use, put it back into the charging chamber and turn it off automatically.

How to reset

When the headset is in pairing status, press the MFB key 4 times. Put the headset inThe headset will automatically shut down and start charging. After removing the headset
It will start automatically and the reset will be completed.

How to pair

1. Take out the charging chamber to start the machine
2. Automatic headset pairing
3. Open the settings of mobile phone/tablet — Bluetooth
— Open Bluetooth —Search—
YYK-Q71 — pairing/connecting — playing music.

Computer/laptop pairing method

Turn on PC settings - Devices - Wireless and other devices - Turn on Wireless - Add WirelessBOr other devices - search Wireless device YYK-Q71 - pair/connect - Play music. Note: If the computer does not have Wireless, please insert the Wireless adapter and down load the Wireless driveThen it can be used normally.

How to charge the headset

1. Put the headset into the charging compartment, and the headset will automatically shut down and start charging,The display lamp of the charging compartment lights up, indicating that the charging compartment is charging the headset.
2. The red light is always on when charging the headset, and the blue light is always on when charging the headset. The charging chamber is off.

Charge the charging chamber

Please use the mobile phone adapter to charge the charging chamber. You can use the computer Type-c cableOr other chargers with Type-c interface.

Safety precautions

There are

1. Two Wireless headsets
2. One charging base
3. One Type-c charging line
4. 1 manual

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement， the device can be used in portable exposure condition without restriction