双听运动耳机
OPENEAR Air X1

使用说明书

佩戴方式

配件清单

OPENEAR Air X1 X1　　说明书 X1　　充电线 X1

产品信息

产品型号：OPENEAR Air X1
耳机类型：双听运动无线耳机
BT版本：5.2
频率范围：20Hz-20KHz
连接范围：≥10米
麦克风灵敏度：-42db
电池容量：180mAh
续航时间：≥7小时（80%音量）
充电时间：≈2小时
充电电压：DC 5V



按键示意图

开/关机

开机：长按多功能键3秒，LED白绿灯闪烁。
提示音：power on pairing;
关机：长按多功能键3秒，LED绿灯闪烁,提示音：power off.

蓝牙连接

打开蓝牙菜单，选择"OPENEAR Air X1"进行连接，
提示音：connected.

接听/挂断电话

单击多功能键。

拒接来电

来电时双击多功能键。

播放/暂停音乐

单击多功能键。



上/下一曲

上一曲：长按＋键。
下一曲：长按－键。



音量加/减

音量加：单击＋键。
音量减：单击－键。

唤醒语音助手

三击多功能键。



低电量报警

当电池电量低于10%时，每隔30秒绿灯闪烁3下，
提示音：battery low。

恢复出厂设置

关机状态下，长按多功能键10秒。

充电

请使用DC 5V适配器为设备充电,充电时绿灯常亮，充满电白灯常亮。

重要说明

1.长时间听大音量音乐可能会带来不适感，请尽可能使用中等左右的音量，避免长时间使用大音量；
2.无论音量大小，使用耳机都将影响您对周围环境的感知，使用耳机时多加注意；
3.切勿拆除或改装耳机，否则可能导致耳机故障或烧毁；
4.切勿抛扔、坐压耳机或将其投入火中；
5.耳机应远离火、高电压设备；
6.不合适十岁以下儿童使用，内包含细小零件；
7.请勿将其归类为生活垃圾，而将其送往当地相应的电器设备回收站。
注意：若用户因违反以上警告内容造成的人身财产损失，本公司不承担任何责任。

Dual Listening Sports Headphones

OPENEAR Air X1

User Manual

How to Wear

What's In the Box

OPENEAR Air X1 X1　　Manual X1　　Charging Cable x1

Specifications

Model: OPENEAR Air X1
Type: Open-Ear Wireless Headphones
BT Version: 5.2
Frequency: 20Hz-20kHz
Connection: ≥10m
Microphone: -42dB
Battery: 180mAh
Play Time: ≥7h(80%volume)
Charging Time: ≈2h
Charging Voltage: DC 5V



Button Control



Power On/Off

Power On: Press & hold the MFB for 3 sec,
white & green led flash. Prompt: power on pairing.
Power Off: Press & hold the MFB for 3 sec.
Prompt: power off.

BT Connection

Select "OPENEAR Air X1" in BT menu to connect.
Prompt: connected.



Answer/Hang Up A Call

Click the MFB once.

Reject A Call

Double click the MFB.



Play/Pause Music

Click the MFB once.



Previous/Next Track

Previous Track: Press & hold the button ＋.
Next Track: Press & hold the button －.



Volume Up/Down

Volume Up: Click the button ＋ once.
Volume Down: Click the button － once.



Voice Command

Quick triple click the MFB.

Low Battery

When battery is lower than 10%, prompt: battery low.

Restore Factory Setting

Under power-off mode, press and hold the MFB for 10sec.

Charge

Please use DC 5V adapter for charging.
Green LED is on during charging.
White LED is on after fully charged.



Attentions

1.Listening to loud music for a long time may cause discomfort,please use medium volume if possible.Donot use high volume for long periods of time.
2.Using headphones will affect your perception of the surrounding environment. Pay more attention when using headphones.
3. Do not remove or modify the headphone,as this may cause damage or burn out.
4. Do not throw,twist on headphones or put them into a fire.
5.Keep it away from fire,hydration and high pressure equipment.
6.Not suitable for children under 10-year-old containing small parts.
7.Do not classify it as household waste. Please send it to the local electrical equipment recycling station.
Note:The company does not assume any responsibility for the loss of personal property caused by the violation of the above warnings..

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.