FREEMAN

Let's learn to walk in style.

www.free-man.cn

(material code): **1080600013**

FREEMAN

Drifting Board

User Manual



Precautions



⚠ WARNING

Wear safety gear and read this paper carefully before driving.
In low battery state,it will autimatically switch to cruise mode.No high speed and high acceleration in low battery status.
Use drifting board before,Make sure that the drifting board is fully charged.Wear suitable protective gear.
Pay attention to the surrounding environment, as far as possible in a safe place to drive.
Please comply with local laws and regulations and use it in places where electric drift plates are allowed.

Remote control function



1.Press and hold the power button on the skateboard for about 10 seconds until the LED starts flashing.
2.Switch on the remote control and use a sharp object to press the binding button on the remote control, until the pairing LED on the remote starts flashing green, indicating successful pairing succeeded.
Firstly, Press and hold the power button on the skateboard for about 10 seconds until the LED starts flashing.
Secondly, Switch on the remote control and use a sharp object to press the binding button on the remote control, until the pairing LED on the remote starts flashing green, indicating successful pairing succeeded.

Remote control function



Electric drifting board



Press the power button to turn on the drifting board and the eagle eye light.

⚠ WARNING

Don't move board until the beeps end(in first 5 seconds after the boot).

Specifications

Capability	Mileage	10Km
	Low speed mode	10Km/h
	High speed mode	15Km/h
Entire board	N.W.	4.0 Kg
	Size	180mm*160mm*105
Board	Material	3.5mm Aluminium alloy
Battery	Capacity	3200mAh
	Type	29.4V Lithium battery
	Weight	400g
	Charging time	1.5 hours
	Cycle life	Above 1000 times
Motor	Type	70mm Hub Motor
	Power	Single-motor 350w
Wheel	Material	PU
	Size	70mm*51mm
	Hardness	78A
Remote	Capacity	500mAh
	Battery type	Lithium battery
	Charge time	2 hours
Package	Size	200mm*200mm*120mm
	G.W.	4.53KG

CE RoHS UN38.3 MSDS

80 X 128MM

(design): Serenity	(quantity): PCS	(model): D1	(colour):
(check):	(units): MM	(name):	(size):
(approve):	(scale): 1:1	(type):	(material):
(version): V1.0	(page): 1	(date): 2018. 2. 28	(surface finish):

FCC Notice

This device complies with Part 15 of the FCC Rules. Operation is
subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.