Get Started

Wi-Fi® connection required. Works with Alexa®, Google Assistant® and select Apple® and Android® mobile devices. Free Carrier Home App download required. See User Guide at CarrierAtHome.com for more details.

Position the air monitor.
Choose a spot in the room at least 3 feet off the floor and 5 feet from any exterior door or window.

Plug it in.
Connect the USB-C power cord to the air monitor and power adaptor. Plug in the power adaptor. The top ring of the air monitor glows as it starts up.

Connect.
Sign up or log in to the Carrier Home app[1] (free download and account).

Tap the *Add device* button, scan the QR code on the product, and follow the instructions to start learning more about the air in your home.



works with alexa

works with the Google Assistant

What's in the box?

Carrier air monitor

Power adaptor

USB-C power cord

Questions?
We're here to help.

For more information and a list of FAQs, visit *CarrierAtHome.com*.

Customer service / assistance is available by calling 1-888-320-0909.

[1] Wi-Fi® connection required. Works with Alexa®, Google Assistant® and select Apple® and Android® mobile devices. Free Carrier Home App download required. See User Guide at *CarrierAtHome.com* for more details.

Carrier
Turn to the experts

HEALTHYHOMES

Third-party trademarks and logos are the property of their respective owners.

©2021 Carrier. All Rights Reserved.

01-IAQ-087-01

Carrier

Get your air monitor up and running

You're one step closer to being more informed about your air quality. In just a few minutes, you'll have the Carrier air monitor up and running, and you'll know more about your air.

Get an instant reading

The Carrier air monitor continuously scans the air in your room. Visit the Carrier Home app[1] to get your air quality reading.





Get connected

Download the Carrier Home app to your phone.

Make sure the air monitor has the cord connected, is plugged into an outlet, and is on. Bluetooth® will automatically turn on for 10 minutes.

Launch the app and sign up for a new account if you do not already have one.

On the app, tap *Add device* and select the device you want to add to your account.

Scan the QR code on the bottom of the monitor.

Select your Wi-Fi Network and enter your password.

Start enjoying real-time air quality monitoring!

A solid light on the unit will provide an instant indication of the air quality level detected in your room.



A pulsing glow indicates the room air quality is of concern. Check the Carrier Home app[1] for more information.

Note: The indicator light on the unit can be turned on/off via the Carrier Home app.[1]

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any inte rference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interferenceto radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.