Wireless Speaker

SP366

Introduction

Thank you for choosing the SP366 as your source for entertainment! You can use this item with iPads,iPhones, iPods and many types of smartphone to stream music and enjoy handsfree calling. In order to get the best results when using the device, please read this manual first before using.

Important Waterproof/Safety Information

Important: DO NOT submerge the SP366 speaker in water,this unit is not intended to function properly after being under water.SP366 is rated IPX6,which means the speaker can be heavily splashed with water or left in the rain(but not submerged in water) for approximately a limited time.If the SP366 gets wet,it is recommended that you dry the speaker completely before using it again.
Please note:Speaker is not water-resistant when the silicone cover is open.please make sure that cover is closed and secure before using in a wet environment.

Description:



1.ON/OFF button

2.Play/Pause/Phone

3.MIC

4.Previous/Volume –

5.Next/Volume +

6.Red LED(Charging)

7.Green LED(AUX)

8.Blue LED(Bluetooth)

9.Micro USB Charging Port

10.AUX in Port

Included:

1.Speaker
2.USB Micro Charging Cable
3.3.5 mm Audio Cable
4.User Manual
5.Warranty Card

Specifications

Bluetooth Version : 4.2
Supported Profiles: A2DP, HFP, AVRCP
Bluetooth Range:33ft (10m)
Dimensions: 180 mm x 65 mm
Battery: 600mah rechargeable lithium battery
Charging: 5V @ 500 mA

Operation

Power On
Press and Hold "ON/OFF" button 2 seconds to power ON, the Blue LED will start to flash.
If an Aux (3.5 mm) cable is connected to the unit, the Blue LED will turn off, and the Green LED will stay illuminated,notifying you, the uint is in Aux-In mode.

Power Off
Press and Hold "ON/OFF" button 2 seconds to power OFF

Bluetooth Mode

Pairing
The unit will automatically go into “Pairing Mode” when it is powered ON.
Go into your Bluetooth device settings menu and look for “Sylvania SP366”

After the unit has paired and connected, it will re-connect automatically when the unit is powered on and the device is in range.
Note: You can press and hold the button to unpair your current device and search for new devices in Bluetooth mode.

Begin Streaming Music

Press “ ” to start playing music
Press and Hold“ ” 2 seconds to play the next track
Press and Hold“ ” 2 seconds to play previous track
Press either “ ” or “ ” for volume control

Making and Receiving Phone Calls

When the unit is connected and paired to your device, the unit allows you to make or receive phone calls with its built-in microphone.
Press “ ” to accept a call
To end a call press“ ”
To reject a call, press and hold “ ” for 2 seconds

Aux-In Mode

Plug in the supplied 3.5 mm cable into the unit. The other end is connected to your device. The Green LED will only illuminate when in “Aux” mode.
Please note music and volume can be controlled by your device.

Charging

Attach the USB cable to the unit, and plug into any USB charger. If the unit is completely discharged, it will take approximately 4 hours to fully charge.

The Red LED will illuminate during charging, when it has completed, the Red LED will turn off.

Note:There will be a beep when the battery is low and needs to be recharged.

LED Status

Blue LED flashing & Blue LED solid	Bluetooth Mode
Green LED on solid	Aux Mode
Red LED	Charging

Troubleshooting

Unit doesn’t connect to device	Speaker needs to be connected/ re-paired to device
A tone is heard every few seconds	Speaker needs to be charged
Unit will not power on	Speaker needs to be charged
Unit doesn’t control track(s)/volume	Speaker needs to be in Bluetooth mode for full control
Unit distorts at high volume	The devices’ volume needs to be lowered

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.