尺寸：60*85mm，材质：150g铜版纸

Specification

Model: KI-SP01H
Wireless version: V5.3
Product material: ABS+Iron mesh
Output power: 200W
Battery capacity: 20000mAh
Working time: 9h(50% volume)
Charging time: 4h30min
Product weight: 4.8kg
Product color: Dark gray
Product size: 320*294*522.5mm
Operating temperature: 0°-45°C

Wireless pairing

① Turn on the wireless speaker and enter the mobile phone wireless pairing interface.
② Search for wireless SP01H and click to connect.

Tips: If you cannot find the wireless pairing name, please short press " ⏻ " on the wireless speaker to enter the mode; for not wireless mode, please short press " ⏻ " to exit wireless pairing mode.

Packing list



Wireless Speaker*1



Multifunctional remote control*1

Microphone*2

3.5mm AUX Cable *1

Type-C Charging Cable *1

User Manual*1

Button operation instructions





Power on/off: long press for 2 seconds

× 8 s
The speaker malfunctions and crashes: press and hold for 8 seconds

× 1 ☀
Light effect switch: short press for 1 second

× 2 s ☀
After turning off the light, press and hold again for 2 seconds to turn on the light

× 1 ⟟ ▲ ▲ ▲
Switching mode: Wireless / Line / TF / AUX / Bluetooth mode: short press for 1 second

× 2 s
Turn on/off the voice assistant: press and hold the 8 key for 2 seconds.

× 1 ▷ / ⏸
Play/pause: short press for 1 second

× 1 ⏭
Forward/Prev: short press

× 2 s ⏭
Reject a call: Press and hold for 2 seconds

× 1 ⏮
Volume down: short press

× 2 s ⏮
Forward song: Press and hold for 2 seconds

× 1 ⏮
Volume up: short press

× 2 s
Rewind song: Press and hold for 2 seconds

× 1 ⟟
Enter wireless pairing mode:long press mode after successful connection: short press

× 2 s
Long-press pairing mode,left TWS pairing mode after successful connection: press and hold for 2 seconds

× 8 s
Reset: long press for 8 seconds



× 1 ⟟
Line wireless microphone on/off

× 2
Double-click to switch the volume operation of a wired microphone or instrument

× 1 s
➔ In microphone mode, short press to turn down the reverberation of the wired wireless microphone.
➔ In instrument mode, short press to turn down the instrument input volume.

× 1 s
➔ In microphone mode, short press to turn up the reverberation of the wired wireless microphone.
➔ In instrument mode, short press to turn up the instrument input volume.

× 1 s
– Short press to weaken the reverberation of the wireless microphone.
➔ In microphone mode, short press to weaken the reverberation of the wired wireless microphone.
➔ In instrument mode, short press to weaken the instrument input reverberation.

× 1 s
+ Short press to strengthen the reverberation of the wireless microphone.
➔ In microphone mode, short press to strengthen the reverberation of the wired wireless microphone.
➔ In instrument mode, short press to strengthen the instrument input reverberation.

USB-A power bank function

This speaker has USB charging function, please plug in the device when the speaker is on, the speaker will automatically detect
The speaker will stop charging the mobile phone when the speaker is turned on, it will automatically shut down after 30 minutes.

Aux-in mode

You can connect your music player/mobile phone to the speaker via the provided 3.5mm AUX cable, and the speaker will automatically
Recognize and switch to AUX mode.

TF/SD card mode

Insert the TF/SD card into the speaker will automatically recognize and play the TF/SD card music.
Warm reminder: TF card supports lossless format music WAV, FLAC, APE, MP3.

Wired microphone function/instrument input function

The speaker supports wired microphones, which can be used by plugging in a wired microphone or a wired instrument.

OTG digital live broadcast

Connect to a mobile device via a Type-C data cable for internal recording live broadcast and other functions.

Wireless microphone

① UHF wireless technology
② Wireless straight-line distance 20+ meters
③ Free switching of multiple frequency points to avoid frequency channeling
④ Moving coil high-sensitivity microphone
⑤ Type-C interface, fast charging
⑥ Battery capacity: 3.7V/1800mAh
⑦ Working hours: 10 hours
⑧ Charging time: 5 hours
⑨ Charging voltage: 5V/1A

Wireless microphone button operation

Press key	Operate	Function Description
On/off		① Press once to power on ② Press and hold for two seconds to power off ③ Shutdown state, need wait for 3 seconds to power on
FN		① Short press the Press and hold for 2 seconds to switch between A microphone/B microphone

CHR Microphone	ON →	OFF →	FN can be from 640.0mHz to 845.0MHz
CHR Microphone	OFF →	ON →	FN can be from 651.0mHHz to 860.0MHz

Power saving mode

If there is no operation after power on:
It will automatically shut down after 30 minutes.
When the battery runs out, it will automatically shut down.
When the battery is low, the battery indicator flashes, the speaker does not perform any operations and will automatically shut down after 30 minutes.

Reminder

1. Please use the product according to the instructions.

2. Please store and use this product in a room temperature environment.

3. Do not use this product near heat sources, such as radiators, heat seal regulators, stoves or other heating instruments.

4. In order to protect your hearing and extend the service life of the product, please do not adjust the volume to the maximum value for a long time.

5. Please choose a charger that has passed the safety certification of a regular manufacturer to charge the product.

Remote Control Console Operation Guide

1. Power switch: Press and hold the button for 2 seconds to turn off the speaker.
Control the wireless speaker to shut down;
2. Warm-up special effects: 5 popular warm-up special effects.
3. Mute: Mute microphone sound.
4. Recording studio: microphone sound effects.
5. Concert: microphone sound effects.
6. Mode switch: Wireless / Wired / Bluetooth / Line / Aux / Card / U disk.
7. Customized special effects: Wireless connect to your mobile phone, long press to record sound, short press to play special effects.
8. Special effects ---- Adjust the sound reduction of "warning effects"
9. Rate the tone: Turn up the voice of the music being played to change the rhythm of the music being played.
10. Original tone: Normal music sound.
11. Lower tone: lower the voice of the music being played and change the rhythm of the music being played.
12. Wireless: Switch to the speaker "wireless" playback mode.
13. Mute: short press for 1 second, the speaker is muted;
Short press again: restore volume.

14. Original accompaniment: short press for 1 second: eliminate the original sound (accompaniment mode)
Short press again: restore original sound.
15.EQ: Speaker "EQ" button switch.
16. Loop: TF card, U disk mode, single loop can be switched.
17. Dodge: Automatically adjust the volume of background music.
18. Microphone Wireless microphone "switch" button.
19. Mode Speaker "mode" switching (wireless/U disk/TF card/AUX).
20. ▲ Speaker "previous song" button operation.
21. Speaker "Volume Down" button operation.
22. Speaker "Volume Up" button operation.
23. ▼ Speaker "Volume Up" button operation.
24. Speaker "next song" button operation.

25. Adjust the volume of the reverberation effect of the instrument input.

26. Adjust the volume of the instrument input.

27. Adjust the 3.5 headphone output volume.

28. Adjust the live OTG output volume.

29. Adjust the microphone bass volume effect.

30. Adjust the microphone treble and volume effect.

31. microphone reverb volume adjustment.
(Adjustment is only useful when selecting #7#, recording studio, or concert mode.

32. Adjust the overall volume of the microphone.

This device complies with part 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
FCC radiation exposure statement:
This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment can be used as portable exposure without any restriction.