LED Ceiling Light

348-2129 (C7253)



1. Turn the clasp and remove the lamp shade downward



4. Insert the lamp body through the screw and turn the lamp body Until the lamp body cannot be removed through the screw head, then lock the screw



2. Fasten the kit screws to the junction box





3. Connect the black wire of the lamp with two wires of the same color on the junction box with the wiring cap provided, and connect the ground wire of the lamp with the ground wire of the wiring gold.



5. Push up the lampshade, yellow turn the lampshade, Clamp the lamp shade to the lamp body and turn on the power (using tuya intelligent control).

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference.
(2)This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note:This equipment has been tested and found to comply with the limits for a class B digital device,pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequence energy and,if not installed and used in accordance with the instructions,may cause harmful interference to radio communications.However,there is no guarantee that interference will not occur in a particular installation.if this equipmemt does cause harmful interference to radio or television reception,which can be determined by turning the equipment off and on,the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an autlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement,This equipment should be installed and operated with a minumum distance of 20 cm between the radiator and your body.