180mm

90mm

Speaker with Wireless Charger Instruction Manual

Congratulations on your purchase of this Speaker with Wireless Charger .
To ensure a long service life and optimal functionality of this product we recommend that you read this manual carefully.

Package Content

1 Speaker with Wireless Charger
1 Type-C Charging Cable
1 User Manual

Specifications

Input (Type-C): DC 5V/2A, DC 9V/2A
Wireless Output: up to 15W (while connecting with external power supply).
Speaker: 4Ω 3W
Bluetooth version: V 5.3
Bluetooth distance: up to 10M
Built-in microphone: Yes
Battery capacity: 720mAh/3.7V

Instructions

Power on: Press and hold the power button for 3 seconds till hearing the "POWER ON"
Power off: Press and hold the power button for 3 seconds till hearing the "POWER OFF"
Pause/Resume: Press the power button to pause/resume the music.
Answer calls/Redial: Press the power button to answer the call. Double press the power button to dial the last call on the phone.
Reject incoming calls/End calls: Double press the power button to reject the incoming call. During the call, press the power button anytime to end the call.

Pairing:

1. Turn on the speaker and Bluetooth on your phone.
2. Find "BTSW100" under the available device.
3. Select "BTSW100" to pair. You will hear "Bluetooth connected" when connecting successfully.

Previous/Next Song: Press the "+" button to play the next song. Press the "-" button to play the last song.
Volume: Press and hold the "+" to increase the volume. Press and hold the "-" button to decrease the volume.
Wireless charging: Wireless charging is available only when the speaker connects with an external power supply. Place the Qi-enabled phone on the wireless charging area. The bottom LED light will slowly pulse in and out to indicate wireless charging is connected, and a wireless charging notification will show on your phone.
Note: When there is a foreign object or errors, the bottom indicator light will flash. Remove the device and unplug the external power supply. Make sure there are no foreign objects between the charging device and wireless charger.
Recharging: Connect the speaker with external power. The red charging indicator light is on, and the red indicator light will be off when the charging is complete.
*Use an adapter that supports QC and PD fast charging

Usage tips:

. To ensure the best charging experience, remove protective cases.
. Charging time depends on battery capacity, phone input specifications, current phone energy consumption, phone position on the wireless charger, distance, etc.

Safety information

- Do not use damaged power cords, wall plugs, or loose electrical sockets.
- Do not place any metal objects between the smartphone and the wireless charger.
- Do not drop or cause an impact on the device.
- Do not disassemble, modify or repair the device.
- Keep away from humidity and heat environments.
- Keep it beyond the reach of children.

180*90mm 70g 书纸 单面印刷 对折一次

说明书折法
图非1:1



第一折痕





说明书折完后正面

说明书折完后背面

说明书折完后尺寸：90*90mm

标准说明书	JMTek	图 号	BTSW100-SMS-JMT001	版 次	第2版	材 料		颜 色		单 位	mm
		型 号	BTSW100	日 期	220913	设 计	Steven	批 准		客户回签	
		料 号	70431-0248-01	第 三 角 度 投 影				第 1 张 共 1 张			

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.