

START GUIDE

F2

Long Distance Communication 2-Way Intercom

Bluetooth®

Manufacturer: Shenzhen xuanwuke Industrial CO., LTD
Address: 411-416 Room Social security building, Honghua Rd,Road Longgang Street Longgang New District, Shenzhen, China



Basic Operations 基本操作



Pair Device(Mobile phone) デバイスとペアリング(スマホ)



Mobile Phone スマホ



Intercom インタコーム

1 Initiate Pairing
インタコーム間のペアリング開始

2 Power on (No.1) and (No.2)
電源オン (No.1) and と (No.2)

3 (No.1) and (No.2) enter pairing mode
(No.1) と (No.2)ペアリングモードに入る

4 Paired Successfully
ペアリング完了

5 Start Intercom
インタコーム通話開始

End Intercom
インタコーム通話切断

Music 音楽

Play Music:
音楽再生

Pause Music:
音楽停止

Play Previous:
前の曲の再生

Play Next:
次の曲の再生

User Manual Download

https://www.myfodsports.com/support/product/manual

Fodsports
Official Facebook Page

facebook.com/Fodsports

Fodsports Official Website

www.fodsports.com

Fodsports
Official YouTube Channel

youtube.com/@ Fodsports

Package Include パッケージリスト

1 x F2 host
1 x F2 ホスト

1 x Hard Tube Microphone
1 x ハードマイク

1 x USB Cable(TYPE-C)
1 x USBケーブル(TYPE-C)

1 x 3M Glue Velcro
1 x 3M接着剤ベルクロ

3 x Velcro
3 x ベルクロ

1 x START GUIDE
1 x クイックガイド

Installation 取付

1

Open the inner lining on the ear position of the helmet attach the VELCRO loop.
ヘルメットの耳の位置にある裏地を開き、ベルクロループを取り付ける。

2

Attach the headphone velcro hook to the loop (the short-line speaker is on the left.)
ヘッドホンのベルクロフックをループに取り付ける(短いスピーカーは左側にある)。

3

Stick the microphone and Velcro on the left side of the helmet at a suitableposition, aim the microphone at the mouth position and arrange the wires to the inner lining.
ヘルメットの左側にあるマイクとベルクロを適切な位置に貼り付け、マイクをエロの位置に向け、ワイヤーを内側の裏地に配置する。

4

Open the 3M Glue Velcro on the back of the host.
ホストの背面にある3M接着剤ベルクロを開く。

5

Attach the host to helmet.
ホストをヘルメットに取り付ける。

6

installation completed.
インストール完了

Technical Specifications 技術仕様

Bluetooth 5.0 Support: HSP,HFP,A2DP,AVRCP
Battery: Ithium battery, 400mAh /3.7v
Dimensions: 75mm *15mm * 10mm
Intercom users:Two riders
Working time:12 hours
Standby time:200 hours
Charging time: 2 hours
Weight: 30g
Frequency Range: 2.4G-2.485G
Operating temperature: -20 ℃-50 ℃
Certification: CE FCC ROHS BQB TELEC
USB Adapter standard charge voltage: DC 5V±0.2V
USB Adapter standard charge circuit: DC 1A±0.5A

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are
designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio
frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.