USER MANUAL





Also includes:
- Micro USB Cable
- 2 Pairs of Earbud Tips (small, medium)

PAIRING TO BLUETOOTH DEVICE

Make sure the Bluetooth function is available on your electronic device. Specific pairing procedures may vary slightly depending on the device. For detailed information, please refer to your device's User Guide.

· Keep the distance between the device and the earbuds within 3 feet (for pairing only).

· If no device connection is made within 10 minutes of the earbuds being switched on, the earbuds will automatically switch off to save power.

PAIRING BOTH EARBUDS

The two earbuds have been connected each other by factory, you don't need to pair them again. The left earbud is the default master one

1. Pick up two earbuds from charging station, then tear the stickers on earbuds first.
2. A few seconds later two earbuds will connect, soon you may hear voice prompt "left channel / right channel".
3. Press and hold main button of each earbuds for 2 seconds simultaneously to power on . A few seconds later two earbuds will connect each other.After two earbuds connected, the master one will automatically enter pairing mode, blue and white lights flash alternately. Then the deputy one is standby mode, blue light flashes once every 7 seconds. Activate the Bluetooth function on your device to search for Bluetooth devices. Look for "G3" in device list display and select. Then you may hear voice prompt "Pairing successful / Second device connected".

If two earbuds connection fails, please turn off two earbuds and follow below operation.

Press and hold main button of each earbud for 4 seconds simultaneously until blue and white lights flash alternately. A few seconds later two earbuds will connect. The bluelights will flash 2 times every 2 seconds. Soon you may hear voice prompt "left channel / right channel" .Then follow step 3 in PAIRING BOTH EARBUDS.

SINGLE EARBUD PAIRING

LEFT EARBUD only

1. When earbuds are power off, press and hold the main button for 4 seconds until blue and white lights flash quickly, soon you may hear "pairing".
2. Activate the Bluetooth function on your device to search for Bluetooth devices. Look for "G3" in device list display and select.
3. When successful connection is made, blue light will flash once every 7 seconds. Left earbud is now ready for use.

RIGHT EARBUD only

1. When earbuds are power off, press and hold the main button for 4 seconds until blue and white lights flash quickly, soon you may hear "pairing".
2. Activate the Bluetooth function on your device to search for Bluetooth devices. Look for "G3" in device list display and select.
3. When successful connection is made, blue light will ash once every 7 seconds. Right earbud is now ready for use.

To Power Off Earbuds [2 ways]

Automatically turn off earbuds by placing them back into charging case.

-OR-

If BOTH earbuds are being used together, press and hold multi-function button on MASTER Earbud only for 4 seconds until you hear "power off" or see the white light appear for 1 second. MASTER Earbud will turn OFF and the other earbud will turn OFF automatically.

If only SINGLE earbud is used, press and hold multi-function button on that earbud for 4 seconds, SINGLE earbud will turn OFF.



Power / Multi-Function Button
ON/OFF, PLAY/PAUSE
Answer/End/Reject CALL

EARBUDS CONTROLS

Listening to Music

Play/Pause/Resume music	Short press multi-function button
Next song	Double press multi-function button
Activate/Stop SIRI	Press/hold multi-function button on Master Earbud for 1 second during standby/music playing

Making and Receiving Calls

You can use your earbuds in various ways for handling calls.

Answer a call	Short press multi-function button
End a call	Short press multi-function button
Reject incoming call	Double press multi-function button
During a call, switch from earbud to phone & back to earbud from phone	Double press multi-function button

BATTERY DISPOSAL:
This product contains a lithium polymer battery. Lithium polymer batteries are environmentally safe when fully discharged. Please refer to your local and state laws for battery disposal procedures.

CHARGING THE CHARGING STATION

1. Plug the built-in USB cable of the Charging Station into an active computer USB port or USB AC adapter that is plugged into an active wall outlet.
2. **Red** light will flash to indicate charging has begun.
3. Once fully charged, red light will always on

CHARGING THE EARBUDS

These earbuds have an internal rechargeable battery. The battery must be fully charged prior to use. Charging time is approximately 2 hours. Earbuds cannot be used while charging.

1. **Place earbuds into charging station.(Please tear the stickers on earbuds first)**
2. **White lights around earbuds turn on when charging has begun. White light turns off when charging is complete.**
3. **Pick up two earbuds when they are charging in charging station, they will automatically power on.**

SPECIFICATIONS

Sensitivity	≥70dB
Frequency	20Hz-20kHz
Bluetooth Version	Bluetooth V5.0
Standby Time	Up to 150 hours
Charge Time	Up to 2 hours
Continuous Play Time	3 hours
Battery in earbud	Polymer Lithium: 3.7V 50 mAh
Battery in charging station	Polymer Lithium: 3.7V 500 mAh
Extreme Temperature	45 degrees max

FCC Warning:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
o Reorient or relocate the receiving antenna.
o Increase the separation between the equipment and receiver.
o Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
o Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.