立刻移除水印

J.ANE MUSIC DESK LAMP

BLUETOOTH SPEAKER, WIRELESS CHARGER, LED LAMP, LED CLOCK

THANK YOU

for choosing a quality product



I. Picture Description

1. Time setting(press for 2s)
2. Volume - / Previous
3. Play/Pause button
4. Volume + / Next
5. Lamp control
6. LED Clock
7. Bluebooth Speaker
8. LED Lamp
9. Power supply connection socket
10. Aroma Diffuser (Optional)
11. Wireless Charger

pdfelement

II. Safety instructions

- Only operate the device when it is connected directly to a working electrical socket.
- Protect the device from dirt, moisture, overheating, and extreme temperatures and only use it in dry rooms.
- Do not open the device. Stop using the device if it becomes damaged.
- The device should only be repaired by a specialist.
- Keep out of the reach of children.
- Only use a soft, dry cloth to clean the device.
- Before cleaning or repairing the device, or if the device is not used for a long period of time, disconnect it from the power supply.
- Run all cables so that they do not pose a tripping hazard or block emergency exits.
- Never use force when plugging in the device and the adapter (if used).
- Do not operate the product outside the power limits given in the specifications.
- Only use the supplied power supply for charging.
- Keep magnetic stripe cards like credit cards, phone cards, passbooks, and boarding passes away from the magnetic field, as they may get damaged.
- Keep the product away from medical devices (pacemakers, hearing implants, etc.) to avoid that it interferes with the device.
- Do not expose your ears to high volume for a long period of time (max. 5 min. nonstop/overall max. 3 hours per week), to avoid hearing damage.

III. Scope of delivery

- Music Lamp
- Power supply

IV. Technical specifications

- Model: LZ-C1801
- Input: DC 9V/3A
- Output: 5W/ 7.5W/ 10W (Wireless Charger)
- Maximum charging distance: ≤5mm
- Luminous flux: 250lm MAX
- Sound Driver: 2*4W
- Bluetooth version: v.5.0
- Bluetooth profile: A2DP, AVRCP
- Bluetooth range: 10m

V. Operation

Connect the included power supply to the corresponding connector (9) and a suitable power source.

Wireless Charger

- Place the smartphone on the designated area (11)

Connecting devices:

- Go to the Bluetooth settings of your smartphone and search for following device: ANU-C1803
- As soon as a connection has been successfully established, the product will play a confirmation sound.
- If the product is not in use for a longer period of time(10min), the Bluetooth speaker will power off, keep the control (3).
- If the Bluetooth speaker connected , Keep thecontrol (3) pressed to disconnect the Bluetooth speaker.

LED Clock

- Keep the control (1) for 2 seconds, the LED Clock flash, press (3) to chose the hour/minute, and press (2)(4) to adjust the time.

VI. Function notes

Lamp control:

- Keep the control(5) 2 seconds to switch the light on/off
- Touch the control(5) shortly to switch between the 4 brightness levels.

Volume switch:

- Shortly press +/- on the volume switch(2)(4) to regulate the sound volume.

Next/Previous:

- Keep +/- pressed on the volume switch(2)(4) to jump from one song to another.

VII. Troubleshooting

Setting up the connection doesn't work:

Make sure that the product:

- is inside the working range of the device.
- is not already connected to any other device (deactivate Bluetooth at surrounding, other devices).

Make sure that your terminal device

- is compatible to the Bluetooth version, listed in the technical data in this manual.
- has an active Bluetooth connection, and is in pairing mode.
- does not have other, active connections running.

Try to connect the product to a different terminal device.

The device doesn't charge properly:

Make sure that the maximum charging distance that is stated in the technical specifications is not exceeded. If necessary, remove cases or other objects from the smartphone that might be too thick.

VIII. Warranty

We assumes no liability and provides no warranty for damage resulting from improper installation/mounting, improper use of the product or from failure to observe the operating instructions and/or safety notes.

IX. Disposal notification

Electric and electronic devices as well as batteries must not be disposed of with household waste. Consumers are obliged by law to return electric and electronic devices as well as batteries at the end of their service lives to the public collecting points set up for this purpose or point of sale.

FCC Statement

This device complies with part 15 and part 18 of the FCC Rules. Operation is Subject To the following two conditions:

(1) This device may not cause harmful interference, and (2) this devicemust accept any interference received, including interference that may cause undesired operation. Changes or modifications not explicitly approved by the partyresponsible for compliance could void the user's authority tooperate this equipment.

Note: this equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 and part 18 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and canradiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference toradio or television reception, which can be determined by turning the equipment off and on, the user is encouraged totry to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.

This device complies with Part 18 of the FCC Rules. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

● Increase the separation between the equipment and any other radio device.
● Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.