MAGIC SNAPSHOT

TRIPOD
SELFIE STICK



Use instructions
0th-AB402

Magic Snapshot Instructions

Switch on and off

Fix mobile phone and press the photo button for 2 seconds , the Bluetooth mode is ready when green light flashes; Search and connect the "SEAJIC", Green light flashes when paired successfully ; press the photo button of the selfie pole to take pictures.

Magic Snapshot Instructions

Remote control separation instructions

1



Pull up the support and pull the lever.

Magic Snapshot Instructions

Remote control separation instructions

2



Take out the Bluetooth remote control, and take pictures with the control remote control.

Magic Snapshot Instructions

Remote control separation instructions

3



Place the remote control in the slot as shown above.

Magic Snapshot Instructions

Remote control separation instructions

4

Place the remote control in the slot as shown above.

Magic Snapshot Instructions

Instructions for selfie stick operation

1



From back side of the Product, rotate cellphone bracket upward till 90°to Selfie Stick.

Magic Snapshot Instructions

Instructions for selfie stick operation

2



Horizontally rotate cellphone bracket to front side of the Product.

Magic Snapshot Instructions

Instructions for selfie stick operation

3



Pull up the support and pull the lever.

Magic Snapshot Instructions

Instructions for selfie stick operation

4



Pull up the foot cushion on the support.

Magic Snapshot Instructions

Instructions for selfie stick operation

5

Push into the mobile phone.

Magic Snapshot Instructions

Instructions for selfie stick operation

6

Extend the tripod from bottom of the Selfie Stick, take selfies under tripod mode.

Magic Snapshot Instructions

Horizontal vertical screen switching instructions

1



Adjust the angle of the cell phone holder perpendicular to the rod degree.

Magic Snapshot Instructions

Horizontal vertical screen switching instructions

2



Lift cellphone bracket and rotate to appropriate angle.

Magic Snapshot Instructions

Horizontal vertical screen switching instructions

3

Push into the mobile phone.

FCC Requirement

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.