TROUBLESHOOTING

No power	Recharge your Star Studio speaker using the included micro USB cable. Try using a different cable.
Music is not playing over Bluetooth®	Make sure your Bluetooth® device has A2DP profile. Check if both devices are paired and connected over Bluetooth®. Restart the speaker to reconnect your Bluetooth® device.
Bluetooth® **device will not reconnect with the speaker**	Navigate to your Bluetooth® settings menu on your Bluetooth® device, tap "**UZ S057B**" and select "**Forget**" Now follow the steps to pair your device again.

SPECS

Speaker Specifications:
Output Power: 6W
Frequency Response: 20HZ~20KHZ
Dimensions (WxHxD): 8.5 x 16.5 x 7 in

Additional Connection Sources:
Audio: 3.5mm AUX cable
Power Source: Built-in rechargeable battery or via USB cable

Power Information:
Input: DC5V
Battery Capacity: 1200mAH
Music playing time: Up to 4 Hours*
Charging time: 3 hours

Bluetooth® Information:
Bluetooth® Version: 5.0
Operating Distance: 30ft.
System Requirements: Bluetooth®-capable device

*Depends on individual use and may be slightly more or less than the time specified.

Technical Support:
Please do not attempt to fix the product by yourself. If you are experiencing any problems with the product, please do not return it to the store you bought it from. You can contact our technical support representatives and they will assist you with any questions you might have. For assistance operating your product, please consult the User's Manual first, then feel free to contact Merkury Innovations technical support:

Merkury Innovations
45 Broadway, 3rd Floor
New York, New York 10006
www.merkuryinnovations.com
support@merkuryinnovations.com

This device complies with Part 15 of the FCC Rules. Operation is subject to the two following conditions:
1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

©2020 Merkury Innovations, LLC.
To explore our full selection of products, visit us at: www.merkuryinnovations.com

Bluetooth® is a registered trademark of Bluetooth SIG, Inc. The illustrated product and specifications may differ slightly from those supplied. All other trademarks and trade names are those of their respective owners.
Made in China

STAR studio
XL Wireless Karaoke Speaker

USER'S MANUAL FOR WIRELESS LED SPEAKER WITH MICROPHONE

REMOTE CONTROL

1. Standby Mode On/Off
2. Select Mode (BT/FM/AUX)
3. Mute
4. Play/Pause or Channel Scan (FM Mode)
5. Previous Track or Channel Search Back (FM Mode)
6. Skip Track or Channel Search Next (FM Mode)
7. EQ adjustment
8. Volume Decrease
9. Volume Increase
10. Repeat Track
11. USB/SD Mode
12. 0-9 Preset channels saved in system (FM Mode)



CHARGE

- Plug the micro USB cable into the micro USB port on the back of the speaker, and connect the other end of the cable with any compatible charger or wall outlet.
- When charging, the small LED indicator will glow red. When fully charged, the LED indicator will turn off.
- Charging time is approximately 3 hours.

TURN ON & OFF

- Turn the Power knob clockwise to power the speaker ON , a tone will be heard and the speaker will enter Bluetooth® mode.
- Turn knob counterclockwise fully to power OFF.

PAIR & CONNECT

- Make sure the speaker is turned off and your device's Bluetooth® setting is activated.
- Turn the speaker on; after a few seconds it will automatically enter into pairing mode and the LED will flash.
- On your Bluetooth® enabled device, navigate to the Bluetooth® settings menu, turn on the Bluetooth® feature, and search for new devices.
- Wait a few seconds and select "**UZ S057B**" The speaker will emit a tone when successfully paired.

NOTE: If your device's Bluetooth® version is below version 2.1, you may need to enter the password "**0000.**"
AUX-IN: When insert the AUX cable, you can switch the mode through the remote control or tape the MODE button on the speaker
NOTE: Insert a USB thumb drive or Micro SD card for direct music playback.

PLAY

- Connect your device to the speaker via Bluetooth® (see "Pair & Connect with a New Device").
- Open your favorite music app and press play.
- Control the music, track and volume from your device, or control them from the controls on the speaker.
- Adjusting Volume : Adjust the volume using the volume knob on the speaker or through your device.
- Press the "▶II" button to play/pause music.
- Press the "⏮" or "⏭" button to skip to the next/previous track.
- All audio, including music, games, videos, and notifications will be routed through the speaker.

RECONNECT TO BLUETOOTH®

- You only need to pair your Bluetooth® device with the speaker once.
- With your previously paired device's Bluetooth® turned on and in range, power on the speaker.
- The speaker will automatically reconnect to the last Bluetooth® device it was connected to.
- If you have a previously paired device that does not auto-reconnect, navigate to the Bluetooth® settings menu on your device, turn on the Bluetooth® feature, and select "**UZ S057B**" from your list of paired Bluetooth® devices and select "**Forget.**" Repeat Pair & Connect steps stated above.

CONTROL AND PORTS (BACK OF SPEAKER)



1. **POWER / VOLUME**
2. **LED INDICATOR LIGHT**
3. **DC 5V CHARGING PORT**
4. **AUX IN**
5. **MODE SELECT (BT/FM/AUX)**
   Press & hold to turn LED on/off
6. **NEXT TRACK**
7. **PLAY/PAUSE**
   Long press for TWS connection
8. **PREVIOUS TRACK**
9. **DIGITAL DISPLAY**
10. **Micro SD PORT**
    Speaker will switch to micro SD card mode when a micro card is detected.
11. **USB PORT**
    Speaker will switch to USB mode when a USB drive is detected.
12. **ECHO VOLUME**
13. **MIC. VOLUME**
14. **MICROPHONE PORT**
    To use a microphone, insert the microphone jack into the microphone port, the speaker will automatically adjust to microphone mode.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

FCC ID: 2AS5O-UZS057B

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment