尺寸：7x10cm

pom Peace of Mind

AI TRANSLATION

SONICORE User Manual

Important Safety Guidelines

• Read this manual carefully before first use and keep it for future reference.
• Keep batteries and earphones out of reach of children.
• Do not heat, open, or dispose of the battery in fire.
• Avoid moisture, excessive heat, or direct sunlight.
• Use only certified or provided charging accessories.
• Do not allow metal objects to touch the charging contacts.
• Clean the device with a soft, dry cloth. Do not use chemicals or water.
• Do not use a high-current charger to avoid damage to the cable or device.

Product Specifications

Bluetooth version: 6.0
Bluetooth Frequency Range: 2402 – 2480 MHz
Frequency response: 20Hz – 20 kHz
Speaker size: 10mm
Effective range: up to 10m
Earbud battery capacity: 30 mAh
Charging case capacity: 200 mAh
Play time: 4 – 5 hours
Charging time: 2 hours
Number of earbud recharges (from case): 2 times
Case input: USB-C
Earbud dimensions: 19 x 29 x 24 mm
Charging case dimensions: 58 x 46 x 25 mm

Functions & Usage

Power On
• Method 1: Remove earbuds from charging case — they turn on automatically.
• Method 2: Press and hold the touch area on each earbud for 3 seconds.

Power Off
• Method 1: Place the earbuds back into the charging case — they power off automatically.
• Method 2: Long-press the touch area on each earbud for 5 seconds.
• Method 3: The earbuds will turn off automatically if without connection within 3mins.

Bluetooth Pairing
1. Open the charging case. The earbuds will power on, sync, and enter pairing mode automatically.
2. On your smart device, open Bluetooth settings and select "**SP150Ai**".
3. The earbuds will connect automatically next time when removed from the case.

Note: If the earbuds do not sync or connect properly, place both earbuds back in the charging case, close the lid, wait 5 seconds, and reopen.

Touch Control Functions

Music Mode
• Play/Pause: Single tap either earbud.
• Previous Track: Double-tap left earbud.
• Next Track: Double-tap right earbud.
• Volume –: Triple-tap left earbud.
• Volume +: Triple-tap right earbud.

Call Management
• Answer Call: Single tap either earbud.
• Hang Up: Single tap again.
• Reject Call: Press and hold either earbud for 2 seconds.

Voice Assistant
• Press and hold either earbud for 2 seconds to activate the voice assistant (Siri/Google Assistant).

Charging & Indicators

Charging the Case
• Connect the included Type-C cable to the charging port and a USB power source.
• The display flashes while charging.
• Once fully charged, the display shows 100%.

Charging the Earbuds
• Place earbuds into the charging case.
• The red indicator light turns on while charging and turns off once fully charged.
• When charging, the display shows "L" or "R" with a flowing light effect.
• When the earbuds' battery is low, a tone will sound and the indicator flashes every 5 seconds.

Factory Reset

• While earbuds are powered on and not connected, tap the touch area on both earbuds 5 times to clear pairing records.

Package Contents

• 1 × Pair of TWS Earphones
• 1 × USB Type-C Charging Cable
• 2 × Eartips(S+L)
• 1 × Instruction Manual

AI APP Connection DanaMate

Download APP

Scan the QR code below with your mobile device to access the Apple App Store or Android App Store and download the "Dana Mate" APP .

App Store Google Play

Operation Guide

Scan the QR code below to view the "Operation Guide", or click on the "Operation Guide" in the upper right corner of the APP's homepage for more details.

Bind Device

Log in Dana Mate App via your email and it will show your device successfully bound.

1. Enable Bluetooth and pair with the headphones

2. Log in via your email



3. Your device will be successfully bound

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
--Reorient or relocate the receiving antenna.
--Increase the separation between the device and receiver.
--Connect the device into an outlet on a circuit different from that to which the receiver is connected.
--Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation

RF warning for portable device:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2AS7V-SP150-AP150