Bluetooth Headphones

H033C

User Manual

Thank you for purchasing our products. This manual addresses the safety guidelines, warranty and operating instructions.
Please review this manual thoroughly before operating your device.

CONTENTS

English Version 1/16
French version 17/34
Español Version 35/52
Deutsche Version 53/70

Package Contents

① Bluetooth headphones × 1
② USB cable × 1
③ 3.5mm audio cable × 1
④ Carry case × 1
⑤ User manual × 1



At a Glance



LED Indicator Guide

- Power on: LED indicator flashes blue for one second
- Power off: LED indicator flashes red for 2 seconds
- Pairing mode: LED indicator flashes red and blue alternately
- Paired: LED indicator flashes blue twice every 5 seconds
- Low battery: LED indicator flashes red with a voice prompt
- Charging: LED indicator stays red during charging and goes off when the headphones are fully charged

Using the Headphones

Charge the headphones

1) Plug the small end of the USB cable into the Micro USB port on the right earcup.
2) Plug the other end into a USB wall charger or computer (DC 5V) that is powered on.



Notes:

- Fully charge the headphones before using them for the first time.
- The LED indicator stays red during charging and goes off when the headphones are fully charged.
- The indicator flashes red, and a voice reminder prompts when the headphones are in low battery.

Power on/off

- Power on: Press and hold the MFB button for 3 seconds.
- Power off: Press and hold the MFB button for 3 seconds when the headphones are on.

Pair

1) Turn on the Bluetooth of your phone or other Bluetooth devices.
2) Turn on the headphones, and the headphones enter pairing mode (indicator flashes red and blue alternately).
3) In the list of found Bluetooth devices in your phone or other Bluetooth devices, choose "H033C" to pair.



4) Enter "0000" or "1234" if your phone or Bluetooth device asks you to enter a code to pair.

Notes:

- When the headphones are on but are not paired with your phone or other Bluetooth devices, they will be automatically off in about 5 minutes (to have them enter pairing mode again, turn on the headphones).
- The headphones will directly enter pairing mode the first time you turn them on, and they will connect to the last paired Bluetooth device automatically when turned on.
- To have the headphones enter the pairing mode when the headphones have been paired with a Bluetooth device, turn off the headphones and press and hold the MFB button for 5 seconds (indicator flashes red and blue alternately).

Headphone functions

Function	What to do
Play/Pause	Press the MFB button
Next track	Press and hold the "+" button for 2 seconds
Previous track	Press and hold the "–" button for 2 seconds
Volume up	Press the "+" button
Volume down	Press the "–" button
Voice Assistant Activation/Deactivation	Press and hold the MFB button for 2 seconds

Call functions

Function	What to do
Answer/end a call	Press the MFB button
Decline an incoming call	Double-press the MFB button
Redial the last number	Double-press the MFB button

ANC function

Slide the ANC Button up/down to activate/deactivate the noise cancellation function. Its green indicator will turn on/off accordingly.



Note:

When the battery is low (the green ANC indicator flashes), the ANC function is not available.

Connect the audio cable

Use the 3.5 mm cable (provided) to connect a non-wireless device or to continue using the headphones if the battery charge is depleted.

1) Insert the cable into the audio port on the left earcup.

2) Insert the other end of the cable into the audio port on your device.

Notes:

- The headphones do not use the internal battery (headphones are off) when you use the audio cable to listen.
- The headphones will not charge when you use the audio cable to listen.

Reset the headphones/Clear all pairing information on the headphones

Press and hold the "+" and "–" button at the same time for 6 seconds when the headphones are being charged (the indicator flashes blue three times).

Care and Maintenance

Store your headphones

The earcups fold for easy, convenient storage. Place the headphones into the case.

Fold both earcups up toward the headband.



Notes:

- Make sure to power off the headphones when not in use.
- Before storing the headphones for more than a few months, make sure the battery is fully charged.

Clean the headphones

Your headphones may require periodic cleaning.

Fold both earcups up toward the headband.

- Wipe the outside surfaces with a soft, dry cloth.
- Don't allow moisture to get inside the earcups or the audio input port.

FAQs

Q: I paired the headphones with my phone before, but I failed to pair them to my phone again.

A: 1) Turn on the Bluetooth of your phone and in "MY DEVICES", choose "H033C" and tap "ⓘ"→"Forget This Device".
2) Turn off the headphones.
3) Reset the headphones.
4) Pair the headphones with your phone again following the instructions in the previous part "Pair".

Q: I paired the headphones with my phone, but there is no sound from the headphones.

A:
- Power on the headphones and charge the battery.
- Make sure the headphones/phone are/is not muted.
- Some phones ask for the setup of the wireless headphones as an audio output device before the sound is transmitted. Please refer to the instructions of your phone for details.
- Move your phone closer to the headphones and away from any interference or obstructions.
- Use a different music source.
- If you use a music player or other devices, please make sure it supports A2DP stereo music profile.

Q: Sound is not stable and consistent?

A: Make sure your headphones stay close to your phone (not away from your phone more than 33 feet, no obstacles between, and no radio or Wi-Fi interference nearby).

Q: My headphones will not switch on.

A: Please recharge the headphones and make sure they have enough battery power. If they are fully charged and still nothing happens or if you are not able to charge the unit, please contact our customer support for further information.

Specifications

Bluetooth Standard: V4.1

Wireless Profile: A2DP, HFP, HSP, AVRCP

Operating Range: 33 feet/10 meters (No obstacles between)

Charging Time: 2-3 hours

Talk/Play Time:
- About 25 hours with ANC off
  (Varies according to volume level and audio content)
- About 10 hours with ANC on
  (Varies according to volume level and audio content)

Charging Voltage: DC 5V

Charging Current: 5V 500mA

Battery Capacity: 500mAh/3.7V

Attention

Use original or certified cables.

Don't expose to liquids.

Don't disassemble.

Avoid dropping.

Avoid extreme temperatures.

SAFETY AND WARRANTY

Important Safety Instructions

- Use of headphones will impair your ability to hear other sounds. Use caution while using your headphones when you are engaging in any activity that requires your full attention.
- If you have a pacemaker or other electrical medical devices, you should consult your physician before using this product.
- This package contains small parts that may be hazardous to children and should be kept out of reach from children. This product is not a toy – never allow children to play with this product. Always store the product out of reach from children. The bags themselves or the many small parts they contain may cause choking if ingested.
- Never try to dismantle the product yourself, or push objects of any kind into the products, as this may cause short circuits which could result in a fire or electric shock.
- None of the components can be replaced or repaired by users. Only authorized dealers or service centers may open the product. If any parts of your product require replacement for any reason, including normal wear and tear or breakage, please contact us.
- Avoid exposing your product to heat and humidity to protect against damage to the product or injury to you.
- Keep all products, cords, and cables away from operating machinery.

- If the product overheats, if the product has been dropped or damaged, if the product has a damaged cord or plug, or if the product has been dropped in a liquid, discontinue use and contact us.
- Do NOT use in areas where there are explosive hazards.
- Do NOT submerge the headphones in water. Do NOT expose the headphones to moving water (e.g., from a faucet, etc.).
- Do NOT wear the headphones while showering or bathing, or when participating in water sports, e.g., swimming, waterskiing, surfing, etc.
- This product contains magnetic material. Consult your physician on whether this might affect your implantable medical device.
- Leaving the product in hot or cold places, such as in a closed car in the summer and winter conditions, will reduce the capacity and lifetime of the headphones.
- Dispose of the product according to local standards and regulations.
- **Remember:** Always drive safely, avoid distractions and follow local laws!

  Using the headphones while operating a motor vehicle, motorcycle, watercraft or bicycle may be dangerous, and is illegal in some jurisdictions, just as use of the headphones with both ears covered while driving is not permitted in certain jurisdictions. Check your local laws. Use caution while using your headphones when you are engaging in any activity that requires your full attention. While engaging in any such activity, removing the headphones from your ear or turning off your headphones will keep you from being distracted, so as to avoid accident or injury. Do not take notes or read documents while driving.

WARRANTY

We strive to build our products with the highest attention to detail and craftsmanship. However, sometimes there are occurrences of defect.

We are happy to offer 1-year hassle-free warranty to all our products as we continue to make amazing wireless product. Please contact us if you have any questions about our devices.

Model No.(Model: H033C)
FCC ID(FCC ID: 2AS8H-H033C)

"RCA is a trademark of Voxx International Corporation or its affiliates used under license by Number One Commerce Co., LTD."

Please contact customer service for questions/comments, warranty, support or service related to the product on the website www.supportrca.com

Email: service@supportrca.com
https://www.rcaaudiovideo.com/audio

Made in China

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.