MODEL# LY0204A

MINI FRIDGE

& WIRELESS SPEAKER COMBO

HOLDS 6 CANS

Read this manual thoroughly
before using and save it for
future reference.

All rights reserved. No portion of this manual may be reproduced by any means whatsoever without written permission from The Steelstone Group, except for the inclusion of quotations in a media review.

Although every precaution has been taken in the preparation of this manual, The Steelstone Group assumes no responsibility for errors or omissions. Nor is any liability assumed for damages resulting from the use of the information contained herein. Although every effort has been made to ensure that the information contained in this manual is complete and accurate, The Steelstone Group is not engaged in rendering professional advice or services to the individual consumer, further, The Steelstone Group shall not be held responsible for any loss or damage allegedly arising from any information or suggestion in this manual.

BRING OUT THE COOL TUNES.

What goes well with parties and company? The latest jams and hottest songs. Rethink chill hour with Gourmia's loudest cooler—the Wireless Speaker & Mini Fridge. With both hot and cold functions, it lets you rock out and dig in all in one.

This thermoelectric powerhouse serves multiple purposes, chilling up to 6 individual 12-ounce cans or keeping food and beverages warm with the flip of a switch.

Just load contents into the chamber, plug into any wall or car outlet, and pair with a Bluetooth-compatible device to rock and refresh your journey. From condo to camper to office to dorm—never drink in silence again!

Thank you for your purchase! We hope you will enjoy all the innovative products brought to you by Gourmia.

TABLE OF CONTENTS

Safety First 6

Using The Thermoelectric Mini Fridge 7

Pairing Your Device 8

Storage and Disposal 9

Warranty and Service 10

IMPORTANT SAFEGUARDS

Disclaimer:

Read these instructions carefully even if you are familiar with the equipment. Following these important safety rules and operation guidelines will reduce the risk of fire, electric shock and injury. Manufacturer/importer advisory board are not responsible for improper use due to instruction manual negligence or failure to follow directions. Before starting up the machine, ensure you are in compliance with all the basic safety precautions included in this user's manual. It is important to understand the equipment's proper usage and limitations in order to avoid potential dangers.

READ ALL SAFETY & USAGE INSTRUCTIONS BEFORE USING

- Keep this out of reach of children or unqualified persons, since the misuse of contents and packaging materials may result in hazard or death.
- When alternating between COLD and HOT functions, turn the switch to OFF first. After 5 minutes, turn it to COLD or HOT.
- When the cooler / warmer is in it's HOT function, use care when handling hot items to avoid burns.
- When using in a car, it is preferred to pull the plug out of the cigarette lighter when the car is stopped and shut off.
- Keep fan free of obstructions to keep it from getting jammed.

THIS EQUIPMENT COMPLIES WITH FCC RADIATION EXPOSURE LIMITS SET FORTH FOR AN UNCONTROLLED ENVIRONMENT. THIS EQUIPMENT SHOULD BE INSTALLED AND OPERATED WITH MINIMUM DISTANCE 20CM BETWEEN THE RADIATOR & YOUR BODY.

KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE!

CAUTION: ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

NOTE: THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS B DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES. THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE IN A RESIDENTIAL INSTALLATION. THIS EQUIPMENT GENERATES, USES AND CAN RADIATE RADIO FREQUENCY ENERGY AND, IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTIONS, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS. HOWEVER, THERE IS NO GUARANTEE THAT INTERFERENCE WILL NOT OCCUR IN A PARTICULAR INSTALLATION. IF THIS EQUIPMENT DOES CAUSE HARMFUL INTERFERENCE TO RADIO OR TELEVISION RECEPTION, WHICH CAN BE DETERMINED BY TURNING THE EQUIPMENT OFF AND ON, THE USER IS ENCOURAGED TO TRY TO CORRECT THE INTERFERENCE BY ONE OR MORE OF THE FOLLOWING MEASURES:

—REORIENT OR RELOCATE THE RECEIVING ANTENNA.
—INCREASE THE SEPARATION BETWEEN THE EQUIPMENT AND RECEIVER.
—CONNECT THE EQUIPMENT INTO AN OUTLET ON A CIRCUIT DIFFERENT FROM THAT TO WHICH THE RECEIVER IS CONNECTED.
—CONSULT THE DEALER OR AN EXPERIENCED RADIO/TV TECHNICIAN FOR HELP.

THERMOELECTRIC MINI FRIDGE OPERATING INSTRUCTIONS

Operating voltage: 12V DC or 120V AC

- When using your cooler / warmer in a car, you can plug it into the cigarette lighter socket, or connect it to a 12V storage battery. When using it at home or at the office, you can plug it into a wall outlet. Before operating, first connect the cord into the socket of the cooler / warmer, then connect the other end into the power outlet.
- Once plugged in, you can then slide the switch to COLD or HOT function.
- Turn the switch to **COLD** for cooling mode. The green LED light will illuminate.
- Turn the switch to **HOT** for warming mode. The red LED light will illuminate.
- Turn the switch to **OFF**. Cooler/warmer will function as an insulated box.
- For best results when cooling or heating items, refrigerate items before placing in cooler on cooling mode, or heat items before putting in warming mode.

PAIRING YOUR DEVICE

- On the back of the fridge, flip the Bluetooth switch to the ON position.
- The fridge will say "The Bluetooth device is ready" indicating that is ready to pair with your phone or tablet.
- Go to the Bluetooth setting on your phone/tablet and search the device list for "Bluetooth". Click on it to pair. **SEE IMAGE.**
- When the fridge pairs with your phone/tablet it will say "The Bluetooth device is paired". You are now ready to enjoy the convenience of your Bluetooth speaker.
- Use the volume control on your phone/tablet to control the volume of the speaker.



Bluetooth

Now discoverable as "John's iPhone".

MY DEVICES

Headphones Connected

My Car Not Connected

Bluetooth Connected

STORAGE & DISPOSAL

- Store the appliance in a cool, dry and clean place, out of the reach of children and pets.
- Please keep the packaging for transporting the appliance or for storing your appliance when not in use for a prolonged period of time.
- This product may not be disposed of along with ordinary household waste, as electrical and electronic waste must be disposed of separately.
- Contact your retailer, distributor or the municipal authorities for further information on product disposal.

WARRANTY & SERVICE

This Limited Warranty is for one full year from the date of purchase. It is applicable to the original purchaser only and is not transferable to a third party user. Repair or replacement of defective parts is solely at the seller's discretion. In the event that the repair isn't possible, the seller will replace the product/part. If product repair/replacement won't suffice, the seller has the option of refunding the cash value of the product or component returned.

Product defects not covered under the Warranty provisions include normal wear and damage incurred from use or accidental negligence, misuse of instruction specifications or repair by unauthorized parties. The manufacturing company is not liable for any incidental or consequential damages incurred by such circumstances.

SHAOXING SHANGYU NORTH ELECTRON MANUFACTURE CO.LTD
YUEXIE ROAD SHANGYU ZHEJIANG CHINA
TEL: 86 575 82719923   FAX: 86 575 82031758