LEtC

User Manual for BrightEye

How to Install APP

Step 1 :

Please search the APP named "BrightEye" in "Google Play Store" or "Apple Store" according to the OS of your cell phone.

Step 2 :

Click the install button. Wait for downloading APP till completed.

How to Connect the Device

Step 1 :

Open the APP
and press "Add" or "+" on
the screen.

Step 2 :

If the device is not connected to the router yet, please select "Add device unconnected router" first. Otherwise, please select "Add device connected router."



Step 3 :

Press "OK" to select WiFi for device connection. The WiFi name will be "Video_Doorbell_xxxxx."
Press "DONE" after you finish it.



Step 4 :

After WiFi connection, the device UID will be shown in the APP. Please input the default password "888888" and press "Add" to complete the connection.



Step 5 :

If you want to set up the device connected to your router, press " OK." Otherwise, press "Cancel." Please see "How to Connect Device to Router" for more details.



Step 6 :

When the connection is completed, you will see the device name in your APP. Select the device name, then you will see the camera image.



How to Connect Device to Router

Step 1 :

After you press "Add" button, the APP will ask you to set up device to router or not. Please press "OK" to set up.

Step 2 :

Choose the WiFi router of your company or home and input the router password. The APP will connect to the router automatically.









How to set timezone

Step 1 :

Press "Setting ⚙ "
on the Upper right corner



Step 2 :

Find & Press
"Sync Timezone"

Step 3 :

Select your Timezone



Icon Description



APP Version

Add new device

Back

Setting

Voice from phone to device

Record image and save it in the phone

Snapshot image and save it in the phone

Lighting control

Read album from phone or SD Card

Image resolution

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

. Reorient or relocate the receiving antenna.
. Increase the separation between the equipment and receiver.
. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
. Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

NCC警語 - 低功率射頻電機：
「依據低功率電波輻射性電機管理辦法」
第十二條 經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。
第十四條 低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。
前項合法通信，指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。」