TW13

使用说明书

产品外观



A. 充电触点
B. 触摸部位
C. 麦克风
D. 数显屏
E. 充电口

产品规格

- 蓝牙版本：5.0
- 通话时间：2H
- 待机时间：120天
- 耳机充电时间：60分钟
- 耳机电池容量：40mAh
- 充电电压：DC 5V
- 信号距离：10-15米
- 听歌时间：4.5小时
- 频率响应：20-20000Hz
- 座充电池容量：300mAh

1

产品使用

如耳机丢失组队，将左右耳机开机，
未连接手机状态下，双击右耳进行手动配对。

1、开机
充电仓翻盖自动开机，或手动长按3秒开机，开机后灯闪2次后红蓝灯熄灭。
（注：如充电仓长时间在待机状态下会造成充电仓没电，但耳机还是可以正常使用，只需手动开机，如担心误这种情况，长按耳机3秒开机即可）

2、关机
放入充电仓后会重叠自动关机，也可手动长按耳机3秒关机，关机灯灯闪三下。
（当设备无连接，3分钟后自动关机）

3、蓝牙连接
开机后自动进入配对模式，从手机蓝牙列表中找到相应的蓝牙配对名“TWS”点击连接配对，约3秒语音提示连接成功，手机连接成功后灭灯。

2

4、充电指示
充电仓充电时，数码屏闪烁电量显示。
耳机充电时，耳机红灯长亮，充满全部灯熄灭。

5、通话模式
当来电，勾手机铃声响起，单击任意耳机接听电话，通话过程中单击任意耳机挂断，
当来电时长按2S：拒接。

6、功能定义
单击：播放/暂停,接听/挂断
双击：左耳双击上一曲，右耳双击下一曲
三击：左耳三击音量减，右耳三击音量加
长按3秒：唤醒语音助手。

3

安全信息

在使用和操作设备前，请阅读并遵守下面的注意事项，以确保设备性能最佳。并避免出现危险或非法情况。

电子设备

●有明文规定禁止使用无线设备的场所，请勿使用本设备,否则会干扰其它电子设备或导致其它危险。

对医疗设备的影响

●有明文规定禁止使用无线设备的医疗和保健场所，请遵守该场所的规定，并关闭设备。
●设备产生的无线电波可能会影响植入式医疗设备或个人医用设备的正常工作，如起搏器、植入耳蜗、助听器等。若您使用了这些医用设备，请向其制造商咨询使用本设备的可能性。
●切勿将本设备对，请与植入的医疗设备(如起搏器、植入耳蜗等)保持至少15厘米的距离。

听力保护

●当您使用耳机收听音乐或通话时，建议您用音乐或通话所需的最小音量，以免损伤听力。长时间接触高音量可能会导致永久性听力损伤。
●若在可接触高音量可能会分散注意力,从而导致事故。

操作环境

●请勿在本机、耳塞、充电盒或其他部件内使用设备，以免引起设备内部电路故障。
●安饺设备时，请远离具有强磁场或强电场的电器，如微波炉、电冰箱等。
●请勿在雷雨天气使用本设备，雷雨天气可能会导致设备故障或电击危险。
●请在温度-10℃~55℃范围内使用本设备，并在温度-40℃~+70℃范围内存放设备及其配件。当环境温度过高或过低时，可能会引起设备故障。
环境温度低于5℃时，电池的性能会受到限制。
●请将该设备放置在阳光直射的地方,如汽车仪表盘或窗台处。

4

●请勿将设备靠近热源或明火源,如电暖器、微波炉、烤箱、热水器、炉火、蜡烛或其他可能产生明火的地方。
●请勿将大头针等尖锐金属物品放置在设备听筒或音扬声器附近，以免金属物品刺着，对您造成伤害。

儿童健康

●本设备及其配件可能包含一些小零件，请将设备及其配件放置在儿童接触不到的地方。儿童可能在无意之中损坏本设备及其配件，或吞下小零件导致窒息或其他危险。
●本设备并非玩具，儿童应在成人监护下使用本设备。

电池安全

请勿拆解或改装电池、插入异物、或浸入水或其它液体中，以免引起电池漏液、过热、起火或爆炸。
●请勿挤压、刺压或保刺电池。避免让电池遭受外部大的压力，从而导致电池内部短路和过热。
本设备配有不可拆卸的内置电池。请勿自行更换电池。以免损坏电池或设备。
●请按当地规定处理电池，不可将电池作为生活垃圾处理。若电池处置不当可能会导致电池爆炸。

充电器安全

●设备充电时，电源插座应安装在设备附近并应易于触及。
●当充电完毕或者不充电时，请断开充电器与设备的连接并从电源插座上拔掉充电器。

环境保护

●请勿将本设备及其附件作为普通的生活垃圾处理。
●请遵守本设备及其附件处置的本地法令，并支持回收行动。

5

使用注意事项

1. 耳机需存放在干燥通风环境下，避免污油、水汽、其汽、潮湿和灰尘等接触，以免影响产品性能。
2. 避免使用刺激的有机溶剂或含有这些成分的物品清洁耳机。
3. 耳机需按照要求正确规范的使用，注意使用环境对耳机的影响，为保证连接顺畅，请位于手机和耳机之间的距离在10米范围内。
4. 如耳机无法连接不上或通讯不畅等其他问题，请咨询品牌经销商耳机本体及配件，否则不予保修。
5. 检耳机充电，请选用标配的车载充电器本公司指定的符合要求的充电器。
6. 为保证您正常使用耳机，请确保耳机的电量充足，并使用USB数据线配套给本产品充电。

保修服务

A.在正常使用本产品过程中，如果本产品出现任何人为损坏的性能故障，自购买之日起，消费者享受免费保修服务，保修期为12个月

B.有下列情况之一，消费者不能享受免费保修权益：
①人为损坏。
②超过保修期。
③不能提供有效的购买凭证。
④未按说明书要求使用、维护、保养而造成产品损坏。
⑤未经授权，擅自拆装、维修产品或产品改水。

6

保修卡

保修卡编号 _____
用户姓名 _____
用户电话 _____
用户地址（含邮编） _____
购机日期 _____
发票编码 _____
销售单位名称 _____
销售单位地址（含邮编） _____
销售单位电话 _____

合格证

产品型号	
检验员	
日　期	

包装明细

● 无线耳机 ● USB充电线 ● 耳机充电仓 ● 使用说明书

7

TW13

User Manual

Appearance



A. Charging Contactor
B. Touching Area
C. Microphone
D. Digital LED Display
E. Charging port

Product Specification:

- Bluetooth Version: V5.0
- Stand-by time: 120 days
- Talk time: 2 hours
- Charging time: 60 mins
- Battery capacity: 40 mAh
- Charging voltage: DC 5V
- Transmission distance: 10m -15 m
- Frequency Response: 20-20000 Hz
- Charging case battery: 300 mAh
- Music playtime: 4.5 hours

1

Products Use:

If earphones lose pairing function, let earphones power on—>Turn off the Bluetooth on the device—->Double touch right earphone to get them paired manually.

1.Power on
Open case, the earphone will power on automatically. Or manually press the button within 3 seconds, the blue light flashes 2 times, then red/blue light flashing to power on. (If the charging box standby for a long time it will default without power, but the earphones still with with power, just press the earphones around 3 seconds, then it will power on)

2. Power off
The earphone will power off when putting it into the charging case with lid closed. Or manually press the "power" button for 5 seconds to turn it off.
(If earphone not connected, it will automatically power off after 3 minutes)

3.Bluetooth pairing
After the earphones power on, will be in auto pairing mode. Open the device and find Bluetooth "TWS"to connect and pair, it will pair successfully within 3 seconds with an indication sound to show it connected.

2

4.Charging indication
When charging the charging case, the digital LED screen shows the power status.
When the earphone is under charging, red light will stay on and go out when full charged.

5.Phone call mode
When a call comes in, synchronize with the phone's ringtone, touch any earphone to answer the call, touch any earphone to hang up during the call.When a call comes in, long press 2S: reject the call.

6. How to use the earphone?
~Single-touch left or right earphone : Play/Pause, Answer/Hang up
~Double-touch: Left earphone ~~>skip back, right earphone~~>skip forward
~Triple-touch: Left earphone ~~>volume down, right earphone ~~>volume up
~Long press left or right earphone 3 seconds: Activate Siri

3

Safety Information

Before using and operating the earphones, please read and follow the below precautions to ensure the best performance of it and to avoid dangerous or illegal situations.

Electronic Devices

- Do not use this device in the place where wireless devices are prohibited, otherwise it will interfere with other electronic devices or cause other dangers.

Medical equipment interference

- In medical and health care places where the use of wireless devices is prohibited, please follow the rules and turn off the device.
- The radio waves generated by the device may affect the normal operation of implanted medical devices or personal medical devices, such as pacemakers, cochlear implants, hearing aids, etc. If you use these medical devices, please consult the manufacturer for restrictions on the use of this device.
- When using this device, please keep at least 15 cm away from implanted medical devices (such as pacemakers, cochlear implants, etc.)

Hearing Loss

- Listening to sound at high volume may permanently damage your hearing. When you use earphones to listen to music or calls, it is recommended to use the minimum volume required for music or calls to avoid hurting your hearing.
- Exposure to high-level volume while driving, driving attention may be distracted and cause accidents.

Operating environment

- Do not use the device in dusty, sharp, compact or near magnetic fields to avoid failure of the internal circuit of the device.
- When installing the device, please keep away from strong magnetic fields or electrical appliances with strong magnetic fields, such as ovens and refrigerators.
- Do not use the device in thunderstorm weather. Thunderstorm weather may cause equipment failure or electric shock hazard.
- Please use the device within a temperature range of -10 ° C ~ + 55 ° C, and store the device and its accessories within a temperature range of -40C ~ + 70 ° C. When the ambient temperature is too high or too low, it may cause device function failure. When the temperature is below 5 ° C, the performance of the battery is limited.

4

- Do not place the device in direct sunlight, such as the dashboard or window sill of a car.
- Do not place the device near heating sources or exposed fire sources, such as electric heaters, ovens, water heaters, stoves, candles, or other places that may generate high temperatures.
Do not place sharp metal objects such as pins near the device's earpiece or speaker, otherwise the metal objects may adhere and cause injury to you.

Child health

- This device and its accessories may contain some small parts. Keep the device and its accessories in a place out of children's reach. Children may inadvertently damage the device and its accessories, or swallow small parts, causing suffocation or other hazards.
- This device is not a toy, children should use this device under adult supervision.

Battery safety

Do not disassemble or modify the battery, or immerse in water or other liquids, to avoid battery leakage, excessive, fire or explosion.
- Do not drop, crush or puncture the battery. It can cause internal short circuits and overheating.
- This device is equipped with a non-removable built-in battery. Do not replace the battery yourself to avoid damage to the battery or device. The battery can only be replaced by Huawei Customer Service Center.

- Please dispose batteries in accordance with local regulations. Do not dispose batteries as household waste. Improper disposal of the battery may cause the battery to explode.

Charger safety

- When charging the device, the power socket should be installed near the device and should be easily accessible.
- When charging is completed or not charging, disconnect the charger from the device and unplug the charger from the power outlet.

Environmental protection

- Do not dispose this device and its accessories as ordinary household garbage.
- Please abide by the local laws and regulations on the handling of this device and its accessories, and support recycling operations.

5

Precautions:

1. The earphones should be stored in a dry/ventilated environment and avoid contacting with oil, water vapor, steam, moisture and dust to prevent the performance of the product.
2. Avoid using harsh organic solvents or items containing these ingredients to clean the earphones.
3. The earphones should be used correctly according to the requirements, and pay attention to the effect of the environment on the product. Make sure the connection is smooth and recommend a distance between them within 10 meters.
4. If the earphone failed to connect or with poor connection, please do not dismantle them or the accessories privately. Otherwise no warranty.
5. When charging the earphones, please use the standard car charger or the charger specified by our company.
6. To ensure the normal use of the earphones, please make sure they are fully charged.

Warranty Service:

A. During normal use of this product, if the product has non-artificially damage performance failure, From the date of the purchase, consumers enjoy a free warranty period with 12 months.
B. In one of the following circumstances, consumers cannot enjoy the free warranty benefits:
1. Artificially damage.
2. Exceeds the warranty period.
3. Cannot provide valid proof of purchase.
4. Failure to use and maintain the product in accordance with the instructions.
5. Unauthorized, dismantle or repair the products privately or product was soaked.
6. Other damage caused by force majeure.

6

Warranty Card

Warranty card number _____
User name _____
User phone _____
User address (including zip code) _____
Purchase date _____
Invoice number _____
Seller name _____
Seller address (including zip code) _____
Seller phone no. _____

Certificate

Product number	
Inspector	
Date	

Packing List

● Wireless earphones ● User manual ● USB charging cable ● Charging case

7

深圳恩乐实业有限公司产品说明书			
物料名称	TW13耳机说明书S-1.2	物料号码	307-BC-0863
工　艺	彩色印刷，风琴折页	日　期	2020-08-06
材　质	材质：105g铜版纸（双铜）	设　计	王金松
规　格	480mm*80mm	确　认	周　雄

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.