clingaura


Know yourself · Change yourself



Quick Guide

1.Device Description

① Box Content



② Removing The Strap And Charging Method

Light up Cling Aura ,press and hold HOME Key for 3 seconds or charge your device then read the instruction Cling ID for device activation.



2 Packing List

1 Cling Aura x1 2 Quick Grip x1

3 Introduction

① Introduction of Device Function interface

When the device is activated, the time interface is displayed by default, you can tap the Home key to switch between the following interfaces:



4 Software Download



Scan QR Code to Install Cling APP

5 Advanced Function Introduction

Note: Tap the Cling Aura 3 times from the home screen to navigate to the Advanced menu page. Touch and hold the Home key for 3 seconds to get to further function screens. Touch the screen briefly to switch between screens.

Tips:Function

① Manual Pressure Measurement

Before using the Blood Pressure Function,please note: It is essential that the wearer calibrates the Cling App using a Sphygmomanometer. Enter the Sphygmomanometer's values in the Cling App. Navigate to the Cling App and will go directly to the "Measuring" mode and calibrate itself.The screen display as 0/0 ... Once the calibration is completed the Blood Pressure reading will be shown on the Aura screen until the next calibration. Hold the Start key for approximately 30 seconds to complete a manual Blood Pressure Fluctuation reading.

6 Activation and Connection

Download the APP to many mobile phones, on the activation portal, select Cling Aura, then follow the APP instructions and discover Cling Aura devices. Select Cling Aura and click Bind. The device will vibrate on the screen and activate it, until you reach 100% - Binding Complete.

Note: the "pairing" prompt of the iOS phone pops up, be sure to allow pairing, Android phone choose to not set the pair.

7 Connection Considerations

1. Make sure the Bluetooth on your phone is turned on.
2. Make sure your phone is within 10 meters of the Cling Aura range below use.
3. Make sure the device is within the range of the phone's Bluetooth connection.
4. If Cling Aura shows a search failure under the Android system, please check the phone's Bluetooth settings and delete the Cling Aura from the phone's Bluetooth system.It is not required to operate GPS.
5. The Cling Aura waterproof rating is IP68, making it safe for use while swimming.

Note: Due to operation and connection do not wear the Aura during hot showers or saunas.

8 Advanced Function Introduction

Note:Tap the Cling Aura 3 times from the Home screen to navigate to the Advanced menu page. Touch and hold the Home key for 3 seconds to get to further function screens. Touch the screen briefly to switch between screens.

Tips:Blood Pressure Function Manual/ Automatic

① Manual Detection

Before using the Blood Pressure Function,please note: It is essential that the wearer calibrates the Cling App using a Sphygmomanometer. Enter the Sphygmomanometer's values in the Cling App. Navigate to the Cling App and will go directly to the "Measuring" mode and calibrate itself.The screen display as 0/0 ... Once the calibration is completed the Blood Pressure reading will be shown on the Aura screen until the next calibration. Hold the Start key for approximately 30 seconds to complete a manual Blood Pressure Fluctuation reading.

A: Method: The wearer is asked in order to achieve the best possible reading to keep their hand still and relaxed during the Blood Pressure fluctuation test while holding the Aura tighter than their hand.



② Automatic detection

Cling Aura will automatically detects Blood Pressure fluctuation 3 times per day. The default detection times are 8:00 AM, 14:00 PM and 20:00 PM.

Auto-detection only happens under quiet human behavior.This means that the wearer should not be moving around or talking during the detection process.

All devices below the Bluetooth will be turned off.

Note: This product is not a medical device and its accompanying data should only be used as a guide. Only a normally accurate device (like a Sphygmomanometer) should be used for medical purposes.

9 Outdoor Running / Cycling

Cling Aura supports the following two types of outdoor sports motion trajectory recording: Outdoor Running and Outdoor Cycling. Before the start of the exercise, wear the Aura screen, from the Advanced Page touch and hold the Home Key button for 3 seconds to go to the menu page. Switch to outdoors by clicking the Home Key for Running or Outdoor Cycling.



Regardless of whether or not Bluetooth is connected, go into the Movement function.



10 Call Rejection

Aura alerts the wearer at dates and times that the wearer enters into the Cling App Reminder. The wearer can also set the Call Rejection feature from the Cling App. When the wearer is engaged in a call, the Cling Aura will vibrate to remind the wearer and will receive medication completeness reports and medication inventory into the Cling App. The wearer can also set the Call Rejection feature in the Cling App.

Call delay reminder:Aura will vibrate to remind the wearer to answer the phone longer. For medication reminders not set medication reminder. If the wearer is in a call, the Cling Aura will vibrate to remind the wearer and will receive medication completeness reports and medication inventory into the Cling App. The wearer can also set the Call Rejection feature in the Cling App.



11 Medication Reminder

New function

Aura alerts the wearer at dates and times that the wearer enters into the Cling App Reminder. The wearer can also set the Call Rejection feature from the Cling App. When the wearer is engaged in a call, the Cling Aura will vibrate to remind the wearer and will receive medication completeness reports and medication inventory into the Cling App. The wearer can also set the Call Rejection feature in the Cling App.

Call delay reminder:Aura will vibrate to remind the wearer to answer the phone longer. For medication reminders not set medication reminder. If the wearer is in a call, the Cling Aura will vibrate to remind the wearer and will receive medication completeness reports and medication inventory into the Cling App. The wearer can also set the Call Rejection feature in the Cling App.



12 Gym Mode

The GYM Mode includes four sports modes: Treadmill, Elliptical, Stationary Bicycle and Aerobics. Each sports can be switched between the following interfaces: The wearer can enter the selected GYM Mode for 3 seconds defined sections of them in the corresponding Cling App.



The workout flowchart is as follows:
Other workout modes are similar to this process.



13 APP Important Reminder Settings

① Caller Reception

The Aura receives and sets up the Call Reception feature from the Cling App. The wearer has the option upon receiving a phone call to answer the call. The Cling Aura will vibrate to remind the wearer of the call in the Call Reception setting. When the wearer receives a call, the Cling Aura will vibrate to remind the wearer of the call. The wearer can also set the Call Reception feature in the Cling App. The "refuse to answer the phone" key can shoot down the screen button to stop the vibration reminder. The Cling App can also be set to reject the call.

Note: more than 8 of the phones in Android users are still not supported.

② Heart rate alarm, step and calorie reminder

New function

From the Cling App Home page navigate to: Device Details - Heart Rate and Activity Alerts - Heart Rate Alerts. Set the Heart Rate Alarm Value. When the wearer's heart rate exceeds the Aura monitors the heart rate to be equal to or higher than the value entered into the App, the Aura will vibrate giving the wearer an early warning. Navigate to Device Details - Activity Alerts - Steps / Calories. The wearer can be reminded step calorie goals. When the wearer reaches the preset value, the Aura will vibrate to remind.



14 Intelligent Reminder

When there is new information, the Aura will vibrate to remind the wearer and the information will be displayed on the screen, and the wearer can touch the button to view the message content.

Note: Please open the corresponding Smart Reminder in App.

15 Frequently Asked Questions

Q1. How to activate Aura?

A: Upon receiving the Aura it needs to be activated first. Press the Aura in the USB charger and then long press the Home key for 3 seconds to turn on the device. Then read the instructions in the Aura screen. To download the Cling Aura activation device, follow the instructions. (Note: Select the same model connection as the product type during activation)

Q2. If the Aura activation is unable to search for equipment?

A: Please make sure that your phone Bluetooth is turned on. Verify that the screen device is within the range of the phone.

Please make sure that the Aura is not in the charger and that it is not in the screen lock mode.

If your Aura is displayed on-screen and doesn't have a pin,please remove the Bluetooth connection from your phone.

Q3. Aura Bluetooth connection failed?

A: Android phones, please cancel the manual pairing in the list of Bluetooth paired devices, then search for devices in the Cling App and connect to the device.

Please make sure that the Aura is not in the charger and that it is not in the screen lock mode.

In the privilege management program of the mobile phone system, please set "Cling" as the self-starting device and allow the software to read in order the privilege of the Bluetooth.

The abolition of electricity saving mode.

Set up the background application lock.

Q4. Data can not be synchronized and has not been connected

A: If the Cling App keeps showing no connection, it may be caused by the Bluetooth connection being disconnected. Please check the Bluetooth connection status on the phone.

Q5. App is too slow.

A: It is suggested to synchronize the data of the Aura once a day to speed up the synchronization speed and to avoid the data being too much to cause a lag.

Q6. App is too slow.

A: It is suggested to synchronize the data of the Aura once a day to speed up the synchronization speed and to avoid the data being too much to cause a lag.

Q7. How to view push information?

A: If the first upgrade fails, please confirm whether the Aura and Cling App are connected. Please synchronize the Aura data before upgrading.

Q8. How to manage the application permissions of Cling App?

A: Please open the corresponding Smart Reminder in App.Permissions Select. Related Settings.

Q9. iOS mobile phone can ring to select the timer permissions?

A: Please open the corresponding Smart Reminder in App.Permissions Select. Related Settings.

Q10. Time does Android mobile not Cling App coming in the background?

A: Android phones, please cancel the manual pairing in the list of Bluetooth paired devices, then search for devices in the Cling App and connect to the device.

In the privilege management program of the mobile phone system, please set "Cling" as the self-starting device and allow the software to read in order the privilege of the Bluetooth.

16 Basic Parameters

Weight	Size
Display Size	38.5x19x9.5 mm
Touch Screen	Case Material
Display Resolution	Strap
Touch Mode	Bluetooth
Sensor	Bluetooth Low Energy 4.0
Battery	PMMA Organic Glass
Battery	IP68 Water Resistant
70 mAh Lithium Ion	Antenna
Core Module Dimensions	PPC Material
Wristband Length	Android 4.4* and IOS8.0*
Wristband Material	
Aluminum Urethane Elastomer, Breathable	

Note:For a better experience the Cling App software and Aura firmware will be updated from time to time, please update to the latest push versions available.

Introduction

Thank you for choosing Cling Aura Wristband . Please read the entire guide carefully before using the device. If you would like to know more information about Cling Aura, please refer to our website: www.clingfun.com

1. Wearing Method: Wear the device on your wrist.
2. Avoid cleaning the Aura when it is charging.
3. Avoid cleaning the Aura when it is charging.
4. Please do not use the Aura in the following circumstances: Wet hands when it is charging; Use in a humid environment.
5. Please do not use the Aura in the following circumstances: Wet hands when it is charging; Use in a humid environment.
6. Avoid Switch on the Bluetooth on the phone, then reopen the Cling App.

Q11. App is too slow.

A: It is suggested to synchronize the data of the Aura once a day to speed up the synchronization speed and to avoid the data being too much to cause a lag.

Q12. How to upgrade?

A: Upon receiving the Aura it needs to be activated first. Press the Aura in the USB charger and then long press the Home key for 3 seconds to turn on the device. Then read the instructions in the Aura screen. To download the Cling Aura activation device, follow the instructions. (Note: Select the same model connection as the product type during activation)

Q13. How to change the application permissions of Cling App?

A: Please open the corresponding Smart Reminder in App.Permissions Select. Related Settings.

Q14. iOS mobile phone can ring to select the timer permissions?

A: Please open the corresponding Smart Reminder in App.Permissions Select. Related Settings.

Q15. Time does Android mobile not Cling App coming in the background?

A: Android phones, please cancel the manual pairing in the list of Bluetooth paired devices, then search for devices in the Cling App and connect to the device.

In the privilege management program of the mobile phone system, please set "Cling" as the self-starting device and allow the software to read in order the privilege of the Bluetooth.

The abolition of electricity saving mode.

Set up the background application lock.

Warranty and after-sales service

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Warning and attention:
1. Warning by warning operator: Long time warning operator. Once device and charging base. If your warranty service. Stored, put your card. prefix 1000 cutting and wrong.
2. 7 days refund - Consumer can get a refund (invoice amount), replacement or maintenance according to the relevant provisions of the state. Due to the user's own reasons, the product is not guaranteed to return.
Commitment Time to refer to the time to start the user's responsibility. Other warranty period, the specific matters of the commitment shall prevail. Non-human damage, the scope of the commitment.
Note by providing the after-service testing report. The after-service testing report must come from an authorized maintenance unit designated by the company or above the provincial level.
Three guarantees: refers to the replacement, repair and return.
Three packages: refers to the door-to-door service.
(1) Unable to provide warranty card or invoice except home appliance (or appliance) can not be repaired.
(2) Damage of product is caused by inappropriate use.
(3) Damage of product is caused by unauthorized repair.
(4) Damage of product is caused by transportation.
(5) Damage of product is caused by force majeure.
(6) Damage of product is caused by abnormal voltage.

Warranty period: 1 year
1. The product is not a medical equipment. Please do not rely on this product data to diagnose, treat or prevent you from any medical problems. Please consult your doctor for medical advice.
2. Please do not use the product in the following circumstances: Wet hands for a shower and charge; Use in a humid environment.
3. Please use the product not application according to its legal functions.
4. Please keep the product working, to keep ingredients.