55*80mm 双面印 风琴折

gorsun®

苹果FindMy认证防丢器

产品使用说明书



Works with Apple Find My

F1

01 产品信息

名称:F1智能防丢器
产品尺寸:35x33.2x8.1mm
产品净重: ≈8g
额定电压:3V

额定电流:3.3mA
音量:80-100dB
配件:挂绳*1



02 产品使用方法

1、设备开机

(1). 开机：长按3秒，有滴滴声音，设备开机。
(2). 关机：短按2下，第三下长按直到听到语音提示。
(3). 断开连接： 防丢器未与手机配对，3分钟后会自动关机。

2、绑定设备

(1). 打开苹果自带的“查找”app。

(2). 将设备靠近您的 iPhone，在“物品”栏点击“添加物品”

(3). 点击“其他支持的物品”,搜索到带有“F1”字符的设备，轻点连接。

(4). 填写“自定名称”以命名您的设备并点继续。

(5). 为物品选取一个表情符号，并点继续 。

(6). 同意将设备注册到您的 Apple ID。

(7). 轻点“完成”绑定成功。

3、物品丢失寻找

(1). 物品在身边丢失寻找，打开“查找”app,点击物品栏中的物品名称，再点击“播放声音”,通过声音来寻找物品。
(2). 物品丢失在远距离，可在“查找”app的物品栏中点击物品名称，并点击“路线” ，通过地图导航来寻找物品。
(3). 若物品彻底丢失，并无法找回，可开启“丢失模式”

激活丢失模式

(1). 打开苹果自带的“查找”app，点击屏幕底部的“物品”，然后点击物品的名称。
(2). 在“丢失模式”下方，点击“启用”
(3). 按照屏幕指示操作，点击“继续”输入联系电话或者邮箱。
(4). 点击“下一步”核对信息后，请再次点击“启用”完成设置。

4、删除设备

打开苹果自带的“查找”app，点击屏幕底部的“物品”，然后点击物品的名称。
在列表的最下方找到“移除物品”，轻点“移除”完成操作。

说明：删除设备后，设备会发出提示音，设备不会关机，处于配对模式。如果5分钟之内，没有重新配对，设备就处于关机状态，此时设备与app无法配对。如果需要配对设备，需要长按三秒开机，设备响。此时设备进入配对状态，可以跟APP重新配对。

5、设备状态确认

双击设备按键两下，设备响，说明设备在工作。如果设备不响，说明设备处于关机状态。长按按键3秒，开机。

6、恢复出厂设置

首先，查找app中，移除设备。然后在设备开机后，快速按四下再长按3秒，设备发出提示音，松开按钮，恢复出厂设置完成。设备就可以跟新的账户配对。

03 电池安装说明

1、通过上盖和下盖之间的缝隙将产品拆开。



2、将CR2032电池插入设备，正极（+）朝上



3、连接上盖和下盖，并压紧。
装上纽扣电池，设备发提示音。表示设备已开机。

04 注意事项

1. 拆换电池：在防丢器拆卸口处打开机身更换电池，更换完成后,盖上后盖,稍稍用力卡住,完成操作。
(注:请更换**CR2032**纽扣电池)
2. 本产品请勿在潮湿环境下使用。
3. 本产品非玩具、请让儿童远离本设备,以免误食。
4. 清洁本产品请勿使用液体，喷雾清洁剂或湿布进行清洁。
5. 使用时远离水源和热源，以免损坏产品并产生安全隐患。

⚠ WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as 2 hours.
- **KEEP** new and used batteries **OUT OF REACH OF CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.

gorsun®

Apple FindMy Tracking Locator

User Manual



Works with Apple Find My

F1

01 Specifications

F1 SMART FINDER
Size: 35*33.2*8.1mm
Net Product Weight: ≈ 8g
Rated Voltage: 3V

Rated Current: 3.3mA
Volume: 80-100dB
Accessories : Sling





02 Product use method

1.Power On

(1). Power on ： Long press the button for 3s till the smart tag will be play sound “ DiDi”
(2).Power off ： Short press twice and then long press until hearing the ringtone
(3).Disconnection：The smart tag will automatically shut down if there is no connection after 3mins

2.Pair the Device

(1). Open the “Find My” application as well as the Bluetooth and network functions

(2). Press “Item” and then “Add other Item

(3) In the Enable state , Search the pairing name “ F1” for connection

(4) Customized your own smart tag name

(5) Select emoji for the item and click “Continue”

(6) Agree to register the smart tag to your Apple ID

(7) Click “Continue ” to complete the registration

3.Lost item search

(1). If you lose an item and need to search for it, open the “Find my” app, Click on the item name in the item list, then click “Play Sound” to find out the location.
(2). If the lost item is located at a distant place, open the the “Find my” app, and then click on “Directions” to find out where the smart device is located based on the location.
(3). If the item is completely lost and cannot be retrieved, the “Lost Mode” can be activated.

Lost mode

(1). Open the “Find my” app , click on the “Items” at the bottom of the screen, and then click on the name of the item.
(2). Active the “Lost Mode ”
(3). Follow the instructions on the screen. Click “Continue” and enter the email address and phone number
(4). After clicking “Next” to verify the information, please click “Enable” again to complete the setup.

4. Delete the device

Open the built-in “Find my” app of Apple, click on the “Items” , and find out “Remove Item”, and them simply tap “Remove” to complete the operation.

Tips : After the device is removed,You will hear a notification sound.The device will not shut down.It will enter the pairing mode. If there is no connection is performed within 5 minutes,the device will enter a powered-off state.At this point, the device cannot be paired with the app.If you need to pair the device, you need to press and hold for 3 seconds to turn it on. After a ringtone ,The device enter the pairing mode.Then you can repair your device .

5.Equipment Status Confirmation

Double-click the device button twice. The device will ring. indicating that it is working. If the device doesn’t ring,The device is currently in a powered-off state. Press and hold the button for 3 seconds to turn it on.

6.Restore factory settings

Quickly press the button 4times hold 5th press until ringtone

03 Battery installation instructions

1. Separate the product by opening the gap between the top cover and the bottom cover.

2.Insert the CR2032 battery into the device with the positive terminal (+) facing upwards



3. Connect the upper cover and the lower cover and press them tightly. When the button battery is installed, the device emits a prompt sound. It indicates that the equipment has been turned on.



04 Notes

1. Please replace with CR2032 button batteries.
2. This product must not be used in a humid environment.
3. This product is not a toy. Please keep children away from this device to prevent them from eating by mistake .
4. To clean this product, please do not use liquid, spray cleaners or damp cloths for cleaning.
5. When using, keep away from water sources and heat sources to avoid damaging the product .

⚠ WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as 2 hours.
- **KEEP** new and used batteries **OUT OF REACH Of CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.