DACOM
AI for audio since 1999

# Bone conduction & Dynamic drivers 2-IN-1 Sport bluetooth headset

Gemini G100
骨传导&动圈双模式运动耳机

使用说明书
Manual


中文 —— 1 - 8
ENGLISH —— 9 - 17
日本語 —— 18 - 26
русский —— 27 - 35


## 功能指示图

触摸MFB键 / LED灯 / 降噪咪 / 骨传导模组 / 通话咪 / Type c充电口 / 音量触摸键

## 配件清单

耳机*1　动圈模组*1对　充电线*1　说明书*1　收纳袋*1　记忆耳塞*1



## 产品信息

耳机型号：Gemini G100
蓝牙版本：V5.0
扬声器：骨传导&动圈
频响范围：20HZ-20KHZ
有效距离：约10米
电池类型：可充电聚合物锂电池
外接电压：DC4.8-5.5V
支持协议：A2DP/HFP/HSP/AVRCP

## 佩戴方式

骨传导模式　动圈模式



骨传导模式　动圈模式

## 双模式更换方式：

1.根据场景选择动圈模组或骨传导模组（不可混搭）。
2.模组对应主机上L/R标识分别插入（如上图所示）
温馨提醒：1.建议在关机状态下更换机头；2.更换机头时请垂直拔插，切勿旋转。

## 基本功能

### 开机
关机状态下，长按耳机触摸MFB键3秒，绿灯闪1下，耳机开机。

### 关机
1.开机状态下，长按耳机触摸MFB键4秒，红灯长亮2秒，耳机关机。



2.未连接待机状态下，5分钟后耳机自动关机，红灯长亮2秒。

### 配对模式
在关机状态下，长按触摸耳机MFB键5秒，耳机开机直至进入红绿灯交替闪烁配对状态。打开手机蓝牙，搜索设备"Gemini G100"并点击它，当听到已连接的提示音后，耳机与手机连接成功。

5S

### 音乐切换
在听歌状态下，三击触摸MFB键，播放上一曲；双击触摸MFB键，播放下一曲。

3击　2击



### 音量控制
在通话或听歌状态下，双击触摸⊕键，音量增加；三击触摸⊖键，音量减小。

2击　3击

### 音乐播放/暂停
在播放/暂停状态下，单击触摸MFB键，实现播放暂停。

### 接听来电
来电状态下，单击触摸MFB键，接听来电。

### 挂断通话
通话或去电中，双击触摸MFB键，挂断电话。

### 拒接来电
来电状态下，长按触摸MFB键2秒，拒接来电。



### 夜跑LED
开机状态下，连续4击触摸MFB键可开启或关闭夜跑LED。

4击

### EQ切换
在听歌状态下，长按触摸⊖键3秒，可以在动感模式与标准模式之间切换

3击

### 语言切换
未连接配对状态下，双击触摸MFB键，可实现中英文语言切换。

### 语音助手
连接待机状态下，长按触摸MFB键2秒，可唤醒语音助手（或Siri）。



备注：语音助手需要设备支持，而且要在设备端打开语音助手权限。

### 复位
充电状态下，长按触摸MFB键5秒，清除所有配对信息。

### 充满电
充电时红灯长亮，充满后绿灯长亮。

## 安全规则

- 请勿以任何理由拆除或改装耳机，否则可能导致耳机故障或烧毁，这些不在保修范围。
- 如因私自拆除或破坏设备结构，导致设备进水或无法使用，制造商将不予保修。
- 请勿将设备于温度过高或过低（0°C以下或45°C以上）的环境下。
- 请避免靠近儿童或动物的眼睛使用设备指示灯。
- 请勿在雷暴天气下使用该设备，雷暴可导致设备工作不正常，并增加触电的危险。

## 售后服务及说明

购机日期以本凭证到购机发票为准，不能提供有效证明的，以生产日期为准。
质量问题不包括用户个人对音质、音色等主观差异。
外壳、说明书、包装不在保修服务范围内。



已停产的型号，本公司仅做功能性恢复。
经销商向您做出的非本公司的承诺，本公司不承担任何责任。

| 产品保修卡 | | |
|---|---|---|
| 经销商信息 | 产品型号 | |
| | 经销商名称 | |
| | 产品序列号 | |
| | 联系电话 | |
| | 销售日期 | |
| 用户信息 | 用户地址 | |
| | 通信地址 | |
| | E-mail | 合格 |
| 备注 | | |

本机一年内免费保修，若人为损坏，行收费维修处理


公司：深圳市盟大网络科技有限公司
地址：深圳市龙岗区坂田街道坂雪岗大道1012号403




English



## Button Function

MFB Touch Button / LED Light / Noise Reduction Microphone / Bone Conduction Head / Talking Microphone / Type C Charging Port / Volume Control Touch Button

## Accessories

Earphone*1　Dynamic Head*1 set　Charging Cable*1　Manual*1　Storage Bag　Memory Earplug



## Product Information

Earphone Model: Gemini G100
Bluetooth Version: V5.0
Driver: Bone Conduction&Dynamic Drivers
Frequency response range: 20Hz-20KHz
Effective distance: about 10 meters
Battery Type: Rechargable Lithium-ion Polymer Battery
External voltage: DC4.8V-5.5V
Support Agreement: HSP / HFP / A2DP / AVRCP

## Wear Introduction

Bone Conduction Mode　Dynamic Mode



Bone Conduction Mode　Dynamic Mode

## Replace Bone Conduction Head/Dynamic Driver Head

1.Select bone conduction or dynamic headphone by different scenario(do not mix and match)
2.Put L and R head on headphone fuselage respectively(show as above image)
remind: 1.replace headset when turn off status,When replacing the heads of the earphone, please must pull and plug vertinally, do not rotate them.

## BASIC SKILLS

### Power On
Long press MFB button for 3S, the green indicator blinks once, the headphone power on.

### Power Off
1.Long press MFB button for 4S, the red indicator goes on for 2S, the headphone power off.



2.The headphone will power off automatically after 5-min stand by, the red indicator goes on for 2S.

### Bluetooth Connection
Long press MFB button for 5S power on your headphone. When the light flashes red and green, turn on the Bluetooth and click "GEMINI G100", it' s connect successful when you hear "connected".

5S

### Previous/Next Song
Previous Song: Triple-click MFB button to previous song Next Song : Double-click MFB button to next song.

x3　x2



### Volume Control
Double-click when listening music or making a phone call volume+ ; Triple-click when listening music or making a phone call volume-.

x2　x3

### Play / Pause
Click MFB button to Play/Pause when listening music.

### Answer the Call
Click MFB button to answer the call.

### Hang Up the Call
Double-click MFB button to hang up the call.

### Reject the call
Long press MFB button for 2S to reject the call.



### Night-Running LED
Click MFB button for 4 times to turn on/off the night-running LED when headphone power on.

x4

### Sport / Standard Mode
Long press for 3S to switch sport/standard mode when listening music.

x3

### Switch Language
Double-click MFB button to switch language before Bluetooth connection.

### Voice Assistant
Long press MFB button for 2S to turn on the voice assistant.



Note: The voice assistant needs to be supported and enabled by the device.

### Reset
Long press MFB button for 5S to clear connection information when charging.

### Full charging
The red indicator keeps on when charging,The green indicator keeps on when full charging.

## SAFETY PRECAUTION

- Do not detach or modify the earphone, otherwise it might get damaged or malfunctioned. Defectives under this category are not included for warranty.
- Do not expose the device into water or other liquid, otherwise it might get damaged or malfunctioned. Defectives caused by liquid inside are not included for warranty.
- Do not expose the earphone in extreme humidity or extreme temperatures (below 0 °C or above 45°C ).
- Avoid putting the indicator light near children eyes or animal eyes.
- Do not use the earphone in thunderstorm weather which might cause malfunction and increase the risk of electric shock.



## WARRANTY SERVICE AND DESCRIPTION

The date of purchase is subject to the purchase invoice, and if the valid invoice cannot be provided, the date of manufacture shall prevail. Quality issues do not include user' s subjective judgment on sound quality.
The warranty does not include plastic, manual and packaging. For those models that have been stopped for production, the company warrants for repairing the functions only.
Our company does not take any responsibility for the commitments dealers made to you but not within our company commitments.



日本語



## ボタン効能

タッチMFBボタン / LEDライト / ノイズキャンセリングマイク / 骨伝導イヤホン / 通話マイク / Type c充電口 / 音量タッチボタン

## パッケージ内容



## 製品説明

イヤホンモデル：Gemini G100
Bluetoothバージョン：V5.0
スピーカー：骨伝導＆ダイナミックドライヤー
周波数範囲：20Hz-20KHz
通信距離：約10m
電池タイプ：充電可能のリチウムポリマー電池
可接電圧：DC4.8V-5.5V
Bluetoothプロファイル：HSP / HFP / A2DP /AVRCP

## 着用方法

骨伝導モード　ダイナミックドライヤーモード



骨伝導モード　ダイナミックドライヤーモード

## ダブルモードの切り替え方法：

1. シーンによって、ダイナミックドライバー　モード或は骨伝導モードを選びます（同時にマッシュアップ使用不可）。
2. 単体モードのイヤホンを本体のL/R標識に合わせて別々に差し込んで、モードを切り替えます。（上の図のように）
ご注意：パワーオフの状態でイヤホンを替えることをお勧めします。イヤホンを切り替えるとき、垂直に抜き差ししてください。無理に捻らないでください。



2. 未接続待機の状態で、5分間後イヤホンが自動的にオフになり、赤いライトが2秒間点灯します。

### ペアリング方法
パワーオフの状態で、MFBボタンを5秒間長押し、イヤホンがオンにして赤と緑のライトが交互に点滅して、ペアリング状態になります。携帯電話のbluetooth機能をオンにし、「Gemini G100」を検索しクリックして、「接続済み」という提示音が聞こえたら、イヤホンと携帯電話の接続が完了になります。

5S

### 音楽の切り替え



### 音量調整
通話或は音楽再生のとき、タッチボタン をダブルクリックして、音量を上げます；タッチボタン を3回クリックして、音量を下げます。

x2　x3

### 音楽を再生/音楽を一時停止
再生/停止の状態で、MFBボタンを1回クリックして、再生と停止を切り替えます。

### 電話に応答
着信の場合、MFBボタンを1回クリックして電話に応答します。



### ナイトランニングLED
パワーオンの状態で、MFBボタンを4回クリックして、ナイトランニングLEDをオン/オフにします。

x4

### ダイナミックモードと標準モードの切り替え
音楽再生のとき、タッチボタン を3秒間長押し、ダイナミックモードと標準モードを切り替えます。

x3



注：音声アシスタント機能はデバイスのサポートが必要です。そして、デバイスの音声アシスタントをオンにする必要があります。

### リセット方法
充電の状態で、MFBボタンを5秒間長押し、すべてのペアリング履歴を削除します。

### 満充電
充電のとき赤いライトが点灯し、緑のライトが点灯になりましたら、満充電になります。

### 安全規則
①イヤホンを分解や改装することに起因する故障関しては保証外となりますので、ご注意ください。
②イヤホンを高湿度あるいは低湿度（0℃以下あるいは45℃以上）の環境に置かないでください。



⑤本商品はリチウム電池を含まれているから、、爆発を防ぐため、日照りで暴露することや、火に投げることなどしないでください。
⑥家庭廃物と別れて、当地の法規に基づいて処理してください。
⑦イヤホンを壊れる可能性があるから、自分で電池を取ること、交換することをやめてください。

### アフターサービスについて
① 個人的に音質や音色などの意見は品質問題に含まないので、ご了承ください。
② 外見は保証外です。
③ 生産を停止したイヤホンは修復するだけです。
④ 保証期限は注文日付から計算しますので、ご注意ください。

### 保証
① ご意見等がございましたら、気軽にご連絡ください。製品の改善に活用させて頂きます。
② お問い合わせ先：注文履歴→出品先に連絡する。



русский



材质：105克双铜+过哑膜
工艺：四色印刷，骑马钉
尺寸：100*70mm

**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.