75PAI

Smart Wrist Ball Q20
User Manual

Welcome to use 75PAI Smart Wrist Ball
This manual will guide you how to use the wrist ball, please read it carefully.

Device Pairing

1. Download Paiactive APP

Search for "Paiactive" in the app store to download the app
OS support: Android5.1, iOS 9.0 and above

Download on the APP Store
Get it on Google Play

2. Device binding

a. Open the battery cover of the device according to the instructions, insert the battery, and make sure that the system indicator starts to flash;
b. Open the Paiactive App, register/log in to the account and add "Smart Wrist Ball" in "Device-Add Device" and follow the prompts to complete the operation.

Start Method

Put on the wrist strap and push the ball with your thumbs in the direction of the arrow until the ball cannot roll.

Quickly release the ball with the thumbs of both hands and hand the ball to the ball holder to rotate.

Feel the centrifugal force of the rotation of the sphere, and use the left and right swing or draw a circle to rotate the wrist.

Feel the power of the sphere's rotation, turn the wrist ball in a circular motion with your wrist, and continue to accelerate with the strength of your hand, while the variable speed lights flash.

Battery Installation

Press the position indicated by the arrow on the label, use your fingers to open the battery cover at the bottom of the wrist ball, insert the button battery, and align the buckle position to press and fix the battery cover.



Daily Maintenance And Precautions

1. The equipment is not waterproof, you need to use a dry cloth when wiping the product, do not get wet.
2. After using or replacing the battery for the first time, please synchronize the data once in the "Paiactive" application, otherwise the data time and date will be incorrect.
3. Please do not use any part of your body to try to stop the high-speed rotating ball, otherwise it is very easy to cause injury. It is recommended that you use clothing or let the ball stop naturally.
4. The running mode of the wrist ball is produced by the use of large friction, so normal friction sound will be produced during the rotation, please rest assured to use it. Please do not add any oily liquid into the shell, which will cause the product to be unusable.
5. The wrist ball is a high-precision product. The ball is very easy to be damaged after it collides with a hard object. Please use and play with the wrist strap.
6. The power generated by the sphere at high speed is very large. It is forbidden to submit to others during the movement to cause unnecessary injury.
7. The power generated by the sphere at high speed is very large, please do not give it to children under 10 or people with insufficient hand strength.

Warranty Description

After-sales service commitment: in strict accordance with the "Consumer Rights Protection Law of the People's Republic of China" and "Product Quality Law of the People's Republic of China" to implement after-sales three guarantees services, the service content is as follows: within the validity period of the three guarantees, you can enjoy repairs and replacements in accordance with these regulations , The right to return goods, repairs, exchanges, and returns should be handled with the purchase certificate.
1. Within 7 days from the date of your purchase, if the product encounters non-human-caused performance failure, it will be determined by the company's after-sales service center. You can choose to return, exchange or repair.
2. Within 15 days from the date of purchase, if the product encounters non-human-caused performance failures, it will be determined by the company's after-sales service center. You can choose to exchange or repair.
3. Within 12 months from the date of purchase, if the product encounters a performance failure caused by non-human causes, it will be tested and determined by the company's after-sales service center, and repairs can be carried out free of charge.

The following three guarantees cannot be enjoyed:

1. Failure caused by improper use, maintenance, storage or operation that does not follow the instructions
2. Unauthorized personnel dismantled or repaired
3. Failure caused by force majeure (such as fire, flood, earthquake, lightning, etc.)
4. The warranty period is exceeded, or the warranty certificate cannot be provided, or the warranty certificate is modified without authorization
5. Product serial number (SN) labels, tamper-evident labels, etc. are missing, torn, damaged or forged labels, etc.

Name and content of hazardous substances in the product

Part Name	Harmful Materials					
	Pb	Hg	Cd	Cr（VI）	PBB	PBDE
Plastic	○	○	○	○	○	○
Metal Structure	○	○	○	○	○	○
PCB	X	○	○	○	○	○
Battery	○	○	○	○	○	○

This form is compiled in accordance with the provisions of SJ/T11364

○: Indicates that the content of the hazardous substance in all homogeneous materials of the part is below the limit requirement specified in GB/T26572.

X: It means that the content of the hazardous substance in at least one of the homogeneous materials of the part exceeds the limit requirement of GB/T26572, and there is no mature alternative in the industry. This product meets the environmental protection requirements of EU RoHS and Reach directives.

The "Environmental Protection Use Period" of this product is 10 years, and its label is shown in the figure above. The environmental protection use period of replaceable parts such as batteries may be different from the environmental protection use period of the product. The "Environmental Protection Use Period" is valid only when the product is used under normal conditions described in the instruction manual

Product Parameter

Product Name: Smart Wrist Ball
Product Model: LS-Q20
Product Size: 72*72*60mm
FCC ID: 2ATWS2020AB
Battery Model: Button Battery
Ball Core Material: Zinc Alloy
Shell Material: Polycarbonate, Silicone
Manufacturer:
Shanghai Laisi Information Technology Co., Ltd.
No.1158, Zhongxin Road, Songjiang District, Shanghai, P.R. China



75PAI

All materials and process technologies should be compliant with ROHS

Designer
Tianye

Date

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment