FV-2030T

FV-2030T Wireless Dual Band PCI Express Adapter

* Image may differ from actual product.

Fenvi Technical Support Information
ktt@ fenvi.cn 86-0755-83628485

Thank you for purchasing a quality Fenvi Product.
Please register your product at www.fenvi.cn
For complete warranty information and future support for your product.

1 Connect to a Computer



1. Screw the antennas to the Wi-Fi PCIe adapter (FV-2030T).
2. Turn off your computer and unplug the power cord from your computer.
3. Remove the side panel of the computer case. Carefully insert the driver into the PCIe slot of the motherboard.
4. Put the side panel of the case back and reconnect the power cord, then turn on your computer.

Shenzhen fenvi Technology Co., Ltd
The antenna is External antenna, Antenna A gain: 5dBi, Antenna B gain: 5 dBi,

2 Install Driver and Utility

A: Insert the resource CD, browse the CD and double-click Setup.exe
You can also download the driver and utility at www.fenvi.cn





B: The Wireless Setup Software will pop up. Click Install to continue and follow the instructions to finish. Then restart the computer to complete the installation.

Install



Success

3 Connect to Wireless Network

Join by Windows Wireless Utility
1. Click WiFi icon at the bottom right corner in Windows.
2. Select desired Wi-Fi network and click Connect.
3. If the network is unencrypted, you will directly connect to it. If the network is encrypted, enter the password (network security key) and then click Next to connect.





FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC’s RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.