版本	标注	ECO编号	变更日期	变更描述	设计者
A01	NA	NA	2021.7.07	初版发行	李烜
A02	NA	NA	2021.9.15	修改内容	李烜
A03	NA	NA	2021.10.13	修改内容	李烜

QUICK START GUIDE

Lockin Smart Gun Safe

QUICK START GUIDE

IN THE BOX

Lockin Smart Gun Safe	x 1
Backup Keys	x 2
AA Batteries	x 4
Mounting Screws	x 2
Quick Start Guide	x 1



1. Lock Catch
2. Cover Panel
3. Battery Cover
4. Emergency Power Port
5. Lock Cylinder
6. Fingerprint Scanner
7. Keypad
8. Interior LED Indicator
9. Eject Button

WARNINGS

To prevent damage to your Lockin unit or injury to yourself or to others, read the following safety precautions before using this unit.

DO NOT place or store the backup keys inside the safe at any time. If the battery fails, you will be unable to open the safe.

DO NOT expose to extreme heat or cold. Battery power may be affected.

DO NOT store loaded guns in this unit. Firearms are serious in nature and must be handled with respect. Store responsibly.

DO NOT get fingerprint sensor wet.

ALWAYS check to make sure door has latched when closing; Lid requires a firm press and locks automatically.

DISCLAIMER

Neither seller nor manufacturer shall be liable for unauthorized access, any injury, loss or damage to personal property direct or consequential, arising out of the use of, or the inability to use the Lockin Safe.

The user shall determine the suitability of the Lockin Safe before the intended use and user assumes all risk and liability whatsoever in connection therewith, Lockin Safe are not intended to protect against environmental hazards including fire and water.

Be sure and follow all local and state firearm laws.

DO NOT operate a firearm without proper training and experience.

SETUP

1. Battery Installation

Use the backup key to unlock the safe. The keyhole is located on left side of the safe underneath the hidden cover.

Press the Eject button (the red area) to remove the battery case.

Install the included 4x AA batteries into the battery case. Insert the battery case back into the slot.

2. Download the Lockin app from the app store. Log in or create a Lockin account to finish Lockin Smart Gun Safe setup.

3. Press the button "1" for 3 seconds to enter pairing mode. Return to Lockin App on your smartphone and click on "Add Device." Select Lockin Smart Gun Safe to begin device setup.



4. Follow the setup instructions in the Lockin App to complete fingerprint and keypad access registration.

5. Once setup is completed, Lockin Smart Gun Safe is ready for use.

BASIC OPERATIONS

Fingerprint Unlock

Place your finger on the fingerprint scanner to unlock the safe

Keypad Unlock

Enter the correct (8~12 digit) access code on the keypad to unlock the safe

Backup Key Unlock



Remove key cover and insert the backup key to unlock the safe.

LED STATUS LIGHT

Green light

Flash Once: Verification Successful

Flashing: Pairing Mode

Red light

Flash Once: Verification Failed

Flashing: Low Battery

Solid: 5 Failed Verification Attempts

Green/Red Light

Flashing: Firmware Update

MOUNTING INSTALLATION

You can securely mount your Lockin Smart Gun Safe to a flat surface using the included mounting screws and the pre-drilled holes on the bottom of the safe.

Using the Mounting Screws

1. Make sure you have enough clearance for the lid to open properly before mounting the safe.
2. Position the safe on a flat surface where you want to mount it.
3. Use a pencil to mark the holes for drilling.
4. Drill pilot holes.
5. Position safe in place and install the mounting screws through the safe and into the pilot holes. Tighten screws to complete installation.

Caution: Mounting the safe vertically so that the door flips upward will result in incomplete opening due to the weight of the lid. The door will open if the safe is mounted vertically so that the door opens down or to the side.

FAQ

1. What are the benefits of using Lockin app with the Lockin Gun Safe?
- Easy step-by-step setup process through the app.
- Conveniently add, change or delete fingerprint or keypad access.
- Status history that shows who or when the safe was accessed.

** All biometric fingerprint data are stored locally on the safe. No biometric data are stored in the Lockin app or cloud.*

2. How do I turn off audio?
- Open Lockin app, then go to Settings page of Lockin Gun Safe. Click on Sound Settings then click on Sound toggle to turn it off.

3. Any tips on improving fingerprint sensor accuracy?
- During fingerprint scan, move your finger slightly to scan the edges of your fingerprint.
- You can also scan the same fingerprint twice.

SPECIFICATION

Product name: Lockin Smart Gun Safe

Model: GS01

Product size: L304.5 x W254 x H83mm(Exterior)
/L285 x W156 x H71mm(Interior)

Product weight: 5.2kg

Battery type: 4x AA alkaline batteries

Warranty: 1 Year

Operating temperature: -10˚C~50˚C

Operating humidity: ≤95%RH

Certification: FCC\CA65\TSCA Test \CA California DOJ Certification

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Contact us
www.lockinsmarthome.com
Manufacturer: Chongqing Luxiangjia Technology Co., Ltd.
Address: No.50 Industrial Avenue, Pulu Street,Tongliang District, Chongqing

备注：
1. 尺寸：98*153mm
2. 印刷颜色：4C
3. 符合云丁科技《有害物质管理标准》

材质：108g哑粉,4C,折页,

表面处理：哑油

SCALE 1:1

SHEET 1/1

UNIT mm

云丁

物料名称：说明书

SELECT			V						
Dim \ TOL	A	B	C	EPS	EPE	EPP	BAG	CTN	LABEL
0~6	0.05	0.05	0.10						0.20
6~30	0.10	0.15	0.20	0.50	0.50	0.50	3.00		0.20
30~120	0.15	0.20	0.30	0.50	0.50	0.50	5.00	1.00	0.25
120~300	0.20	0.30	0.40	1.00	1.00	1.00	10.00	1.00	0.30
300~450	0.25	0.40	0.50	2.00	2.00	2.00	15.00	2.00	0.50
450~600	0.30	0.50	0.60	3.00	3.00	3.00	20.00	3.00	0.80
DRAFT TOLERANCE			± 0.20˚		CRITICAL DIM. MARK				*

产品名称	料号	设计	核准
JEEP-L	0524086001	李烜	周树温