802.11ax-40 MHz(RU26) LOW CHANNEL



802.11ax-40 MHz(RU26) MIDDLE CHANNEL



802.11ax-40 MHz(RU26) HIGH CHANNEL



802.11ax-40 MHz(RU52) LOW CHANNEL



802.11ax-40 MHz(RU52) MIDDLE CHANNEL

802.11ax-40 MHz(RU52) HIGH CHANNEL



802.11ax-40 MHz(RU106) LOW CHANNEL



802.11ax-40 MHz(RU106) MIDDLE CHANNEL



802.11ax-40 MHz(RU106) HIGH CHANNEL



802.11ax-40 MHz(RU242) LOW CHANNEL



802.11ax-40 MHz(RU242) MIDDLE CHANNEL



802.11ax-40 MHz(RU242) HIGH CHANNEL



SISO-Aux. Antenna

802.11b CHANNEL 1

802.11b CHANNEL 6

802.11b CHANNEL 11

802.11g CHANNEL 1



802.11g CHANNEL 2



802.11g CHANNEL 6

802.11g CHANNEL 10

802.11g CHANNEL 11



802.11n-20 MHz CHANNEL 1



802.11n-20 MHz CHANNEL 2

802.11n-20 MHz CHANNEL 6



802.11n-20 MHz CHANNEL 10

802.11n-20 MHz CHANNEL 11

802.11n-40 MHz CHANNEL 3

802.11n-40 MHz CHANNEL 4

802.11n-40 MHz CHANNEL 5



802.11n-40 MHz CHANNEL 6



802.11n-40 MHz CHANNEL 7

802.11n-40 MHz CHANNEL 8

802.11n-40 MHz CHANNEL 9

VHT-20 MHz CHANNEL 1



VHT-20 MHz CHANNEL 2

VHT-20 MHz CHANNEL 6

VHT-20 MHz CHANNEL 10

VHT-20 MHz CHANNEL 11

VHT-40 MHz CHANNEL 3

VHT-40 MHz CHANNEL 4



VHT-40 MHz CHANNEL 5



VHT-40 MHz CHANNEL 6

VHT-40 MHz CHANNEL 7

VHT-40 MHz CHANNEL 8

VHT-40 MHz CHANNEL 9

802.11ax-20 MHz(SU) CHANNEL 1

802.11ax-20 MHz(SU) CHANNEL 2

802.11ax-20 MHz(SU) CHANNEL 6

802.11ax-20 MHz(SU) CHANNEL 9

802.11ax-20 MHz(SU) CHANNEL 10

802.11ax-20 MHz(SU) CHANNEL 11

802.11ax-40 MHz(SU) CHANNEL 3

802.11ax-40 MHz(SU) CHANNEL 4

802.11ax-40 MHz(SU) CHANNEL 5

802.11ax-40 MHz(SU) CHANNEL 6

802.11ax-40 MHz(SU) CHANNEL 7

802.11ax-40 MHz(SU) CHANNEL 8

802.11ax-40 MHz(SU) CHANNEL 9

802.11ax-20 MHz(RU26) LOW CHANNEL



802.11ax-20 MHz(RU26) MIDDLE CHANNEL



802.11ax-20 MHz(RU26) HIGH CHANNEL



802.11ax-20 MHz(RU52) LOW CHANNEL



802.11ax-20 MHz(RU52) MIDDLE CHANNEL



802.11ax-20 MHz(RU52) HIGH CHANNEL



802.11ax-20 MHz(RU106) LOW CHANNEL



802.11ax-20 MHz(RU106) MIDDLE CHANNEL



802.11ax-20 MHz(RU106) HIGH CHANNEL



802.11ax-40 MHz(RU26) LOW CHANNEL



802.11ax-40 MHz(RU26) MIDDLE CHANNEL



802.11ax-40 MHz(RU26) HIGH CHANNEL



802.11ax-40 MHz(RU52) LOW CHANNEL



802.11ax-40 MHz(RU52) MIDDLE CHANNEL



802.11ax-40 MHz(RU52) HIGH CHANNEL



802.11ax-40 MHz(RU106) LOW CHANNEL



802.11ax-40 MHz(RU106) MIDDLE CHANNEL



802.11ax-40 MHz(RU106) HIGH CHANNEL



802.11ax-40 MHz(RU242) LOW CHANNEL



802.11ax-40 MHz(RU242) MIDDLE CHANNEL



802.11ax-40 MHz(RU242) HIGH CHANNEL

MIMO-Main Antenna

802.11b CHANNEL 1

802.11b CHANNEL 6

802.11b CHANNEL 11

802.11g CHANNEL 1

802.11g CHANNEL 2

802.11g CHANNEL 6



802.11g CHANNEL 10

802.11g CHANNEL 11



802.11n-20 MHz CHANNEL 1

802.11n-20 MHz CHANNEL 2



802.11n-20 MHz CHANNEL 6



802.11n-20 MHz CHANNEL 10



802.11n-20 MHz CHANNEL 11

802.11n-40 MHz CHANNEL 3

802.11n-40 MHz CHANNEL 4



802.11n-40 MHz CHANNEL 5



802.11n-40 MHz CHANNEL 6

802.11n-40 MHz CHANNEL 7

802.11n-40 MHz CHANNEL 8

802.11n-40 MHz CHANNEL 9

VHT-20 MHz CHANNEL 1

VHT-20 MHz CHANNEL 2

VHT-20 MHz CHANNEL 6



VHT-20 MHz CHANNEL 10

VHT-20 MHz CHANNEL 11



VHT-40 MHz CHANNEL 3

VHT-40 MHz CHANNEL 4



VHT-40 MHz CHANNEL 5



VHT-40 MHz CHANNEL 6

VHT-40 MHz CHANNEL 7

VHT-40 MHz CHANNEL 8

VHT-40 MHz CHANNEL 9

802.11ax-20 MHz(SU) CHANNEL 1

802.11ax-20 MHz(SU) CHANNEL 2

802.11ax-20 MHz(SU) CHANNEL 6

802.11ax-20 MHz(SU) CHANNEL 9

802.11ax-20 MHz(SU) CHANNEL 10

802.11ax-20 MHz(SU) CHANNEL 11

802.11ax-40 MHz(SU) CHANNEL 3

802.11ax-40 MHz(SU) CHANNEL 4

802.11ax-40 MHz(SU) CHANNEL 5

802.11ax-40 MHz(SU) CHANNEL 6

802.11ax-40 MHz(SU) CHANNEL 7

802.11ax-40 MHz(SU) CHANNEL 8

802.11ax-40 MHz(SU) CHANNEL 9

802.11ax-20 MHz(RU26) LOW CHANNEL



802.11ax-20 MHz(RU26) MIDDLE CHANNEL



802.11ax-20 MHz(RU26) HIGH CHANNEL



802.11ax-20 MHz(RU52) LOW CHANNEL



802.11ax-20 MHz(RU52) MIDDLE CHANNEL



802.11ax-20 MHz(RU52) HIGH CHANNEL



802.11ax-20 MHz(RU106) LOW CHANNEL



802.11ax-20 MHz(RU106) MIDDLE CHANNEL



802.11ax-20 MHz(RU106) HIGH CHANNEL

802.11ax-40 MHz(RU26) LOW CHANNEL



802.11ax-40 MHz(RU26) MIDDLE CHANNEL



802.11ax-40 MHz(RU26) HIGH CHANNEL



802.11ax-40 MHz(RU52) LOW CHANNEL



802.11ax-40 MHz(RU52) MIDDLE CHANNEL

802.11ax-40 MHz(RU52) HIGH CHANNEL



802.11ax-40 MHz(RU106) LOW CHANNEL



802.11ax-40 MHz(RU106) MIDDLE CHANNEL



802.11ax-40 MHz(RU106) HIGH CHANNEL



802.11ax-40 MHz(RU242) LOW CHANNEL



802.11ax-40 MHz(RU242) MIDDLE CHANNEL



802.11ax-40 MHz(RU242) HIGH CHANNEL

MIMO-AUX. Antenna

802.11b CHANNEL 1

802.11b CHANNEL 6

802.11b CHANNEL 11

802.11g CHANNEL 1



802.11g CHANNEL 2



802.11g CHANNEL 6



802.11g CHANNEL 10

802.11g CHANNEL 11

802.11n-20 MHz CHANNEL 1



802.11n-20 MHz CHANNEL 2



802.11n-20 MHz CHANNEL 6



802.11n-20 MHz CHANNEL 10



802.11n-20 MHz CHANNEL 11



802.11n-40 MHz CHANNEL 3



802.11n-40 MHz CHANNEL 4



802.11n-40 MHz CHANNEL 5



802.11n-40 MHz CHANNEL 6

802.11n-40 MHz CHANNEL 7

802.11n-40 MHz CHANNEL 8

802.11n-40 MHz CHANNEL 9

VHT-20 MHz CHANNEL 1



VHT-20 MHz CHANNEL 2



VHT-20 MHz CHANNEL 6



VHT-20 MHz CHANNEL 10



VHT-20 MHz CHANNEL 11

VHT-40 MHz CHANNEL 3

VHT-40 MHz CHANNEL 4



VHT-40 MHz CHANNEL 5

VHT-40 MHz CHANNEL 6

VHT-40 MHz CHANNEL 7

VHT-40 MHz CHANNEL 8

VHT-40 MHz CHANNEL 9

802.11ax-20 MHz(SU) CHANNEL 1

802.11ax-20 MHz(SU) CHANNEL 2

802.11ax-20 MHz(SU) CHANNEL 6

802.11ax-20 MHz(SU) CHANNEL 9

802.11ax-20 MHz(SU) CHANNEL 10

802.11ax-20 MHz(SU) CHANNEL 11

802.11ax-40 MHz(SU) CHANNEL 3

802.11ax-40 MHz(SU) CHANNEL 4

802.11ax-40 MHz(SU) CHANNEL 5

802.11ax-40 MHz(SU) CHANNEL 6

802.11ax-40 MHz(SU) CHANNEL 7

802.11ax-40 MHz(SU) CHANNEL 8

802.11ax-40 MHz(SU) CHANNEL 9



802.11ax-20 MHz(RU26) LOW CHANNEL



802.11ax-20 MHz(RU26) MIDDLE CHANNEL



802.11ax-20 MHz(RU26) HIGH CHANNEL