书写纸

尺寸:60mm*70mm

60mm

70mm

True Wireless Earbuds
A300



User Guide

1.Package Accessories



2* Bluetooth Earbuds
1* Charging Case
1* Charging Cable
1* User Manual
3* Pairs of Ear Tips

2.Product Introduction



1. Inductive Touch Sensor
2. LED Indicators of Earbuds
3. Charging pins on Earbuds
4. Micro USB Charging Port
5. LED Indicator of Charging Case

Usage Instructions

1. Please tear off the insulation film on the charging pins and then fully charge the earbuds before use.

2. How to Pair

a) Binaural mode instructions:

Take the earbuds out of the charging case / press and hold the multifunctional touch button (MFB) for 3 seconds to turn them on, the LED indicator of the right earbud will flash red and white light after the left/right earbuds have paired; turn on the Bluetooth function of your phone, search "A300" and click to pair. A voice prompt will follow after the earbuds and the phone have paired succefully.

b) Mono mode instructions:

Take the single earbud out of the charging case/press and hold the MFB button for 3 seconds to turn it on, the LED indicator will flash red and white light; turn on the Bluetooth function of your phone, search "A300" and click to pair. A voice prompt will follow after successful pairing.

3. How to control

Turn on	Take out from the charging case/press and hold the MFB button for 3 seconds.
Turn off	Put back into the charging case/press and hold the MFB button for 5 seconds in standby state.
Play/pause	Click the MFB button.
Previous/next	Double click L/R.
Volume -/+	Long press L/R.
Answer/ hang up the call	Click the MFB button during a call.
Reject the call	Press and hold the MFB button for 2 seconds during a call.
Activate voice assistant	Triple-click L/R.

4. Product parameters

Version	5.0
Support protocol	HFP, HSP, A 2DP, AVRCP
Workong distance	10M(barrier-free)
Workong time	4 hours (Varies by volume level and audio contents)
Single earbud/charging case battery capacity	50mAh/500mAh
Charging times	4 times
Input current	5V/1A

Tips

Warranty void if the earphones submersion in the water keep the earphones and the packaging out of reach of children.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

真无线立体声蓝牙耳机
A300



用户指南

1.包装配件



蓝牙耳机 X 2pcs
充电盒 X 1pcs
充电线 X 1pcs
用户指南 X 1pcs
耳塞 X 3pcs

2.产品说明

1. 多功能按键
2. 耳机LED指示灯
3. 耳机充电口
4. Micro USB充电端口
5. 充电盒LED指示灯

使用说明

1. 首次使用请撕下耳机充电口上的绝缘膜，然后将耳机充满电。

2. 如何配对

a) 双耳模式说明：

1. 将耳机从充电盒中取出或长按多功能按键约3秒将其打开；
2. 耳机自动开始配对，左右耳机红白灯闪烁；
3. 在智能设备的蓝牙列表中选择 " A300 " 进行配对。

b) 单耳模式说明：

1. 将单个耳机从充电盒中取出或长按多功能按键约3秒将其打开
2. 耳机自动开始配对，耳机红白灯闪烁；
3. 在智能设备的蓝牙列表中选择 " A300 " 进行配对。

3. 操作说明

开机	将耳机从充电盒取出或长按耳机多功能按键约3秒
关机	将耳机放回充电盒或长按耳机多功能按键约5秒
播放或暂停	单击多功能按键
上/下一首	双击左/右耳机多功能按键
音量 -/+	长按左/右耳机多功能按键
接听/挂断电话	单击多功能按键
拒接电话	长按多功能按键约2秒
启用语音助手	双击左/右耳机多功能按键

4. 产品参数

蓝牙版本	5.0
支持协议	HFP, HSP, A 2DP, AVRCP
有效距离	10M(无障碍)
工作时长	4小时（因音量和音频内容而异）
耳机/充电盒电池容量	50mAh/500mAh
充电次数	4 次
输入电流	5V/1A

温馨提示

请将耳机及包装放在儿童无法触及的地方，如果耳机进水，保修无效。