注意：
1、成品折叠尺寸90*70mm
2、四周已加2MM出血位
3、折叠位的虚线仅供参照，印刷的时候请去掉
4、上下两个画板拼双面（一面中文，一面英文）

AirToms

Model：AirToms

说明书

使用产品前请仔细阅读本说明书，并妥善保管

配件清单：

❶ 充电仓 ❷ 耳机 ❸ Type-C充电线 ❹ 说明书



产品介绍：

A 充电仓电量指示灯 B 无线充感应区

C Type-C充电端口



D 触摸感应区
E 耳机指示灯&麦克风
F 入耳感应
G 充电触点

产品参数：

蓝牙版本：5.0
支持协议：HFP/HSP/A2DP/AVRCP
喇叭直径：10mm
灵敏度：102±3dB
阻抗：32Ω
传输范围：10米
频率范围：2.402G - 2.483GHz
音频信噪比：≥92dB
电池容量：30mAh（耳机）
电池容量：400mAh（充电仓）
工作时间：约3小时
充电时长：约1.2小时
供电电压：3.0V~4.2V
播放音乐电流：≤9.5mA
通话电流：≤9.5mA
待机电流：≤0.5mA
充电电流：Max50mA
工作温度：-20℃~+50℃

产品使用：

1、开机
充电仓翻盖自动开机，或手动触摸耳机2秒开机。（注：如充电仓长时间处于待机状态下可能会造成充电仓电量流失，只需给充电仓重新充电或手动开机即可）

2、关机
将耳机放入充电仓后合盖可自动关机，也可手动触摸耳机5秒关机。

3、蓝牙连接
开机后自动进入双耳配对模式（指示灯快闪1秒），配对成功后即可用手机蓝牙搜索AirToms点击连接配对，连接成功后指示灯灭；本产品支持主从无缝切换，可选择双耳使用也可任意单耳使用；同时具有自动回连功能，再次使用时只需打开耳机及手机蓝牙功能即可自动完成连接配对。

触控功能：

开机：耳机关机状态下，触摸耳机2秒
关机：耳机开机状态下，触摸耳机5秒
播放/暂停：在音乐模式下，触摸左边或右边耳机一下
接听/挂机：来电时触摸左边或右边耳机一下
拒听来电：来电时触摸左边或右边耳机两下
上一曲：在音乐模式下，触摸右边耳机两下
下一曲：在音乐模式下，触摸左边耳机两下
音量+：触摸右边耳机三下
音量-：触摸左边耳机三下
SIRI：长按左边或右边耳机两秒，听到提示音后即已启动SIRI
光感功能：拿下任意一边耳机，音乐自动暂停；再次戴上耳机，音乐即可恢复播放

指示灯状态：

耳机指示灯：开/关机时白色指示灯长亮1秒；连接成功后白灯熄灭。
充电仓指示灯：充电时白灯长亮，并对应电量档位指示灯闪烁，充满电后四颗白灯长亮；放电时对应电量档位白灯长亮16秒后熄灭，且同时给耳机供电。

提示音：

状态	提示内容
开机	Power on
关机	Power off
连接成功	Connected
配对	Pairing
低电量	Battery low

使用注意事项：

1. 耳机需存放在干燥通风环境下，避免与油、水汽、蒸汽和灰尘等接触，以免影响产品性能。
2. 避免使用刺激的有机溶剂或含有这些成分的物品清洁耳机。
3. 耳机需按照要求正确规范的使用，注意使用环境对耳机的影响，为保证连接顺畅，建议手机和耳机之间的距离在10米范围内。
4. 如耳机有连接不上或通讯不畅等其他问题，请勿私自拆卸耳机本体及配件，否则不予保修。
5. 若给充电仓使用无线充电，请选用标准配置的无线充电器。
6. 为保证您正常使用耳机，请确保耳机的电量充足。

保修服务：

A. 在正常使用本产品过程中，如果本产品出现非人为损坏的性能故障，自购买之日起，消费者享受免费保修服务。保修期为12个月。
B. 有下列情况之一，消费者不能享受免费保修权益：

①人为损坏。
②超过保修期。
③不能提供有效的购买凭证。
④未按说明书要求使用而造成产品损坏。
⑤未经授权，擅自拆卸，维修产品或产品潮水。
⑥其他不可抗力造成的损坏。

AirToms

User Manual

Read this manual carefully before use,
and retain it for future reference

Accessories List：

❶ Charging case ❷ Earphone ❸ Type-C cable
❹ User manual



Product Overview：

A Indicator Light B Wireless Charging Induction Area
C Charging Port



D Touching Area
E Indicator Light & Microphone
F In-ear Sensor
G Charging Contact

Product Specification：

Bluetooth Version: V5.0
Support Agreement: HFP/HSP/A2DP/AVRCP
Speaker Diameter: 10mm
Sensitivity(S.P.L): 102±3dB
Impedance: 32Ω
Transmission Range: 10m
Frequency Range: 2.402G - 2.483GHz
Audio Signal-to-Noise Ratio: ≥92dB
Battery Capacity: 30mAh (Earbud)
Battery Capacity: 400mAh (Charging Case)
Working time: Around 3 hours
Charging time: Around 1.2 hours
Supply Voltage: 3.0v ~ 4.2v
Playing Current: ≤9.5mA
Speaking Current: ≤9.5mA
Standby Current: ≥0.5mA
Charging Current: Max50mA
Working Temperature: -20℃~+50 ℃

Product Instruction：

1. Power on
They will auto pairing when you take the earphones out of the charging case. You can also press the touch area for 2 seconds to turn it on. (If the earphone cannot be power on automatically, please charge the charging case or press the touch area for 2 seconds.)
2. Power off
Put the earbuds into the charging case or long press the earbuds touch area for 5 seconds.
3. Bluetooth pairing
After the earphones turned on, it will get paired automatically (Indicator light fast blink for 1 second). Turn on the Bluetooth, and click "AirToms" in the Bluetooth name list to connect pairing. The LED light will be off after it connected. This product can be fast switched between master mode and slave mode, free to wear one or both sides. It has automatic connection function, so when you use the same phone device, it can be auto pairing.

Touch Control Functions：

Power on: When the earbud is power off, long touch the earbud for 2 seconds
Power off: When the earbud is power on, long touch the earbud for 5 seconds
Play/Pause: One touch the L/R earbud to play or pause the music
Answer/Hang up: One touch the L/R earbud to answer or end the call
Reject calls: Double touch the L/R earbud to reject the call
Previous track: Double touch the right earbud for previous track
Next track: Double touch the left earbud for next track
Volume up: Triple touch the right earbud for volume up
Volume down: Triple touch the left earbud for volume down
SIRI: Long touch L/R earbud for 2 seconds, SIRI is activated after you hear a voice prompt
Optical sensor: Enable to pause the music as soon as you take one earbud off; once you put it back on, the music will playback again

Indicator Light Status：

Earphone indicator light: When the earphone is on/off, the indicator light is on for 1 second; the white light will be off after connected.
Charging case indicator light: When charging, the indicator light is on, and the indicator light is flashing corresponding to the power level. When the battery is fully charged, the four white lights are always on; When charging the earphones, the corresponding white light is on for 16 seconds and then the light is off.

Prompt tone：

Status	Prompt content
Power on	Power on
Power off	Power off
Connected	Connected
Paired	Pairing
Low battery	Battery low

Precautions：

1. The earphone should be stored in a dry environment to avoid oil, water, moisture and dust affecting product performance.
2. Avoid using stimulus, organic solvents to clean the earphones.
3. The earphone should be used correctly as per the instruction. Do not use the earphone in the above prohibited environment. In order to ensure the smooth connection, it is suggested that the distance between the earphone and phone within 10 meters.
4. If the earphones failed to connect or with poor connection, please do not dismantling the earphone by your own.
5. Please use the standard wireless charger to charge the charging case.
6. In order to ensure your normal use of the earphone, please make sure that the earphone is fully charged.

Warranty Service：

A. Product are warranted for 12 months from the date of purchase which products are not being damaged by any man-made factors.
B. In one of the following circumstances, consumers can not be served with the free warranty :

① Artificial damage
② Exceeding the warranty period
③ Failing to provide valid proof of purchase
④ Damage caused by failure to comply with instructions
⑤ Disassembling products without authorization or being soaked
⑥ Other damage caused by force majeure

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.