| 变更日期 | 标记 | 处数 | 变更描述 |
|---|---|---|---|
| | | | |

按实际生产的月份印刷

Hunt-key 航嘉

Q10磁吸移动电源

产品说明书

型号：HKCPB2710Q1

**前言**

尊敬的用户，感谢您选购航嘉产品。为了您能更进一步的了解产品，使用前请仔细阅读本说明书，妥您体验愉快！

**包装清单**

磁吸移动电源 × 1　充电线 × 1　说明书 × 1

**产品示意图**



① USB-C输入/输出接口　② 电源键　③ Qi 无线充模组　④ 电量显示
⑤ 剩余充/放电时间　⑥ 功率显示　⑦ 支架控制键

**产品参数**

| | |
|---|---|
| 产品尺寸 | 103*70*19.8mm |
| 电池类型 | 锂聚合物电池 |
| Qi 磁吸无线充 | 15W(MAX) |
| USB-C 输入 / 输出 | 5V⎓3A 或 9V⎓3A(MAX) |
| 总输出 | 5V⎓3A |
| | |
| 锂电池容量 | 5000mAh 7.2VDC/36Wh |
| 额定容量 | 6400mAh(5V⎓3A) |
| 产品重量 | 237g(近似值) |
| 工作温度 | -5℃~35℃ |
| 存储温度 | -20℃~50℃ |
| 数据线 | 30cm/USB-C转USB-C |
| 充电时间 | 约 2.5 小时(使用30W电源适配器) |

**使用说明**

- 首次使用时，请先短按电源键点亮屏幕以进出休眠模式，并将移动电源充满电。
- 充电线位于底部下方。
- 请勿使用多合一的数据线同时给多台设备充电。以免损坏您的设备。
- 消费者若使用电源适配器供电，则应购买配套使用容得CCC认证并满足标准要求的电源适配器。
- 推荐搭配使用机差30W及以上PD充电器，以获得理想充电体验。
- 若本产品存在电池膨胀、漏液、变形等异常时，请停止使用。
- 请水泡禁止使用。
- 电量查询：短按底部电源键，LCD显示屏将显示剩余电量的百分比，快速双击电源键可以关闭屏幕显示。
- 小电流充电模式：长按电源键持续3秒以上，USB-C接口将进入小电流充电模式，适合为手环、耳机等低功率设备充电。
- 异物检测 (FOD) 保护模式：当无线充电面板检测到金属异物时，自动进入保护模式，请移开无线充电面板上的所有金属异物，快速双击电源键以退出保护模式。
- 隐藏支架：短按左侧 "OPEN" 键，背部隐藏支架弹出。
- 请将本产品放置在儿童不能接触的地方。
- 如较长时间不使用本产品，请您将它储存在干燥环境中，为保证电池使用寿命，请每3个月至少给产品进行一次完全的充放电。

**安全警告**

- 请勿将本产品暴露在高温环境中或发热设备周围，如汽车、日照暴晒、取暖器、微波炉、烤箱等高温环境，可能引起爆炸。
- 严禁使用未经认可或不兼容的充电器、充电线等，可能引发火灾、爆炸或其他危险。
- 请勿将本产品长时间置于不通风的空间内，如手提包，密闭空间容易引发火灾等危险。
- 本产品包含锂聚合物电芯，严禁私自拆开产品外壳以免造成电芯破损或引发火灾危险。
- 请勿跌落、挤压、穿刺、短路本产品，或投入水、火中以免引发危险事故。
- 请按当地规定处理本产品，不可将本产品作为生活垃圾处理，若处理不当可能污染环境。
- 请勿在雷雨天气使用本产品，以免导致产品故障或电击危险。

**产品中有害物质的名称及含量**

| 部件名称 | 有害物质 | | | | | |
|---|---|---|---|---|---|---|
| | 铅 (Pb) | 汞 (Hg) | 镉 (Cd) | 六价铬 (Cr VI) | 多溴联苯 (PBB) | 多溴二苯醚 (PBDE) |
| 移动电源 | × | ○ | ○ | ○ | ○ | ○ |
| 数据线 | ○ | ○ | ○ | ○ | ○ | ○ |

本表格依据SJ/T 11364的规定编制。

○：表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。

×：表示该有害物质至少在该部件的某一均值材料中的含量超出GB/T 26572规定的限量要求。

技术说明：

PCBA中的二极管，三极管中使用的高温焊锡合结，符合达标管理目录使用物质应用例外清单6.1条款。

PCBA中的贴片电阻、二极管等使用的玻璃全结，符合达标管理目录使用物质应用例外清单6.3.1条款。

**保修说明**

消费者请过合法渠道购买的Hunt-key航嘉产品，自购机之日起一年内如果出现非人为原因造成的故障，可以享受产品保修服务。

为保证您的合法权益，请注意以下事项：

(1)保修卡应由用户妥善保管，遗失不补，涂改无效。

(2)本产品若发生非人为原因造成的故障，用户可凭保修卡和购机凭证，在保修期内到指定的维修点进行免费维修。

以下不属于保修服务范围

（1）产品超过保修有效期；

（2）无有效购机凭证，也无法证明所购产品在保修有效期内；

（3）保修卡型号与产品型号不符；

（4）无保修卡或者保修卡被涂改过；

（5）人为因素造成的损坏；

（6）非授权的维修、暴力操作、拆解、改装、挤压、进液、腐蚀；

（7）因水灾、火灾、雷击等不可抗力造成的损坏

如需在保修服务失效的情况下提供维修服务，航嘉将按零部件和人工成本计算合理的维修费用，并向用户提出维修报价，在征得用户的同意并支付费用后为用户的产品提供维修服务。

**保修卡**

尊敬的用户，感谢您使用Hunt-key航嘉的产品。为了能更好地为您服务，在购买产品后，请您阅读，填写并妥善保存此保修卡。

用户姓名 _____

用户地址/邮编 _____

联系电话 _____

产品型号 _____

产品序列号 _____

购买日期 _____

发票号码 _____

销售单位名称 _____

销售单位地址/电话 _____

**深圳市航嘉驰源电气股份有限公司**
**Shenzhen Huntkey Electric Co., Ltd**

深圳市龙岗区坂田街道五和大道19号"源创核计园

400-678-8388　航嘉微博　航嘉商城　航嘉官方旗舰店

www.huntkey.com

中国制造

合格证
型号：HKCPB2710Q1
检验员：02
出厂日期：2024.08

Hunt-key

Power Your Dream

Q10 Magnetic Power Bank

Manual

Model: HKCPB2710Q1

**Preface**

Thank you for purchasing the Huntkey products. For optimum operation, please read this manual carefully before using.

**Package Contents**

1 × Magnetic Power Bank　1 × Charging Cable　1 × User Manual

**Product Overview**



① USB-C Input/Output Port　② Power Button　③ Qi Wireless Charging Module　④ Electric Quantity　⑤ Remaining Charging/Discharging Time
⑥ Power Display　⑦ Holder Control Key

**Specifications**

| | |
|---|---|
| Dimensions | 103*70*19.8mm |
| Battery Type | Lithium-ion polymer battery |
| Qi Magnetic Wireless Charging | 15W(MAX) |
| USB-C Input/Output | 5V⎓3A or 9V⎓3A(MAX) |
| Qi + USB-C Output | 5V⎓3A |
| | |
| Li-ion energy | 5000mAh 7.2VDC/36Wh |
| Rated Capacity | 6400mAh(5V⎓3A) |
| Product Weight | 237g (approximation) |
| Operating Temperature | -5℃~35℃ |
| Storage Temperature | -20℃~50℃ |
| Charging Cable | 30cm/USB-C to USB-C |
| Charging Time | About 2.5 hours (using a 30W power adapter) |

**Instructions**

- Before its first use, please click the power button to light up the screen to exit sleep mode, and fully charge the power bank.
- The charging cable is below the blister.
- Please don't use all-in-one cables to charge multiple devices at the same time, as it may damage your devices.
- For optimal performance, we recommend that you use Huntkey accessories such as 30W(or above) PD charger.
- Stop all use if the battery is swollen, leaking or deformed.
- Stop all use if the battery is submerged.
- Electric Quantity: Press the power button at the bottom, and the LCD screen will display the percentage of remaining electric quantity. Double-click the power button quickly to close the screen display.
- Low Current Charging Mode: Press the power button for more than 3 seconds, and the USB-C port will start the low current charging mode, which is for charging low-power devices such as wristbands and earphones.
- FOD Protected Mode: When the wireless charging panel detects a metal foreign object, it automatically starts the protected mode. Remove all metal objects from the wireless charging panel and quickly double-click the power button to end protected mode.
- Hidden Holder: Press the "OPEN" key on the left and the back hidden holder will pop up.
- Please keep the product out of reach of children.
- When not in use, store the product in dry environment. To preserve lifespan, recharge and discharge it every 3 months.

**Cautions**

- Do not expose the product to excessive temperature or areas which may become hot, including but not limited to, on or near vehicles, space heaters, cooking appliances like oven.
- Use unapproved or incompatible power adapters, cables may result in fire, explosion or other hazards.
- Do not store the product in a restricted ventilation area like handbag for a long time, a closed-in area may result in fire or other hazards.
- The product contains a Lithium-ion battery: Disassembling product may cause property damage or fire.
- Do not drop, crush, puncture, short-circuit, or dispose of the product in fire or water.
- Disposal of the product separately from household waste, following local regulations.
- Do not use the product during a thunderstorm, it may cause malfunctions or electric shocks.

**Warranty Description**

If there is a failure caused by non-man-made reasons, consumers who purchased Huntkey products through legal channels can enjoy product warranty services within 12 months from the date of purchase.
In order to ensure your legitimate rights and interests, please keep in mind the following :
(1) The warranty card should be properly kept by the user. No replacement if lost. Invalid if altered.
(2) If there is a failure caused by non-man-made reasons, the user can use the warranty card and the purchase certificate for free maintenance at the designated maintenance point during the warranty period.
The following are not covered by warranty services:
- The product exceeds the warranty period;
- Damage caused by human factors;
- The warranty card model does not match the product model;
- There is no warranty card or the warranty card has been altered;
- There is no valid purchase certificate or no proof that the purchased product is within the warranty period;
- Unauthorized maintenance, violent operation, disassembling, modification, extrusion, liquid inlet, corrosion;
- Damage caused by force majeure such as flood, fire, lightning strike.

If the warranty service is void, the maintenance service is still required, Huntkey will calculate the appropriate maintenance fee according to the cost of parts and labor, make a maintenance quote to the user, and then provide maintenance services after obtaining the user's consent and payment.

**Warranty Card**

Dear users, thank you for using Huntkey's products. In order to better serve you, please read, fill out and properly keep this warranty card after purchasing the product.

Name _____
Address/Zip Code _____
Phone Number _____
Product Model _____
Product Serial Number _____
Date of Purchase _____
Invoice Number _____
Name of Marketing Unit _____
Add/Phone of Marketing Unit _____

**Shenzhen Huntkey Electric Co., Ltd**

Huntkey Industrial Park, Banxue Road, Banban, Shenzhen, Guangdong 518129 China

400-678-8388　www.huntkey.com

Made in China

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RF exposure statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Hunt-key

Power Your Dream

正面

反面

技术要求：

1. 材质：105g双铜；
2. 尺寸：65*65mm，公差+/-0.5mm；
3. 风琴折，双面黑白印刷，字迹清晰整洁；
4. 具体见签样；
5. 需满足航嘉无卤要求，所有物料及生产工艺必须满足相关安规要求及《Q01-731-18航嘉环境有害物质管理标准》最新版和《Q01-824-17充电器类产品包装外观检验标准》最新版。

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| Hunt-key 航嘉 | MATERIEL NAME | 说明书 | | MATERIAL | 105g双铜 | | |
| SHEET | 1 OF 1 | MATERIAL No. | 352-xxxx | | FILE NAME | 说明书/充电宝 | |
| UNIT | mm | SCALE | 1:1 | DATE | 2024.09.09 | REV | V01 |
| DESIGNED | | CHECKED | | CHECKED | | APPROVED | FILE No. |
| 陈金燕 | | 赵文博 | | 安少杰 | | 陈舜美 | |